

Container Refrigeration





OPERATIONS AND SERVICE MANUAL

For

PrimeLINE

69NT40-561-200 to 299 69NT40-561-500 to 599

PrimeLINE ONE[™]

69NT40-565-200 to 299 69NT40-565-500 to 599

Container Refrigeration Units



OPERATIONS AND SERVICE MANUAL

For

PrimeLINE

69NT40-561-200 to 299 69NT40-561-500 to 599

PrimeLINE ONE

69NT40-565-200 to 299

69NT40-565-500 to 599

Container Refrigeration Units

TABLE OF CONTENTS

PARAC	SRAPH	NUMBER	PAGE
SAFET	Y SUMI	MARY	1–1
1.1	GEN	NERAL SAFETY NOTICES	1–1
1.2	FIR	ST AID	1–1
1.3	OPE	ERATING PRECAUTIONS	1–1
1.4	MAI	NTENANCE PRECAUTIONS	1–1
1.5	SPE	ECIFIC HAZARD STATEMENTS	1–1
INTRO	DUCTIO	DN	2–1
2.1	INT	RODUCTION	
2.2	REF	FRIGERANT	2–1
2.3	CO	NFIGURATION IDENTIFICATION	2–1
2.4	FEA	ATURE DESCRIPTIONS	2–1
	2.4.1	Control Box	2–1
	2.4.2	Temperature Readout	2–1
	2.4.3	Pressure Readout	2–1
	2.4.4	Compressor	
	2.4.5	Condenser Coil	
	2.4.6	Evaporator	
	2.4.7	Evaporator Fan Operation	
	2.4.8	Plate Set	
2.5		FION DESCRIPTIONS	
	2.5.1	Battery	
	2.5.2	Dehumidification	
	2.5.3	USDA	
	2.5.4	Interrogator	
	2.5.5	Remote Monitoring	
	2.5.6	Communications Interface Module	
	2.5.7	Autotransformer	
	2.5.7	Gutters	
	2.5.9	Handles	2–3 2–3
	2.5.10	Thermometer Port	
	2.5.11	Water Cooling	
	2.5.12	Back Panels	
	2.5.13	460 Volt Cable	
	2.5.14	230 Volt Cable	
	2.5.15	Cable Restraint	
	2.5.16	Upper Air (Fresh Air Make Up)	
	2.5.17	Lower Air (Fresh Air Make Up)	
	2.5.18	Labels	
	2.5.19	Controller	
	2.5.20	Condenser Grille	
	2.5.21	Emergency Bypass	
	2.5.22	XtendFRESH	
	2.5.23	TripWise	
	2.5.24	FuelWise	2–4
	2.5.25	QUEST	2–4

i

T-362

DESCR	RIPTION		3–1
3.1	GEN	ERAL DESCRIPTION	3–1
	3.1.1	Refrigeration Unit - Front Section	3–1
	3.1.2	Compressor Section	3–2
	3.1.3	Air-Cooled Condenser Section	3–2
	3.1.4	Water-Cooled Condenser Section	3–6
	3.1.5	Fresh Air Makeup Vent	3–7
	3.1.6	Evaporator Section	3–7
	3.1.7	Control Box Section	3–10
	3.1.8	Communications Interface Module	3–10
3.2	REFI	RIGERATION SYSTEM DATA	3–11
3.3	ELEC	CTRICAL DATA	3–12
3.4	SAF	ETY AND PROTECTIVE DEVICES	3–13
3.5	REF	RIGERATION CIRCUIT	3–14
	3.5.1	Standard Operation	3–14
	3.5.2	Economized Operation	3–14
	3.5.3	Electronic Expansion Valve (EEV)	3–14
MICRO	PROCES	SSOR	4–1
4.1		PERATURE CONTROL MICROPROCESSOR SYSTEM	
	4.1.1	Controller	4–1
	4.1.2	Display Module and Keypad	4–1
4.2	CON	TROLLER SOFTWARE	4–3
	4.2.1	Configuration Software (CnF Variables)	4–3
	4.2.2	Operational Software (Cd Function Codes)	
4.3	MOD	DES OF OPERATION	4–19
	4.3.1	Start Up - Compressor Phase Sequence	4–19
	4.3.2	Start Up - Compressor Bump Start	4–19
	4.3.3	Perishable Mode Temperature Control	4–19
	4.3.4	Perishable Pulldown	4–19
	4.3.5	Perishable Steady State	4–19
	4.3.6		4–19
	4.3.7	Perishable Heating	4–20
	4.3.8	Perishable Dehumidification	4–20
	4.3.9	Perishable Dehumidification - Bulb Mode	4–21
	4.3.10		4–21
	4.3.11		4–22
	4.3.12	·	4–23
	4.3.13		4–23
	4.3.14	Frozen Mode - Temperature Control	4–23
	4.3.15		4–23
	4.3.16		4–24
	4.3.17		4–24
	4.3.18		4–24
	4.3.19	·	4–24
	4.3.20	·	. - . 4–25
	4.3.21		. - 0 4–26
	4.3.22	·	4–27
	4.3.23		4–28

T-362 ii

		4.3.24	QUEST Mode	4–28
	4.4	CON	TROLLER ALARMS	4–29
	4.5	PRE	-TRIP DIAGNOSTICS	4–42
		4.5.1	Controller Pre-Trip Test Codes	4–42
	4.6	DAT	ACORDER	4–48
		4.6.1	DataCORDER Description	4–48
		4.6.2	DataCORDER Configuration Software	4–49
		4.6.3	DataCORDER Operational Software	
		4.6.4	DataCORDER Power Up	4–53
		4.6.5	DataCORDER Alarms	
		4.6.6	Pre-Trip Data Recording	4–55
		4.6.7	DataCORDER Communications	
		4.6.8	USDA Cold Treatment	4–57
		4.6.9	ISO Trip Header	4–59
ΟP	ER <i>A</i>	ATION .	·	5–1
	5.1		PECTION	
	5.2		NECT POWER	
		5.2.1	Connecting to 380/460 VAC Power	
		5.2.2	Connecting to 190/230 VAC Power	
	5.3	ADJI	JST FRESH AIR MAKEUP VENT	
		5.3.1	Upper Fresh Air Makeup Vent	5–2
		5.3.2	Lower Fresh Air Makeup Vent	
		5.3.3	Vent Position Sensor	
	5.4	CON	NECT WATER-COOLED CONDENSER	
		5.4.1	Water-Cooled Condenser with Water Pressure Switch	5–4
		5.4.2	Water-Cooled Condenser with Condenser Fan Switch	5–4
	5.5	CON	NECT REMOTE MONITORING RECEPTACLE	5–5
	5.6	STAI	RTING AND STOPPING INSTRUCTIONS	5–5
		5.6.1	Starting the Unit	5–5
		5.6.2	Stopping the Unit	5–5
	5.7	STAI	RT-UP INSPECTION	5–5
		5.7.1	Physical Inspection	5–5
		5.7.2	Check Controller Function Codes	5–5
		5.7.3	Start Temperature Recorder	5–5
		5.7.4	Complete Inspection	5–5
	5.8	PRE	-TRIP DIAGNOSIS	5–6
		5.8.1	Prior to Starting a Pre-Trip	5–6
		5.8.2	Starting a Pre-Trip	5–6
		5.8.3	Displaying Pre-Trip Test Results	5–7
	5.9	PRO	BE DIAGNOSTICS	5–7
	5.1	0 OPT	IONAL OPERATING MODES	5–8
		5.10.1	Emergency Bypass Operation	5–8
		5.10.2	TripWise	5–9
		5.10.3	XtendFRESH	5–11
		5.10.4	Automatic Cold Treatment Mode	5–12
		5.10.5	Automatic Setpoint Change Mode	5–13
		5.10.6	Quest Mode	5–14
		5 10 7	FuelWise Mode	5–14

iii

T-362

5.1	10.8 Pharma Mode	5–14
TROUBLE	SHOOTING	6–1
6.1	UNIT WILL NOT START OR STARTS THEN STOPS	6–2
6.2	UNIT OPERATES LONG OR CONTINUOUSLY IN COOLING	6–2
6.3	UNIT RUNS BUT HAS INSUFFICIENT COOLING	6–3
6.4	UNIT WILL NOT HEAT OR HAS INSUFFICIENT HEATING	6–3
6.5	UNIT WILL NOT TERMINATE HEATING	6–3
6.6	UNIT WILL NOT DEFROST PROPERLY	6–3
6.7	ABNORMAL PRESSURES	6–4
6.8	ABNORMAL NOISE OR VIBRATIONS	6–4
6.9	MICROPROCESSOR MALFUNCTION	6–5
6.10	NO EVAPORATOR AIR FLOW OR RESTRICTED AIR FLOW	6–5
6.11	XTENDFRESH NOT OPERATING	6–5
6.12	ELECTRONIC EXPANSION VALVE MALFUNCTION	6–5
6.13	AUTOTRANSFORMER MALFUNCTION	6–6
6.14	WATER-COOLED CONDENSER OR WATER PRESSURE SWITCH	6–6
6.15	COMPRESSOR OPERATING IN REVERSE	6–6
6.16	ABNORMAL TEMPERATURES	6–6
6.17	ABNORMAL CURRENTS	6–6
SERVICE		7–1
7.1	SECTION LAYOUT	
7.2	MANIFOLD GAUGE SET	
7.2	2.1 Evacuating the Manifold Gauge Set	7–2
7.3	SERVICE CONNECTIONS	
7.3	3.1 Connecting the Manifold Gauge Set	
7.3		
7.4	PUMP DOWN THE UNIT	
7.4		
7.4	·	
7.5	REFRIGERANT LEAK CHECKING	
7.6	EVACUATION AND DEHYDRATION	
7.6	6.1 General	7–5
7.6		
7.6	·	
7.6		
7.7	REFRIGERANT CHARGE	
7.7		
7.7		
7.7		
7.8	CONVERTING TO R-513A REFRIGERANT	
7.9	COMPRESSOR	
7.9		
7.10	HIGH PRESSURE SWITCH	7–10
	10.1 Checking High Pressure Switch	7–10
	10.2 Replacing High Pressure Switch	7–11
7.11	CONDENSER COIL	7–11
	I1.1 Condenser Coil Cleaning	<i>7</i> –11
	I1.2 Condenser Coil Removal	<i>7</i> –11
	I 1.3 Condenser Coil Preparation	7_12

T-362 iv

7.11.4	Condenser Coil Installation	7–12
7.11.5	Micro Channel Heat Exchanger (MCHE) Repair Instructions	7–13
7.12 CON	DENSER FAN AND FAN MOTOR	7–17
7.12.1	Condenser Fan Motor Remove/Replace	7–17
7.13 WAT	ER-COOLED CONDENSER CLEANING	7–18
7.13.1	Cleaning Supplies Needed	7–18
7.13.2	Cleaning Procedure Summary	7–18
7.13.3	Cleaning Procedure Detailed	7–18
7.14 FILT	ER DRIER	7–20
7.14.1	Checking the Filter Drier:	7–20
7.14.2	Replacing the Filter Drier:	7–20
7.15 EVA	PORATOR COIL	7–21
7.15.1	Evaporator Coil Replacement	7–21
7.16 EVA	PORATOR HEATERS	7–21
7.16.1	Megger Testing the Heaters	7–22
7.17 EVA	PORATOR FAN AND MOTOR ASSEMBLY	7–23
7.17.1	Replacing the Evaporator Fan Assembly	7–23
7.17.2	Disassemble the Evaporator Fan Assembly	7–23
7.17.3	Assemble the Evaporator Fan Assembly	7–24
7.18 EVA	PORATOR SECTION CLEANING	7–25
7.18.1	Cleaning Preparation	7–25
7.18.2	Cleaning Procedure	7–26
7.19 ELEC	CTRONIC EXPANSION VALVE (EEV)	7–26
7.19.1	Removing an EEV	7–26
7.19.2	Installing an EEV	7–27
7.20 HUM	IIDITY SENSOR (HS)	7–27
7.20.1	Disabling the Humidity Sensor	7–27
	Checking the Operation of the Humidity Sensor (HS)	7–27
	NOMIZER SOLENOID VALVE (ESV)	7–29
7.21.1	Removing a Solenoid Valve Coil	7–29
7.21.2	Removing the Solenoid Valve	7–29
	Installing the Solenoid Valve	7–29
	Installing the Solenoid Valve Coil	7–29
	NOMIZER EXPANSION VALVE (EXV)	7–30
	Removing the Economizer Expansion Valve	7–30
	Installing the Economizer Expansion Valve	7–30
	UBLESHOOTING P6-7 (DUV)	7–30
	TAL UNLOADER VALVE (DUV)	7–31
	Removing the DUV	7–31
7.24.2	Installing the DUV	7–32
7.25 VAL\	VE OVERRIDE CONTROLS	7–32
	OTRANSFORMER	7–33
7.27 CON	TROLLER SERVICE	7–34
	Controller Module Handling	7–34
7.27.2	Controller Troubleshooting	7–35
	Removing and Installing a Controller	7–36
7.27.4	Battery Replacement	7–36
	ITPOLLED DECCEMENT DECCEDITIES	7 37

T-362

7.28.1	Downloading Unit Data	7–37
7.28.2	Loading Operational Software	7–37
7.28.3	Changing Controller Configuration	7–38
7.28.4	Setting the Date and Time	7–39
7.28.5	Setting the Container ID	7–39
7.29 TEM	IPERATURE SENSOR SERVICE	7–40
7.29.1	Ice Bath Preparation	7–40
7.29.2	Sensor Checkout Procedure	7–40
7.29.3	GDP Supply and Return Sensor Calibration	7–43
7.29.4	Sensor Replacement	7–49
7.29.5	Supply Sensor (STS/SRS) Reinstallation	7–51
7.29.6	Return Sensor (RRS/RTS) Reinstallation	7–51
7.29.7	Defrost Temperature Sensor (DTS) Reinstallation	7–52
7.29.8	Evaporator Temperature Sensor (ETS1/ETS2) Reinstallation	7–52
7.29.9	Compressor Discharge Temperature Sensor (CPDS) Reinstallation	7–52
7.30 VEN	IT POSITION SENSOR (VPS)	7–53
7.31 XTE	NDFRESH SERVICE	7–53
7.32 MAI	NTENANCE OF PAINTED SURFACES	7–53
7.33 COM	MMUNICATIONS INTERFACE MODULE INSTALLATION	7–54
7.33.1	Installing the Module	7–54
ELECTRICAL V	VIRING SCHEMATIC AND DIAGRAMS	8–1
EU DECLARAT	TION OF CONFORMITY	9–1
INDEX	IND	FY_1

T-362 vi

LIST OF ILLUSTRATIONS

FIGURE NUMBER	Page
Figure 3.1 Refrigeration Unit - Front Section	3–1
Figure 3.2 Compressor Section	3–2
Figure 3.3 Condenser Section with "C" Shape Coil (PIDs < NT3000)	3–3
Figure 3.4 Condenser Section, with MCHE and Steel Receiver (PIDs NT3000 to NT3099)	3–4
Figure 3.5 Condenser Section, with MCHE and Aluminum Receiver (PIDs > NT3100)	3–5
Figure 3.6 Tube In Shell Water-Cooled Condenser	3–6
Figure 3.7 Brazed Plate Water-Cooled Condenser	3–7
Figure 3.8 Evaporator Section	3–8
Figure 3.9 Evaporator Section - PrimeLINE ONE	3–9
Figure 3.10 Control Box Section	3–10
Figure 3.11 Refrigeration Circuit Schematic - Standard Operation	3–15
Figure 3.12 Refrigeration Circuit Schematic - Economized Operation	3–16
Figure 3.13 Refrigeration Circuit Schematic - Water-Cooled Condenser (Tube In Shell)	3–17
Figure 3.14 Refrigeration Circuit Schematic - Water-Cooled Condenser (Brazed Plate)	3–18
Figure 4.1 Controller	4–1
Figure 4.2 Display Module and Keypad	4–1
Figure 4.3 Controller Operation - Perishable Mode	4–20
Figure 4.4 Perishable Mode Cooling	4–22
Figure 4.5 Perishable Mode Heating	4–23
Figure 4.6 Controller Operation - Frozen Mode	4–24
Figure 4.7 Frozen Mode	4–25
Figure 4.8 Defrost	4–27
Figure 4.9 DataCORDER Configuration Screen	4–57
Figure 4.10 DataCorder Probe Calibration Screen	4–58
Figure 4.11 DataCorder Probe Calibration Screen	4–59
Figure 4.12 DataCorder Systems Tool Screen	4–59
Figure 5.1 Autotransformer	5–2
Figure 5.2 Upper Fresh Air Make Up Flow Chart	5–3
Figure 5.3 Diagram of Emergency Bypass Connections	5–9
Figure 5.4 TripWise Status in DataCorder	5–10
Figure 5.5 Generating TripWise Summary Report	5–11
Figure 6.1 Unit Troubleshooting Sequence	6–1
Figure 7.1 Manifold Gauge Set	7–1
Figure 7.2 Manifold Gauge / Hose Set	7–2
Figure 7.3 Service Valve	7–3
Figure 7.4 Refrigeration System Service Connections	7–5
Figure 7.5 Compressor Kit	7–9
Figure 7.6 High Pressure Switch Testing	7–10
Figure 7.7 Condenser Fan Position	7–13
Figure 7.8 Water-Cooled Condenser Cleaning - Forced Circulation	7–19
Figure 7.9 Water-Cooled Condenser Cleaning - Gravity Circulation	7–20
Figure 7.10 Heater Arrangement	7–21

vii T-362

Figure 7.11 Evaporator Fan Assembly	7–24
Figure 7.12 Access Panel Torque Pattern	7–25
Figure 7.13 Electronic Expansion Valve (EEV)	7–26
Figure 7.14 Coil View of Economizer Solenoid Valve (ESV)	7–29
Figure 7.15 Economizer Expansion Valve	7–30
Figure 7.16 Adapter and O-Ring	7–31
Figure 7.17 View of Digital Unloader Valve (DUV) Assembly	7–32
Figure 7.18 Autotransformer	7–34
Figure 7.19 Controller	7–35
Figure 7.20 Supply Sensors - Cover Assembly and Sensors	7–44
Figure 7.21 Removing Front Access Panels	7–45
Figure 7.22 Removing Evaporator Motor	7–45
Figure 7.23 Return Sensors - Bracket	7–45
Figure 7.24 Return Sensors - Cutting Wire Ties	7–46
Figure 7.25 DataLINE - Probe Calibration	7–46
Figure 7.26 DataLINE - Calibrate Sensors Button	7–47
Figure 7.27 DataLINE - Enter Service Center Information	7–47
Figure 7.28 Ice Bath	7–48
Figure 7.29 DataLINE - Start Cal Button	7–48
Figure 7.30 DataLINE - Calibration Results	7–49
Figure 7.31 Sensor Types	7–50
Figure 7.32 Sensor and Cable Splice	7–50
Figure 7.33 STS/SRS Positioning	7–51
Figure 7.34 RRS/RTS Positioning	7–51
Figure 7.35 ETS1/ETS2 Positioning	7–52
Figure 7.36 Compressor Discharge Temperature Sensor	7–52
Figure 7.37 Communications Interface Installation	7–54
Figure 8.1 LEGEND - Standard Unit Configuration	8–1
Figure 8.2 Schematic Diagram	8–2
Figure 8.3 Unit Wiring Diagram (Sheet 1 of 2)	8–3
Figure 8.4 Unit Wiring Diagram (Sheet 2 of 2)	8–4
Figure 8.5 Legend - Unit With Auto Transformer	8–5
Figure 8.6 Schematic Diagram - Unit With Auto Transformer	8–6
Figure 8.7 Unit Wiring Diagram - Unit With Auto Transformer (Sheet 1 of 2)	8–7
Figure 8.8 Unit Wiring Diagram - Unit With Auto Transformer (Sheet 2 of 2)	8–8

T-362 viii

LIST OF TABLES

TABLE NUMBER	Page
Table 3–1 Refrigeration System Data	3–11
Table 3–2 Electrical Data	3–12
Table 3–3 Safety and Protective Devices	3–13
Table 4–1 Display Module LEDs	. 4–2
Table 4–2 Keypad Function	. 4–2
Table 4–3 Controller Configuration Variables	. 4–3
Table 4–4 Controller Function Codes	. 4–5
Table 4–5 Alarm Indications and Descriptions	4–30
Table 4–6 Controller Pre-Trip Test Codes	4–42
Table 4–7 DataCORDER Configuration Variables	4–49
Table 4–8 Sensor Configuration	4-50
Table 4–9 DataCORDER Function Code Assignments	4–52
Table 4–10 DataCORDER Alarm Indications	4–54
Table 4–11 DataCORDER Pre-Trip Result Records	4–55
Table 7–1 Valve Override Control Displays	7–33
Table 7–2 Test Point Descriptions	7–35
Table 7–3 Sensor Resistance - AMBS, DTS, ETS, RRS, RTS, SRS, STS	7–42
Table 7–4 Sensor Resistance - PrimeLINE CPDS	7–43
Table 7–5 R-134a Refrigerant Pressure Temperature Chart	7–55
Table 7–6 R-513A Refrigerant Pressure Temperature Chart	7–58
Table 7–7 Recommended Bolt Torque Values (Dry, Non-Lubricated for 18-8 Stainless Steel)	7–61

ix

T-362

SECTION 1 SAFETY SUMMARY

1.1 General Safety Notices

Installation and servicing of refrigeration equipment can be hazardous due to system pressures and electrical components. Only trained and qualified service personnel should install, repair, or service refrigeration equipment. When working on refrigeration equipment, observe all potential Danger, Warning and Caution hazards, including those shown below and on hazard labels attached to the unit.

The following general safety notices supplement specific warnings and cautions appearing elsewhere in this manual. They are recommended precautions that must be understood and applied during operation and maintenance of the equipment covered herein. The general safety notices are presented in the following three sections labeled: First Aid, Operating Precautions and Maintenance Precautions. A listing of the specific warnings and cautions appearing elsewhere in the manual follows the general safety notices.

1.2 First Aid

An injury, no matter how slight, should never go unattended. Always obtain first aid or medical attention immediately.

1.3 Operating Precautions

Always wear safety glasses.

Keep hands, clothing and tools clear of the evaporator and condenser fans.

Wear appropriate personal protective equipment for the work being undertaken.

No work should be performed on the unit until all circuit breakers and Start-Stop switches are turned off, and power supply is disconnected.

In case of severe vibration or unusual noise, stop the unit and investigate.

1.4 Maintenance Precautions

Beware of unannounced starting of the evaporator and condenser fans. Do not open the condenser fan grille or evaporator access panels before turning power off, disconnecting and securing the power plug.

Be sure power is turned off before working on motors, controllers, solenoid valves and electrical control switches. Tag circuit breaker and power supply to prevent accidental energizing of circuit.

Do not bypass any electrical safety devices, e.g. bridging an overload, or using any sort of jumper wires. Problems with the system should be diagnosed, and any necessary repairs performed by qualified service personnel.

When performing any arc welding on the unit or container, disconnect all wire harness connectors from the modules in control boxes. Do not remove wire harness from the modules unless you are grounded to the unit frame with a static safe wrist strap.

In case of electrical fire, open circuit switch and extinguish with CO₂ (never use water).

1.5 Specific Hazard Statements

To help identify the label hazards on the unit and explain the level of awareness each one carries, an explanation is given with the appropriate consequences:

DANGER - means an immediate hazard that WILL result in severe personal injury or death.

WARNING - means to warn against hazards or unsafe conditions that COULD result in severe personal injury or death.

CAUTION - means to warn against potential hazard or unsafe practice that could result in personal injury, product or property damage.

The statements listed below are applicable to the refrigeration unit and appear elsewhere in this manual. These recommended precautions must be understood and applied during operation and maintenance of the equipment covered herein.

1–1 T-362



EXPLOSION HAZARD: Failure to follow this WARNING can result in death, serious personal injury and / or property damage. Never use air or gas mixtures containing oxygen (O_2) for leak testing or operating the product. Charge only with refrigerants R-134a or R-513A as specified for the unit model number: Refrigerant must conform to AHRI Standard 700 specification.

WARNING

Beware of unannounced starting of the evaporator and condenser fans. The unit may cycle the fans and compressor unexpectedly as control requirements dictate.

WARNING

Do not attempt to remove power plug(s) before turning OFF the Start-Stop switch (ST), unit circuit breaker(s) and external power source.

WARNING

Make sure the power plugs are clean and dry before connecting to power receptacle.

N WARNING

Make sure that the unit circuit breaker(s) (CB-1 & CB-2) and the Start-Stop switch (ST) are in the "O" (OFF) position before connecting to any electrical power source.

MARNING

Make sure power to the unit is OFF and power plug disconnected before replacing the compressor.

WARNING

Before disassembly of the compressor, be sure to relieve the internal pressure very carefully by slightly loosening the couplings to break the seal.

MARNING

Do not use a nitrogen cylinder without a pressure regulator.

⚠ WARNING

Do not open the condenser fan grille before turning power OFF and disconnecting power plug.

⚠ WARNING

Oakite No. 32 is an acid. Be sure that the acid is slowly added to the water. DO NOT PUT WATER INTO THE ACID - this will cause spattering and excessive heat.

⚠ WARNING

Wear rubber gloves and wash the solution from the skin immediately if accidental contact occurs. Do not allow the solution to splash onto concrete.

T-362 1–2



Always turn OFF the unit circuit breakers (CB-1 & CB-2) and disconnect main power supply before working on moving parts.

⚠ WARNING

Installation requires wiring to the main unit circuit breaker, CB-1. Make sure the power to the unit is off and power plug disconnected before beginning installation.

MARNING

Before powering on the unit, it is important to ensure that all dismantling work is done and tools are away and service personnel are not working on the unit at the time of power on.

WARNING

Before removing the Supply or Return air sensors from the unit, turn the ON/OFF switch and circuit breaker to the OFF position. Disconnect the power plug from the unit. Follow proper lockout/tagout procedures to ensure the power cannot inadvertently be energized. It is important that all dismantling work is done and tools and personnel are away from the unit before powering on the unit for calibration.

WARNING

When performing the Return Air Sensor calibration, disconnect both evaporator motors.

A CAUTION

When charging the unit with R-513A refrigerant, charge as a liquid only. R-513A is an azeotrope blend containing R-1234yf and R-134a. Charging or topping off as a vapor will result in an incorrect mixture of blend in the system.

A CAUTION

Charge water-cooled condenser or receiver according to nameplate specifications to ensure optimal unit performance.

A CAUTION

Do not remove wire harnesses from circuit boards unless you are grounded to the unit frame with a static safe wrist strap or equivalent static drain device.

A CAUTION

Remove the controller module and unplug all connectors before performing any arc welding on any part of the container.

⚠ CAUTION

Do not attempt to use an ML2i PC card in an ML3 equipped unit. The PC cards are physically different and will result in damage to the controller.

1–3 T-362



Pre-trip inspection should not be performed with critical temperature cargoes in the container.

A CAUTION

When PRE-TRIP key is pressed, economy, dehumidification and bulb mode will be deactivated. At the completion of pre-trip activity, economy, dehumidification and bulb mode must be reactivated.

A CAUTION

When condenser water flow is below 11 lpm (3 gpm) or when water-cooled operation is not in use, the CFS switch MUST be set to position "1" or the unit will not operate properly.

A CAUTION

When a failure occurs during automatic testing, the unit will suspend operation awaiting operator intervention.

A CAUTION

When Pre-Trip test Auto 2 runs to completion without being interrupted, the unit will terminate pre-trip and display "Auto 2" "end." The unit will suspend operation until the user depresses the ENTER key!

A CAUTION

The unit will remain in the full cooling mode as long as the EB switch is in the On position and the Mode Switch is in the Full Cool position. If the cargo can be damaged by low temperatures, the operator must monitor container temperature and manually cycle operation as required to maintain temperature within required limits.

A CAUTION

Allowing the scroll compressor to operate in reverse for more than two minutes will result in internal compressor damage. Turn the Start-Stop switch OFF immediately.

A CAUTION

To prevent trapping liquid refrigerant in the manifold gauge set, make sure set is brought to suction pressure before disconnecting.

⚠ CAUTION

The scroll compressor achieves low suction pressure very quickly. Do not use the compressor to evacuate the system below 0 psig. Never operate the compressor with the suction or discharge service valves closed (front seated). Internal damage will result from operating the compressor in a deep vacuum.

⚠ CAUTION

Take necessary steps (place plywood over coil or use sling on motor) to prevent motor from falling into condenser coil.

T-362 1–4



Do not remove wire harnesses from module unless you are grounded to the unit frame with a static safe wrist strap.

⚠ CAUTION

Unplug all module connectors before performing arc welding on any part of the container.

⚠ CAUTION

The unit must be OFF whenever a programming device is inserted or removed from the controller programming port.

⚠ CAUTION

Use care when cutting wire ties to avoid nicking or cutting wires.

A CAUTION

1–5

Do not allow moisture to enter wire splice area as this may affect sensor resistance.

T-362

SECTION 2 INTRODUCTION

2.1 Introduction

The Carrier Transicold PrimeLINE models 69NT40-561-200 to 299 and 69NT40-561-500 to 599 are units of lightweight aluminum frame construction, designed to be bolted on to the front of a container and serve as the container's front wall. Forklift pockets are provided for unit installation and removal.

The Carrier Transicold PrimeLINE ONE™ models 69NT40-565-200 to 299 and 69NT40-565-500 to 599 are units of lightweight aluminum frame construction, designed to be directly installed on-site onto a welded front wall of a container.

PrimeLINE units are self-contained, all electric units, which include cooling and heating systems to provide precise temperature control. The units are supplied with a complete charge of refrigerant and compressor lubricating oil, and are ready for operation upon installation.

The base unit operates on nominal 380/460 volt, 3-phase, 50/60 hertz (Hz) power. An optional autotransformer may be fitted to allow operation on nominal 190/230, 3-phase, 50/60 Hz power. Control system power is provided by a transformer which steps the supply power down to 18 and 24 volts, single phase.

The controller is a Carrier Transicold Micro-Link 3 microprocessor. The controller operates automatically to select cooling, holding or heating as required to maintain the desired set point temperature within very close limits. The unit may also be equipped with an electronic temperature recorder. The controller has a keypad and display for viewing or changing operating parameters. The display is also equipped with lights to indicate various modes of operation.

2.2 Refrigerant

PrimeLINE models 69NT40-561-200 to 299 and PrimeLINE ONE™ models 69NT40-565-200 to 299 are units designed to only be charged with R-134a refrigerant.

PrimeLINE models 69NT40-561-500 to 599 and PrimeLINE ONE™ models 69NT40-565-500 to 599 are R-513A-ready units. They are supplied with a complete charge of R-134a refrigerant. But, they are capable of being field converted to R-513A refrigerant at a later date as requested by the unit owner. R-513A is an azeotrope blend containing R-1234yf and R-134a. All information in this manual pertaining to R-513A is only applicable to 561-500 to 599 or 565-500 to 599 model units that have either been converted or are being converted to R-513A.

To convert a R-513A-ready unit to R-513A refrigerant, refer to the procedure in Section 7.8 of the Service chapter.

2.3 Configuration Identification

Unit identification information is provided on a unit nameplate (see **Figure 3.1**) located on the back wall of the condenser section. The nameplate provides the unit model number, serial number and parts identification number (PID). The model number identifies the overall unit configuration, while the PID number provides information on specific optional equipment, factory provisioned to allow for field installation of optional equipment and differences in detailed parts.

2.4 Feature Descriptions

2.4.1 Control Box

Units are equipped with an aluminum control box, and may be fitted with a lockable door.

2.4.2 Temperature Readout

The unit is fitted with suction and discharge refrigerant temperature sensors. The sensor readings may be viewed on the controller display.

2.4.3 Pressure Readout

The unit is fitted with an evaporator, suction, and discharge pressure transducers. The transducer readings may be viewed on the controller display.

2–1 T-362

2.4.4 Compressor

The unit is fitted with either an R-134a or an R-513A scroll compressor equipped with suction and discharge service connections. To identify an R-513A-ready compressor in the field, a green dot is located on the top of the compressor on the DUV fitting.

2.4.5 Condenser Coil

Units may be fitted either with a "C" shape condenser coil, or a "U" shape micro-channel heat exchanger (MCHE) condenser coil.

2.4.6 Evaporator

The evaporator section is equipped with an electronic expansion valve (EEV).

2.4.7 Evaporator Fan Operation

Units are equipped with three-phase evaporator fan motors. Opening of an evaporator fan internal protector will shut down the unit.

2.4.8 Plate Set

Each unit is equipped with a tethered set of wiring schematics and wiring diagram plates. The plate sets are ordered using a seven-digit base part number and a two-digit dash number.

2.5 Option Descriptions

Various options may be factory or field equipped to the base unit. These options are described in the following subparagraphs.

2.5.1 Battery

The refrigeration controller may be fitted with standard replaceable batteries or a rechargeable battery pack. Rechargeable battery packs may be fitted in the standard location or in a secure location.

2.5.2 Dehumidification

The unit may be fitted with a humidity sensor. This sensor allows setting of a humidity set point in the controller. In dehumidification mode, the controller will operate to reduce internal container moisture level.

2.5.3 USDA

The unit may be supplied with fittings for additional temperature probes, which allow recording of USDA Cold Treatment data by the integral DataCORDER function of the Micro-Link refrigeration controller.

2.5.4 Interrogator

Units that use the DataCORDER function are fitted with interrogator receptacles for connection of equipment to download the recorded data. Two receptacles may be fitted; one is accessible from the front of the container and the other is mounted inside the container (with the USDA receptacles).

2.5.5 Remote Monitoring

The unit may be fitted with a remote monitoring receptacle. This item allows connection of remote indicators for COOL, DEFROST and IN RANGE. Unless otherwise indicated, the receptacle is mounted at the control box location.

2.5.6 Communications Interface Module

The unit may be fitted with a communications interface module. The communications interface module is a slave module which allows communication with a master central monitoring station. The module will respond to communication and return information over the main power line. Refer to the ship master system technical manual for further information.

2.5.7 Autotransformer

An autotransformer may be provided to allow operation on 190/230, 3-phase, 50/60 Hz power. The autotransformer raises the supply voltage to the nominal 380/460 volt power required by the base unit. The autotransformer may also be fitted with an individual circuit breaker for the 230 volt power.

T-362 2–2

If the unit is equipped with an autotransformer and communications module, the autotransformer will be fitted with a transformer bridge unit (TBU) to assist in communications.

2.5.8 Gutters

Rain gutters may be fitted over the control box and recorder section to divert rain away from the controls.

2.5.9 Handles

The unit may be equipped with handles to facilitate access to stacked containers. These fixed handles are located on either side of the unit.

2.5.10 Thermometer Port

The unit may be fitted with ports in the front of the frame for insertion of a thermometer to measure supply and/or return air temperature. If fitted, the port(s) will require a cap and chain.

2.5.11 Water Cooling

The refrigeration system may be provisioned for a water-cooled condenser. The condenser is constructed using copper nickel tube for sea water applications. Refer to **Section 3.1.4** for a more detailed description of the water-cooled condenser.

2.5.12 Back Panels

Aluminum back panels may have access doors and/or hinge mounting.

2.5.13 460 Volt Cable

Various power cable and plug designs are available for the main 460 volt supply. The plug options tailor the cables to each customer's requirements.

2.5.14 230 Volt Cable

Units equipped with an autotransformer require an additional power cable for connection to the 230 volt source. Various power cable and plug designs are available. The plug options tailor the cables to each customer's requirements.

2.5.15 Cable Restraint

Various designs are available for storage of the power cables. These options are variations of the compressor section cable guard.

2.5.16 Upper Air (Fresh Air Make Up)

The unit may be fitted with an upper fresh air makeup assembly. The fresh air makeup assembly is available with a vent positioning sensor (VPS) and may also be fitted with screens.

2.5.17 Lower Air (Fresh Air Make Up)

The unit may be fitted with a lower fresh air makeup assembly. The fresh air makeup assembly is available with a vent positioning sensor (VPS) and may also be fitted with screens.

2.5.18 Labels

Safety Instruction and Function Code listing labels differ depending on the options installed. Labels available with additional languages are listed in the parts list.

2.5.19 Controller

Two replacement controllers are available:

- 1. Re-manufactured Controller is equivalent of a new OEM controller, supplied with a 12-month warranty.
- 2. Repaired Controller has had previous faults repaired and is upgraded with the latest software.

NOTE

Repaired controllers are NOT to be used for warranty repairs; only full OEM Re-manufactured controllers are to be used.

2–3 T-362

Controllers will be factory-equipped with the latest version of operational software, but will NOT be configured for a specific model number and will need to be configured at the time of installation or sale.

2.5.20 Condenser Grille

Condenser grilles are direct bolted.

2.5.21 Emergency Bypass

The optional Emergency Bypass switch (EB) functions to bypass the controller in the event of controller failure.

2.5.22 XtendFRESH

XtendFRESH™ is an OEM option that helps slow the ripening process by removing ethylene and simultaneously controlling CO₂ and O₂ levels in multiple combinations.

Procedures and technical information related to the XtendFRESH™ controlled atmosphere system can be found in the T-366 XtendFRESH Manual, located in the Literature section of the Container Refrigeration website. To find the manual from the Literature section, click on Options > XtendFRESH.

2.5.23 TripWise

TripWise[™] is a new premium option available for PrimeLINE units. TripWise is software logic that runs in the background during every voyage and will let you know whenever a standard pre-trip inspection (PTI) is needed. Refer to **Section 5.10.2** for more detail on the TripWise option.

2.5.24 FuelWise

FuelWise™ is a power-saving option available for PrimeLINE units. FuelWise software works by dynamically cycling the refrigeration system on and off to save energy while still maintaining temperature within +/- 0.25 degrees Celsius of setpoint on an hourly average.

2.5.25 QUEST

QUEST (Quality and Energy Efficiency in Storage and Transport) power-saving mode available for PrimeLINE units. QUEST reduces energy requirements by up to 50 percent while reducing emissions related to power consumption.

T-362 2–4

SECTION 3 DESCRIPTION

3.1 General Description

3.1.1 Refrigeration Unit - Front Section

The unit is designed so that the majority of the components are accessible from the front (see **Figure 3.1**). The unit model number, serial number and parts identification number can be found on the unit nameplate on the back wall under the condenser fan.




Figure 3.1 Refrigeration Unit - Front Section

- Upper Fresh Air Makeup Vent Panel. Located inside are: Evaporator Fan #2, Defrost Temperature Sensor (DTS)
- Access Panel. Located inside are: Evaporator Fan #1, Electronic Expansion Valve (EEV), Heat Termination Thermostat (HTT)
- 3) Fork Lift Pockets
- 4) Control Panel
- 5) Unit Display
- 6) Keypad
- 7) Remote Monitoring Receptacle (if equipped)

- 8) Start-Stop Switch (ST)
- 9) Compressor
- 10) Access Panel for Supply Temperature Sensor (STS) / Supply Recorder Sensor (SRS)
- 11) Ambient Temperature Sensor (AMBS)
- 12) Economizer Heat Exchanger
- 13) Options Label
- 14) Unit Nameplate
- 15) Power Cables and Plug
- 16) Autotransformer location (if equipped)
- 17) Condenser Fan

3–1 T-362

3.1.2 Compressor Section

The compressor section (see Figure 3.2) includes the compressor, digital unloader valve (DUV), high pressure switch, discharge pressure transducer (DPT), evaporator pressure transducer (EPT) and the suction pressure transducer (SPT). The supply temperature sensor (STS) and supply recorder sensor (SRS) are located to the left of the compressor.

Figure 3.2 Compressor Section


- 1) Compressor
- Compressor Discharge Temperature Sensor (CPDS) location
- 3) Discharge Connection
- 4) Suction Connection location
- 5) Compressor Terminal Box
- 6) Oil Drain location
- 7) Economizer Connection
- 8) Discharge Pressure Transducer (DPT)

- 9) Digital Unloader Valve (DUV)
- 10) Suction Pressure Transducer (SPT)
- 11) Evaporator Pressure Transducer (EPT)
- 12) High Pressure Switch (HPS)
- 13) Discharge Service Valve
- 14) Suction Service Valve
- 15) Supply Temperature Sensor (STS) / Supply Recorder Sensor (SRS)
- 16) Warning Label

3.1.3 Air-Cooled Condenser Section

The air-cooled condenser section (see **Figure 3.3**) consists of the condenser fan, condenser coil, receiver, liquid line service valve, filter drier, fusible plug, economizer, economizer expansion valve (EXV), economizer solenoid valve (ESV), and sight glass / moisture indicator. The condenser fan pulls air from around the coil and discharges it horizontally through the condenser fan grille.

Figure 3.3 Condenser Section with "C" Shape Coil (PIDs < NT3000)




- 1) Condenser Coil
- 2) Grille and Venturi Assembly
- 3) Condenser Fan
- 4) Condenser Coil Cover
- 5) Condenser Fan Motor
- 6) Receiver, Steel
- 7) Receiver Sight Glass

- 8) Receiver Moisture & Liquid Indicator
- 9) Fusible Plug
- 10) Filter Drier
- 11) Economizer
- 12) Economizer Solenoid Valve (ESV)
- 13) Economizer Expansion Valve (EXV)
- 14) Service Access Valve

- - - -

3–3 T-362

Figure 3.4 Condenser Section, with MCHE and Steel Receiver (PIDs NT3000 to NT3099)




- 1) MCHE Coil
- 2) Grille and Venturi Assembly
- 3) Condenser Fan
- 4) Condenser Coil Cover
- 5) Condenser Fan Motor
- 6) Receiver, Steel
- 7) Receiver Sight Glass

- 8) Receiver Moisture & Liquid Indicator
- 9) Fusible Plug
- 10) Service Access Valve
- 11) Filter Drier
- 12) Economizer
- 13) Economizer Solenoid Valve (ESV)
- 14) Economizer Expansion Valve (EXV)

- - -

Figure 3.5 Condenser Section, with MCHE and Aluminum Receiver (PIDs ≥ NT3100)



- 1) MCHE Coil
- 2) Grille and Venturi Assembly
- 3) Condenser Fan
- 4) Condenser Coil Cover
- 5) Condenser Fan Motor
- 6) Receiver, Aluminum
- 7) Receiver Sight Glass

- 8) Receiver Moisture & Liquid Indicator
- 9) Fusible Plug
- 10) Service Access Valve
- 11) Filter Drier
- 12) Economizer
- 13) Economizer Solenoid Valve (ESV)
- 14) Economizer Expansion Valve (EXV)

- - - -

3–5 T-362

3.1.4 Water-Cooled Condenser Section

The unit may contain a water-cooled condenser (WCC) installed as an option. When operating on the water-cooled condenser, the condenser fan is deactivated by a water pressure switch or condenser fan switch. There are two types of water-cooled condensers available and both are described below.

Tube in Shell Water-Cooled Condenser

The tube in shell water-cooled condenser section (see **Figure 3.6**) consists of a water-cooled condenser, sight glass, rupture disc, filter drier, water couplings, water pressure switch, economizer, economizer expansion valve (EXV), economizer solenoid valve (ESV), and moisture / liquid indicator. The water-cooled condenser is in series with the air-cooled condenser and replaces the standard unit receiver.

5 3 2 0 O 9 9 0 0 0 10 12 11 9

Figure 3.6 Tube In Shell Water-Cooled Condenser

- 1) Water-Cooled Condenser (WCC)
- 2) Rupture Disc
- 3) Moisture / Liquid Indicator
- 4) Filter Drier
- 5) Economizer
- 6) Economizer Solenoid Valve (ESV)

- 7) Economizer Expansion Valve (EXV)
- 8) Coupling Water In
- 9) Liquid Line Service Valve / Connection
- 10) Self Draining Coupling Water Out
- 11) Water Pressure Switch (WPS)
- 12) Sight Glass

Brazed Plate Water-Cooled Condenser

The brazed plate water-cooled condenser section (see **Figure 3.7**) consists of the brazed plate water-cooled condenser (WCC), water couplings, a water pressure switch and a fusible plug. The receiver is retained in this configuration and the brazed plate heat exchanger is placed between the air-cooled condenser and the receiver.

3

Figure 3.7 Brazed Plate Water-Cooled Condenser

- 1) Water-Cooled Condenser (WCC)
- 2) Coupling Water In

- 3) Self Draining Coupling Water Out
- 4) Water Pressure Switch (WPS)

3.1.5 Fresh Air Makeup Vent

The function of the upper or lower fresh air makeup vent is to provide ventilation for commodities that require fresh air circulation. Air exchange depends on static pressure differential, which will vary depending on the container and how the container is loaded.

Units may be equipped with a Vent Position Sensor (VPS). The VPS determines the position of the fresh air makeup vent (upper or lower, as equipped) and sends data to the controller display.


3.1.6 Evaporator Section

The evaporator section is shown in **Figure 3.8**. The evaporator fans circulate air through the container by pulling it into the top of the unit, directing it through the evaporator coil to be heated or cooled, and discharging it at the bottom.

Most evaporator components are accessible by removing the upper rear panel or by removing the evaporator fan access panels.

3–7 T-362

Figure 3.8 Evaporator Section




- 1) Evaporator Fan and Motor (EM1)
- 2) Evaporator Fan and Motor (EM2)
- 3) Return Temperature Sensor (RTS) / Return Recorder Sensor (RRS)
- 4) Humidity Sensor (HS), PIDs < NT2750**
- 5) Humidity Sensor (HS), PIDs ≥ NT2750**
- 6) Evaporator Coil
- 7) Heaters**

- 8) Heat Termination Thermostat (HTT)**
- 9) Defrost Temperature Sensor (DTS)**
- 10) Electronic Expansion Valve (EEV)
- 11) Evaporator Temperature Sensors (ETS1 / ETS2)
- 12) USDA Probe Receptacles (PR1, PR2, PR3)
- 13) Cargo Probe Receptacle (PR4)
- 14) Interrogator Connector Rear (ICR)

** general location, not shown in figure.

Figure 3.9 Evaporator Section - PrimeLINE ONE



- 1) Evaporator Fan and Motor (EM1)
- 2) Evaporator Fan and Motor (EM2)
- 3) Return Temperature Sensor (RTS) / Return Recorder Sensor (RRS) /
- 4) Humidity Sensor (HS)
- 5) Evaporator Coil
- 6) Heaters

- 7) Heat Termination Thermostat (HTT)**
- 8) Defrost Temperature Sensor (DTS)**
- 9) Electronic Expansion Valve (EEV)
- 10) Evaporator Temperature Sensors (ETS1 / ETS2)
- 11) USDA Probe Receptacles (PR1, PR2, PR3)
- 12) Cargo Probe Receptacle (PR4)
- 13) Interrogator Connector Rear (ICR)

** general location, not shown in figure.

3–9 T-362

3.1.7 Control Box Section

The control box (see **Figure 3.10**) includes: the manual operation switches, circuit breaker (CB-1), compressor, fan and heater contactors, control power transformer, fuses, keypad, display module, current sensor module, controller module and the communications interface module.

2 5 **□** 0 •**(**)• 14 0**(**)0 0 13 0 \bigcirc 12 11 10 8

Figure 3.10 Control Box Section

- 1) Compressor Contactor (CH)
- 2) Unit Phase A Contactor (PA)
- 3) Unit Phase B Contactor (PB)
- 4) Heater Contactor (HR)
- 5) Controller / DataCORDER Module
- Remote Monitoring Receptacle (RM)
- 7) Start-Stop Switch (ST)

- 8) Controller Battery Pack (standard location)
- 9) Control Transformer (TS)
- 10) Evaporator Fan Contactor High Speed (EF)
- 11) Evaporator Fan Contactor Low Speed (ES)
- 12) Condenser Fan Contactor (CF)
- 13) Circuit Breaker 460V (CB1)
- 14) Current Sensor Module

3.1.8 Communications Interface Module

The unit may be equipped with an optional communications interface module, which is a slave module that allows communication between the refrigeration unit and a ship system master central monitoring station. The module will respond to communication and return information over the ship's main power line. If equipped, this module is located next to the Controller. See the master system technical manual for further information.

3.2 Refrigeration System Data

Table 3-1 Refrigeration System Data

	Model Number	ZMD26KVE-TFD-272
Compressor / Motor Assembly	Weight (With Oil)	42.9 kg (95 lb)
Compressor / Motor Assembly	Approved Oil	Uniqema Emkarate RL-32-3MAF
	Oil Charge	1774 ml (60 ounces)
Electronic Expansion Valve (EEV) Superheat Evaporator	Verify at - 18°C (0°F) container box temperature	4.4 to 6.7°C (8 to 12°F)
Economizer Expansion Valve (EXV) Superheat	Verify at - 18°C (0°F) container box temperature	4.4 to 11.1°C (8 to 20°F)
Heater Termination	Opens	54° (+/- 3) C = 130° (+/- 5) F
Thermostat (HTT)	Closes	38° (+/- 4) C = 100° (+/- 7) F
High Pressure Switch (HPS)	Cut-Out	$25 (+/- 1.0) \text{ kg/cm}^2 = 350 (+/- 10) \text{ psig}$
Ingli Flessure Switch (HFS)	Cut-In	18 (+/- 0.7) kg/cm ² = 250 (+/- 10) psig

MARNING

EXPLOSION HAZARD: Failure to follow this WARNING can result in death, serious personal injury and / or property damage. Never use air or gas mixtures containing oxygen (O_2) for leak testing or operating the product. Charge only with refrigerants R-134a or R-513A as specified for the unit model number: Refrigerant must conform to AHRI Standard 700 specification.

Refrigerant R-134a / R-513A Conforming to AHRI standard 700 specifications.

A CAUTION

Charge water-cooled condenser or receiver according to nameplate specifications to ensure optimal unit performance.

Refrigerant Charge	PIDs Prior to NT2800:		
	WCC Tube-In-Shell	4.99 kg (11 lbs)	
	WCC Brazed Plate	4.85 kg (10.7 lbs)	
	Receiver	4.54 kg (10 lbs)	
	PIDs NT2800 and Up:		
	WCC Brazed Plate	4.58 kg (10.1 lbs)	
	Receiver	4.26 kg (9.4 lbs)	
Fusible Plug	Melting point	99°C = (210°F)	
	Torque	6.2 to 6.9 mkg (45 to 50 ft-lbs)	
Rupture Disc	Bursts at	35 +/- 5% kg/cm ² = (500 +/- 5% psig)	
	Torque	6.2 to 6.9 mkg (45 to 50 ft-lbs)	
Unit Weight	Refer to unit model number plate.		
Water Pressure Switch (WPS)	Cut-In	0.5 +/- 0.2 kg/cm ² (7 +/- 3 psig)	
	Cut-Out	1.6 +/- 0.4 kg/cm ² (22 +/- 5 psig)	

3–11 T-362

3.3 Electrical Data

Table 3–2 Electrical Data

	CB-1 (25 amp)	Trips at 29 amps	
Circuit Breaker	CB-2 (50 amp)	Trips at 62.5 amps	
	CB-2 (70 amp)	Trips at 87.5 amps	
Compressor Motor (CP)	Full Load Amps (FLA)	13 amps @ 460 VAC	
(,	Nominal Supply	380 VAC / 3 Phase / 50 Hz 460 VAC / 3 Phase / 60 Hz	
	Full Load Amps	.71 amps	.72 amps
	Horsepower	0.21 hp	0.36 hp
Condenser Fan Motor	Rotations Per Minute	1450 rpm	1750 rpm
(CM)	Voltage and Frequency	360 - 460 VAC +/- 2.5 Hz	400 - 500 VAC +/- 2.5 Hz
	Bearing Lubrication	Factory lubricated, additional grease not required.	
	Rotation	Counter-clockwise when viewed from shaft end.	
	Number of Heaters	6	
	Rating	750 watts +5/-10% each @ 230 VAC	
Evaporator Coil Heaters	Resistance (cold)	66.8 to 77.2 ohms @ 20°C (68°F)	
	Туре	Sheath	
		380 VAC / 3 Phase / 50 Hz	460 VAC / 3 Phase / 60 Hz
	Full Load Amps High Speed	1.07	.9
Evaporator Fan Motors (EM)	Full Load Amps Low Speed	0.47	0.47
	Nominal Horsepower High Speed	0.36	0.63
	Nominal Horsepower Low Speed	0.05	0.8
	Rotations Per Minute High Speed	2850 rpm	3450 rpm
	Rotations Per Minute Low Speed	1425 rpm	1725 rpm
	Voltage and Frequency	360 - 460 VAC +/- 1.25 Hz	400 - 500 VAC +/- 1.5 Hz
	Bearing Lubrication	Factory lubricated, additional grease not required	
	Rotation	CW when viewed from shaft end	
	Control Circuit	7.5 amps (F3A,F3B)	
Fuses	Controller / DataCORDER	5 amps (F1 & F2)	
	Emergency Bypass	10 amps (FEB)	
Vant Danitian Canaan	Electrical Output	0.5 VDC to 4.5 VDC over 90 degree range	
Vent Position Sensor (VPS)	Supply Voltage	5 VDC +/- 10%	
	Supply Current	5 mA (typical)	
Economizer Solenoid Valve (ESV) Coils 24 VDC	Nominal Resistance @ 77°F (25°C)	7.7 ohms +/- 5%	
	Maximum Current Draw	0.7 amps	
Digital Unloader Valve (DUV) Coils 12 VDC	Nominal Resistance @ 77°F (20°C)	14.8 ohms +/- 5%	
	Maximum Current Draw	929 mA	

Table 3–2 Electrical Data (Continued)

Electronic Expansion Valve (EEV) Nominal	Coil Feed to Ground (Gray Wire)	47 ohms		
Resistance	Coil Feed to Coil Feed	95 ohms		
Humidity Sensor (HS)	Orange wire	Power		
	Red wire	Output		
	Brown wire	Ground		
	Input voltage	5 VDC		
	Output voltage	0 to 3.3 VDC		
	Output voltage readings verses relative humidity (RH) percentage:			
	30%	0.99 V		
	50%	1.65 V		
	70%	2.31 V		
	90%	2.97 V		
Controller	Setpoint Range	-35 to +30°C (-31 to +86°F)		

3.4 Safety and Protective Devices

Unit components are protected from damage by safety and protective devices listed in **Table 3–3**. These devices monitor the unit operating conditions and open a set of electrical contacts when an unsafe condition occurs.

Open safety switch contacts on either or both of devices IP-CP or HPS will shut down the compressor.

Open safety switch contacts on device IP-CM will shut down the condenser fan motor.

The entire refrigeration unit will shut down if one of the following safety devices open: (a) circuit breaker(s); (b) fuse (F3A/F3B, 7.5A); or (c) evaporator fan motor internal protector(s) - (IP).

Table 3-3 Safety and Protective Devices

Unsafe Condition	Device	Device Setting
	Circuit Breaker (CB-1, 25 amp) - Manual Reset	Trips at 29 amps (460 VAC)
Excessive current draw	Circuit Breaker (CB-2, 50 amp) - Manual Reset	Trips at 62.5 amps (230 VAC)
	Circuit Breaker (CB-2, 70 amp) - Manual Reset	Trips at 87.5 amps (230 VAC)
Excessive current draw in the control circuit	Fuse (F3A & F3B)	7.5 amp rating
Excessive current draw by the controller	Fuse (F1 & F2)	5 amp rating
Excessive current draw by the Emergency Bypass module	Fuse (FEB)	10 amp rating
Excessive condenser fan motor winding temperature	Internal Protector (IP-CM) - Automatic Reset	N/A
Excessive compressor motor winding temperature	Internal Protector (IP-CP) - Automatic Reset	N/A
Excessive evaporator fan motor(s) winding temperature	Internal Protector(s) (IP-EM) - Automatic Reset	N/A
Abnormal pressures / temperatures in the high refrigerant side	Fusible Plug - Used on the Receiver Rupture Disc - Used on the Water-Cooled Condenser	99°C = (210°F) 35 kg/cm ² = (500 psig)
Abnormally high discharge pressure	High Pressure Switch (HPS)	Opens at 25 kg/cm ² (350 psig)

3–13 T-362

3.5 Refrigeration Circuit

3.5.1 Standard Operation

Starting at the compressor, (see Figure 3.11) the suction gas is compressed to a higher pressure and temperature.

The refrigerant gas flows through the discharge line and continues into the air-cooled condenser. When operating with the air-cooled condenser active, air flowing across the coil fins and tubes cools the gas to saturation temperature. By removing latent heat, the gas condenses to a high pressure/high temperature liquid and flows to the receiver, which stores the additional charge necessary for low temperature operation.

When operating with the water-cooled condenser active (see Figure 3.13, Figure 3.14), the refrigerant gas passes through the air-cooled condenser and enters the water-cooled condenser shell. The water flowing inside the tubing cools the gas to saturation temperature in the same manner as the air passing over the air-cooled condenser. The refrigerant condenses on the outside of the tubes and exits as a high temperature liquid. The water-cooled condenser also acts as a receiver, storing refrigerant for low temperature operation.

The liquid refrigerant continues through the liquid line, the filter drier (which keeps refrigerant clean and dry) and the economizer (not active during standard operation) to the electronic expansion valve (EEV).

As the liquid refrigerant passes through the variable orifice of the EEV, the pressure drops to suction pressure. In this process some of the liquid vaporizes to a gas (flash gas), removing heat from the remaining liquid. The liquid exits as a low pressure, low temperature, saturated mix. Heat is then absorbed from the return air by the balance of the liquid, causing it to vaporize in the evaporator coil. The vapor then flows through the suction tube back to the compressor.

On systems fitted with a water pressure switch, the condenser fan will be off when there is sufficient pressure to open the switch. If water pressure drops below the switch cut out setting, the condenser fan will automatically start.

During the standard mode of operation, the normally closed digital unloader valve (DUV) controls the system refrigerant flow and capacity by loading and unloading the compressor in frequent discrete time intervals. If the system capacity has been decreased to the lowest allowable capacity with the DUV, the unit will enter a trim heat mode of operation, during which the controller will pulse the evaporator heaters in sequence with the compressor digital signal in order to absorb the excess capacity.

3.5.2 Economized Operation

In the economized mode, (see **Figure 3.12**) the frozen and pull down capacity of the unit is increased by subcooling the liquid refrigerant entering the electronic expansion valve. Overall efficiency is increased because the gas leaving the economizer enters the compressor at a higher pressure, therefore requiring less energy to compress it to the required condensing conditions.

Liquid refrigerant for use in the economizer circuit is taken from the main liquid line as it leaves the filter drier. The flow is activated when the controller energizes the economizer solenoid valve (ESV).


The liquid refrigerant flows through the ESV to the expansion valve internal passages, absorbing heat from the liquid refrigerant flowing to the electronic expansion valve. The resultant "medium" temperature/pressure gas enters the compressor at the economizer port fitting.

When the control air temperature falls to 2.0°C (3.6°F) above setpoint, the DUV unloads the compressor's scroll and begins to reduce the capacity of the unit. Percentage of the unit capacity is accessed through code select 01 (Cd01). For example, if Cd01 displays 70, it indicates that the compressor is operating unloaded with the DUV engaged 30% of the time.

3.5.3 Electronic Expansion Valve (EEV)

The microprocessor controls the superheat leaving the evaporator via the electronic expansion valve (EEV), based on inputs from the evaporator pressure transducer (EPT). The microprocessor transmits electronic pulses to the EEV stepper motor, which opens or closes the valve orifice to maintain the superheat setpoint.

Figure 3.11 Refrigeration Circuit Schematic - Standard Operation




- 1) Compressor
- 2) Discharge Service Valve
- 3) Discharge Pressure Transducer (DPT)
- 4) Condenser
- 5) Receiver
- 6) Receiver Sight Glass
- 7) Fusible Plug
- 8) Receiver Liquid Level / Moisture Indicator
- 9) Liquid Line Service Valve
- 10) Filter Drier
- 11) Economizer
- 12) Economizer Solenoid Valve (ESV)

- 13) Economizer Expansion Valve (EXV)
- 14) Economizer Expansion Valve (EXV) Sensing Bulb
- 15) Economizer Connection
- 16) Electronic Expansion Valve (EEV)
- 17) Evaporator
- 18) Evaporator Temperature Sensor (ETS1)
- 19) Evaporator Temperature Sensor (ETS2)
- 20) Digital Unloader Valve (DUV)
- 21) Evaporator Pressure Transducer (EPT)
- 22) Suction Pressure Transducer (SPT)
- 23) Suction Service Valve

- - - -

3–15 T-362

Figure 3.12 Refrigeration Circuit Schematic - Economized Operation




- 1) Compressor
- 2) Discharge Service Valve
- 3) Discharge Pressure Transducer (DPT)
- 4) Condenser
- 5) Receiver
- 6) Receiver Sight Glass
- 7) Fusible Plug
- 8) Receiver Liquid Level / Moisture Indicator
- 9) Receiver Liquid Line Service Valve
- 10) Filter Drier
- 11) Economizer
- 12) Economizer Solenoid Valve (ESV)

- 13) Economizer Expansion Valve (EXV)
- 14) Economizer Expansion Valve (EXV) Sensing Bulb
- 15) Economizer Connection
- 16) Electronic Expansion Valve (EEV)
- 17) Evaporator
- 18) Evaporator Temperature Sensor (ETS1)
- 19) Evaporator Temperature Sensor (ETS2)
- 20) Digital Unloader Valve (DUV)
- 21) Evaporator Pressure Transducer (EPT)
- 22) Suction Pressure Transducer (SPT)
- 23) Suction Service Valve

T-362 3–16

Figure 3.13 Refrigeration Circuit Schematic - Water-Cooled Condenser (Tube In Shell)




- 1) Compressor
- 2) Discharge Service Valve
- 3) Discharge Pressure Transducer (DPT)
- 4) Condenser
- 5) Rupture Disk
- 6) Water-Cooled Condenser
- 7) Sight Glass
- 8) Coupling (Water In)
- 9) Water Pressure Switch (WPS)
- 10) Coupling (Water Out)
- 11) Moisture Indicator
- 12) Liquid Line Service Valve
- 13) Filter Drier

- 14) Economizer Solenoid Valve (ESV)
- 15) Economizer Expansion Valve (EXV)
- 16) Economizer Expansion Valve (EXV) Sensing Bulb
- 17) Economizer
- 18) Economizer Connection
- 19) Electronic Expansion Valve (EEV)
- 20) Evaporator
- 21) Evaporator Temperature Sensor (ETS1)
- 22) Evaporator Temperature Sensor (ETS2)
- 23) Digital Unloader Valve (DUV)
- 24) Evaporator Pressure Transducer (EPT)
- 25) Suction Pressure Transducer (SPT)
- 26) Suction Service Valve

3–17 T-362

Figure 3.14 Refrigeration Circuit Schematic - Water-Cooled Condenser (Brazed Plate)



- 1) Compressor
- 2) Discharge Service Valve
- 3) Discharge Pressure Transducer
- 4) Condenser
- 5) Water-Cooled Condenser
- 6) Coupling (Water In)
- 7) Water Pressure Switch
- 8) Coupling (Water Out)
- 9) Receiver
- 10) Fusible Plug
- 11) Receiver Sight Glass
- 12) Receiver Sight Glass / Moisture Indicator
- 13) Liquid Line Service Valve
- 14) Filter Drier

- 15) Economizer Solenoid Valve (ESV)
- 16) Economizer Expansion Valve (EXV)
- 17) Economizer Expansion Valve (EXV) Sensing Bulb
- 18) Economizer
- 19) Economizer Connection
- 20) Electronic Expansion Valve (EEV)
- 21) Evaporator
- 22) Evaporator Temperature Sensor (ETS1)
- 23) Evaporator Temperature Sensor (ETS2)
- 24) Digital Unloader Valve (DUV)
- 25) Evaporator Pressure Transducer (EPT)
- 26) Suction Pressure Transducer (SPT)
- 27) Suction Service Valve

T-362 3–18

SECTION 4 MICROPROCESSOR

4.1 Temperature Control Microprocessor System

The temperature control Micro-Link 3 microprocessor system consists of a control module (controller), keypad, display module and interconnected wiring.

4.1.1 Controller

The controller (see Figure 4.1) is fitted with test points, harness connectors and a software card programming port. The controller contains temperature control software and DataCORDER software. The temperature control software (see Section 4.2) functions to operate the unit components as required to provide the desired cargo temperature and humidity. The DataCORDER software (see Section 4.6) functions to record unit operating parameters and cargo temperature parameters for future retrieval.

Read the Controller Service section (see **Section 7.27**), including all caution statements, before performing any service on the controller.




Figure 4.1 Controller

- 1) Micro-Link 3 Controller / DataCORDER Module
- 2) Mounting Screw
- 3) Connectors
- 4) Test Points

- 5) Fuses
- 6) Control Circuit Power Connection
- 7) Software Programming Port
- 8) Battery Pack (Standard Location)

4.1.2 Display Module and Keypad

The display module and keypad (see **Figure 4.2**) are mounted on the control box door and serve to provide user access and readouts for both of the controller functions, temperature control and DataCORDER. The functions are accessed by keypad selections and viewed on the display module.



Figure 4.2 Display Module and Keypad



4–1 T-362

The display module consists of two 5-digit displays and seven indicator lights. The indicator lights are described in **Table 4–1**. The keypad consists of eleven push button switches that act as the user's interface with the controller. The switch functions are described in **Table 4–2**.

Table 4–1 Display Module LEDs

Light	Function
COOL (White / Blue)	Energized when the refrigerant compressor is energized.
HEAT (Orange)	Energized to indicate heater operation in heat mode, defrost mode, or dehumidification.
DEFROST (Orange)	Energized when the unit is in defrost mode.
IN RANGE (Green)	Energized when the controlled temperature probe is within specified tolerance of setpoint. The controlling probe in perishable range is the SUPPLY air probe and in frozen range is the RETURN air probe.
SUPPLY (Yellow)	Energized when the supply air probe is used for control. When this LED is illuminated, the temperature displayed in the AIR TEMPERATURE display is the reading at the supply air probe. This LED will flash if dehumidification or humidification is enabled.
RETURN (Yellow)	Energized when the return air probe is used for control. When this LED is illuminated, the temperature displayed in the AIR TEMPERATURE display is the reading at the return air probe.
ALARM (Red)	Energized when an active or inactive shutdown alarm is in the alarm queue.

Table 4–2 Keypad Function

Key	Function
CODE SELECT	Access function codes.
PRE-TRIP	Display Pre-Trip selection menu. Discontinue pre-trip in progress.
ALARM LIST	Display alarm list and clear alarm queue.
MANUAL DEFROST / INTERVAL	Display selected defrost mode. Press and hold this key for five seconds to initiate defrost using same logic as if the optional manual defrost switch was toggled on.
ENTER	Confirm a selection or save a selection to the controller.
Arrow Up	Change or scroll a selection up. Pre-trip advance or test interrupt.
Arrow Down	Change or scroll selection down. Pre-trip repeat backward.
RETURN / SUPPLY	Display non-controlling probe temperature (momentary display).
°C / °F	Display alternate english / metric scale (momentary display). When set to F, pressure is displayed in psig and vacuum in "/hg." "P" appears after the value to indicate psig and "i" appears for inches of mercury. When set to C, pressure readings are in bars. "b" appears after the value to indicate bars.
BATTERY POWER	Initiate battery backup mode to allow setpoint & function code selection if AC power is not connected.
ALT MODE	Switch the functions from temperature software to DataCORDER software. The remaining keys function the same as described above except the readings or changes are made to the DataCORDER programming.

4.2 Controller Software

The controller software is a custom designed program that is subdivided into configuration software and operational software. The controller software performs the following functions:

- Control supply or return air temperature to required limits, provide modulated refrigeration operation, economized operation, unloaded operation, electric heat control, and defrost. Defrost is performed to clear buildup of frost and ice to ensure proper air flow across the evaporator coil.
- Provide default independent readouts of setpoint and supply or return air temperatures.
- Provide ability to read and (if applicable) modify the configuration software variables, operating software function codes and alarm code indications.
- Provide a pre-trip step-by-step checkout of refrigeration unit performance including: proper component operation, electronic and refrigeration control operation, heater operation, probe calibration, pressure limiting and current limiting settings.
- Provide battery-powered ability to access or change selected codes and setpoint without AC power connected.
- · Provide the ability to reprogram the software through the use of a memory card.

4.2.1 Configuration Software (CnF Variables)

Configuration software is a variable listing of the components available for use by the operational software. This software is factory installed in accordance with the equipment fitted and options listed on the original purchase order. Changes to the configuration software are required only when a new controller has been installed or a physical change has been made to the unit such as the addition or removal of an option. A configuration variable list is described in **Table 4–3**. Change to the factory-installed configuration software is achieved via a configuration card or by communications.

Table 4–3 Controller Configuration Variables

Config	Title	Default	Option
CnF04	Enable Dehumidification	On	OFF
CnF08	Evaporator Motor Type	1Ph	3Ph
CnF11	Defrost "Off" Selection	noOFF	OFF
CnF18	Heater Type	Old (Low Watt)	nEW (High Watt)
CnF22	Economy Mode	OFF	Std, Full, CUSt
CnF23	Enable Defrost Interval Save	noSAv	SAv
CnF24	Enable Long Pre-Trip Test Series	Auto (Auto1)	Auto2, Auto3
CnF25	Enable Pre-Trip Data Recording	rSLtS	dAtA
CnF26	Heat Lockout Temperature	Set to -10C	Set to -5C
CnF28	Enable Bulb Mode	NOr	bULb
CnF31	Probe Check	SPEC	Std
CnF33	Enable Snap Freeze	OFF	SnAP
CnF34	Temperature Unit Display	bOth	F, C
CnF37	Electronic Chart Probe	rEtUR	SUPPL, bOth
CnF39	Enable Expanded Current Limits	Out	In
CnF41	Enable Low DTT Setting	Out	In
CnF42	Enable Auto Pre-Trip Trip Start	Out	In
CnF44	Autoslide Enable	Out	LO, UP
CnF45	Low Humidity Enabled	Out	In
CnF46	Quench / Liquid Injection Valve Type	nO	nC
CnF47	Vent Position	OFF	UP, LOW, CUStOM
CnF49	OEM Reset Option	OFF	Std, SPEC, CUSt

4-3

T-362

Table 4–3 Controller Configuration Variables (Continued)

Config	Title	Default	Option
CnF50	Enhanced Bulb Mode Interface	Out	In
CnF51	Timed Defrost Disable	Out	In
CnF52	Oil Return Algorithm	Out	In
CnF53	Water Cool Oil Return Logic	Out	In
CnF55	TXV Boost Relay	Out	In
CnF56	TXV Boost Circuit	Out	In
CnF57	PWM Compressor Control	Out	DUV, DUV module, ACDC coil
CnF59	Electronic Evaporator Expansion Valve	None	EC, KE, NA
CnF61	ACT ASC Control Enable	Out	In
CnF62	Extended Temperature Control Enable	Out	In
CnF63	QUEST Pre-Trip / TripWise Default State	On	Off
CnF64	Enable Fan Pulsing Logic	In	Out
CnF66	High Speed Evaporator Fan Option	Off	On
CnF67	Air Heaters	Out	In
CnF68	Enable Default Pulsing Temperature	Out	In
CnF70	Enable XtendFRESH Logic	Out	In
CnF71	XtendFRESH Pre-Trip / TripWise Default State	Off	On
CnF74	TripWise Pretrip / TripWise Default State	On	Off, ONALW
CnF78	XtendFRESH Scrubber Output Available	Out	In
CnF89	Time Based Defrost	Out	In

Note: Configuration numbers not listed are not used in this application. These items may appear when loading configuration software to the controller but changes will not be recognized by the controller programming.

4.2.2 Operational Software (Cd Function Codes)

The operational software is the actual operation programming of the controller which activates or deactivates components in accordance with current unit operating conditions and selected modes of operation.

The programming is divided into function codes. Some of the codes are read only, while the remaining codes may be user configured. The value of the user configurable codes can be assigned in accordance with user desired mode of operation. A list of the function codes is described in **Table 4–4**.

General Notes on Function Code Navigation

- 1. Press the CODE SELECT key on the keypad. Then, use the Arrow keys to navigate through the function codes (Cd) in the left display. The right display will show the respective data. If the right display shows dashes "-----", then this is an optional code not available to the system.
- 2. Press the ENTER key to navigate into the menu of the selected Cd code. Pressing the ENTER key will cause the present selected value to be displayed for 5 seconds, or until the user selects a different value. If additional time is required, pressing the ENTER key will extend the display time to 30 seconds.
- 3. Pressing CODE SELECT key in a selection menu cancels the current selection activity and ascends back up to the next higher selection menu.
- 4. If the operator does not press any key for five seconds the interface reverts to normal system display and the current selection menu is cancelled, but any previously committed changes are retained.

Code	Description
	NOTICE
	NOTICE
I	f a function is not applicable or the related option not purchased for the unit, the display will read ""
Display	Only Functions - Cd01 through Cd26 are display only functions.
Cd01	Capacity Modulation (%)
	Cd01 displays the DUV percent closed. The right display reads 100% when the valve is fully closed. The valve will usually be at 10% on start up of the unit except in very high ambient temperatures.
Cd03	Compressor Motor Current
	Cd03 displays the current value passing through the compressor motor leg T3. The current sensor measures current draw in lines L1 & L2 by all of the high voltage components. It also measures current draw in compressor motor leg T3.
Cd04	Line Current, Phase A
Cd05	Line Current, Phase B
Cd06	Line Current, Phase C
	Cd04, Cd05, Cd06 display the measured of Phase A, B and C in amperes. The current sensor measures current on two legs. The third unmeasured leg is calculated based on a current algorithm. The current measured is used for control and diagnostic purposes.
	For control processing, the highest of the Phase A and B current values is used for current limiting purposes. For diagnostic processing, the current draws are used to monitor component energization.
	Whenever a heater or a motor is turned ON or OFF, the current draw increase/reduction for that activity is measured. The current draw is then tested to determine if it falls within the expected range of values for the component.
	Failure of this test will result in a pre-trip failure or a control alarm indication.
Cd07	Main Power Voltage
	Cd07 displays the main supply voltage.
Cd08	Main Power Frequency
	Cd08 displays the value of the main power frequency in Hertz. The frequency displayed will be halved if either fuse F1 or F2 is bad (alarm code AL21).
Cd09	Ambient Temperature
	Cd09 displays the ambient sensor reading.
Cd10	Compressor Suction Temperature / Evaporator Temperature
	Cd10 displays the Evaporator Temperature Sensor (ETS) reading.
Cd11	Compressor Dome Temperature / Discharge Temperature
	Cd11 displays the Compressor Discharge Temperature Sensor (CPDS) reading, using compressor dome temperature, is displayed.
Cd12	Compressor Suction Port Pressure / Evaporator Pressure
	Cd12 displays the Evaporator Pressure Transducer (EPT) reading in the left display; Press ENTER at Cd12 to show reading for compressor suction port pressure in the right display.
Cd14	Compressor Discharge Pressure
	Cd14 displays the Compressor Discharges Pressure Transducer (DPT) reading.
Cd15	Digital Unloader Valve
	Cd15 displays the status of the Digital Unloader Valve (DUV) as Open or Closed.

4–5 T-362

Code	Description
Cd16	Compressor Motor Hour Meter / Unit Run Time Hour Meter
	Cd16 displays the compressor motor hours. The user can view unit run time by pressing the ENTER key while in Cd16. Total hours are recorded in increments of 10 hours (i.e., 3000 hours is displayed as 300).
	The Compressor Motor Hour Meter display can be reset to 0 by pressing and holding the ENTER key for 5 seconds. The Unit Run Time Hour Meter cannot be reset.
Cd17	Relative Humidity (%)
	Cd17 displays the Humidity Sensor (HS) relative humidity reading, as a percent value.
Cd18	Software Revision Number
	Cd18 displays the software revision number.
Cd19	Battery Check
	Cd19 checks the Controller / DataCORDER battery pack. While the test is running, "btest" will flash on the right display, followed by the result. "PASS" will be displayed for battery voltages greater than 7.0 volts. "FAIL" will be displayed for battery voltages between 4.5 and 7.0 volts, and "" will be displayed for battery voltages less than 4.5 volts.
	After the result is displayed for four seconds, "btest" will again be displayed, and the user may continue to scroll through the various codes.
Cd20	Config / Model Number
	Cd20 indicates the dash number of the model for which the Controller is configured (i.e., if the unit is a 69NT40-561-253, the display will show "61253"). To display controller configuration database information, press ENTER. Values in "CFYYMMDD" format are displayed if the controller was configured with a configuration card or with a valid OEM serial port configuration update; YYMMDD represents the publication date of the model configuration database.
Cd21	Capacity Mode
	Cd21 displays the mode of operation as Unloaded, Standard, or Economized.
Cd22	Compressor State
	Cd22 displays the status of the compressor as OFF or On.
Cd23	Evaporator Fan State
	Cd23 displays the current state of the evaporator fan as OFF, LOW or HIGH.
Cd25	Compressor Run Time Remaining Until Defrost
	Cd25 displays the time remaining until the unit goes into defrost (in tenths of an hour). This value is based on the actual accumulated compressor running time.
Cd26	Defrost Temperature Sensor Reading
	Cd26 displays the Defrost Temperature Sensor (DTS) reading.

Code	Description
Cd27	Defrost Interval (Hours or Automatic)
	Cd27 controls the Defrost Timer Interval, which is the desired period of time between defrost cycles. The user-selected intervals are 3, 6, 9, 12, 24 Hours, Off, AUTO, PuLS, AUTO2, or AUTO3. Factory default is "AUTO". See the Defrost Operation (Section 4.3.21) for information on Defrost Timer Interval.
	After a new Defrost Interval is selected, the previously selected Interval is used until the next defrost termination, the next time the DTT contacts are OPEN, or the next time power to the control is interrupted. If the previous value or the new value is "OFF", the newly selected value will be used immediately.
	If any Auto Pre-trip sequence is initiated, Cd27 will be set to 'AUTO' unless CnF49 (OEM Reset) is set to "Custom" AND CnF64 (Evaporator Fan Pulsing Logic) configuration variable is set to IN, in which case Cd27 will be set to "PuLS".
	CnF11 determines whether the operator will be allowed to chose "OFF" as a defrost interval option.
	CnF64 determines whether the operator will be allowed to choose "PuLS" as a defrost interval option. For units operating with "PuLS" selected, defrost interval is determined by the unit temperature setpoint and the Evaporator Fan Pulsing Temperature Setting (Cd60). When the unit temperature setpoint is equal to or less than the Evaporator Fan Pulsing Temperature Setting, the defrost interval is set to 6 hours. Otherwise, the defrost interval is determined using the Automatic Defrost Interval Determination logic. In either case, "PuLS" remains displayed in this function select code.
Cd28	Temperature Units (Degrees C or Degrees F)
	Cd28 controls the temperature units (C or F) that will be shown on all temperature values. The user selects C or F by selecting function code Cd28 and pushing the ENTER key.
	The factory default value is Celsius units. This function code will display "" if CnF34 is set to F.
Cd29	Failure Action (Mode)
	Cd29 controls the shutdown action to take if all of the control sensors are out of range (alarm code AL26) or there is a probe circuit calibration failure (alarm code AL27).
	Cd29 has one of four possible actions to select as described below:
	 A - Full Cooling (Compressor is on, economized operation.)
	b - Partial Cooling (Compressor is on, standard operation.)
	 C - Evaporator Fan Only (Evaporator fans on high speed, not applicable with frozen setpoints.) d - Full System Shutdown - Factory Default (Shut down every component in the unit.)
Cd30	In-Range Tolerance
	Cd30 controls the in-range tolerance, which determines the temperature band around the setpoint which will be designated as in-range. If the control temperature is in-range, the green IN-RANGE light will be illuminated.
	For normal temperature control, control temperature is considered in range if it is within setpoint in-range Tolerance. There are four possible values:
	• 1 = +/- 0.5°C (+/-0.9°F)
	• $2 = +/- 1.0$ °C (+/-1.8°F)
	• $3 = +/- 1.5$ °C (+/-2.7°F)
	• 4 = +/- 2.0°C (+/-3.6°F) - Factory Default
	In-range tolerance shall be set to +/- 2.0°C upon activation of Dehumidification or Bulb Mode (Cd33, Cd35, Cd48).
	When QUEST is actively controlling, in-range tolerance is not considered.
	"" will be displayed whenever Dehumidification or Bulb Mode is enabled or when CCPC with six hour re-activation is actively controlling.
	"" will be displayed whenever Frozen Economy Mode is operating.

4–7 T-362

Code	Description
Cd31	Stagger Start Offset Time (Seconds)
	Cd31 displays the stagger start offset time, which is the amount of time that the unit will delay at start-up. This allows multiple units to stagger their control initiation when all units are powered up together.
	The eight possible offset values are: 0 (Factory Default), 3, 6, 9, 12, 15, 18 or 21 seconds.
Cd32	System Current Limit (Amperes)
	Cd32 displays the current limit, which is the maximum current draw allowed on any phase at any time. Limiting the unit's current reduces the load on the main power supply. When desirable, the limit can be lowered. Note, however, that capacity is also reduced.
	The five values for 460 VAC operation are: 15, 17, 19, 21, or 23 amperes. The factory default setting is 21 amperes.
Cd33	Humidity Setpoint
	Cd33 controls dehumidification along with setting the relative humidity value in percent that will trigger dehumidification. Relative humidity is detected with a humidity sensor and this sensor reading can be viewed at Cd17. There are configuration variables that determine whether dehumidification capabilities are installed. Note: Humidification was once available but no longer supported.
	Cd33 has the following values / settings:
	"XX" - lower humidity setpoint
	• "dISbL" - This disables dehumidification entirely; the humidity sensor is removed from the logic. Humidity sensor variable CnF04 is set to OFF. This is available with software revision 5374 and higher. Refer to Disabling the Humidity Sensor procedure in Section 7.20.1 for detail.
	 "tESt" - Dehumidification test can be run. Setpoint will be temporarily set to 1%, during the test. After 5 minutes, the normal setpoint is restored.
	"OFF" - Turns off dehumidification.
	"XX" - upper humidity setpoint
	If Pre-Trip Inspection is initiated, Cd33 will be set to "OFF" automatically.
	If CnF50 Enhanced Bulb Mode Interface is active, then Cd33 will show instead Cd48 Dehumidification / Bulb Cargo Mode Parameter Selection.
Cd34	Economy Mode (On-Off)
	Cd34 displays the current state of the Economy Mode option, "", On, or OFF.
	CnF22 determines whether Economy Mode offered. Economy Mode is a user selectable mode of operation provided for power saving purposes.
Cd35	Bulb Mode
_	Cd35 displays the current state of the Bulb Mode option, "", nOr, or bULb.
	Bulb Mode is an extension of dehumidification control (Cd33). If dehumidification (CnF04) is set to "Off," Cd35 will display "Nor" and the user will be unable to change it. CnF28 determines whether the Bulb Mode selection is offered.
	After a dehumidification setpoint has been selected and entered for code Cd33, the user may then change Cd35 to "bulb." After Bulb Mode has been selected and entered, the user may then utilize function codes Cd36 and Cd37 to make the desired changes.
	If CnF50, Enhanced Bulb Mode, is active then Cd35 will instead show settings for Cd48.

Cd36	
	Evaporator Fan Speed
	Cd36 is for setting the desired evaporator fan speed for use during the Dehumidification Bulb Mode option.
	This code is enabled only if Dehumidification Mode (Cd33) is On and Bulb Mode (Cd35) has been set to "bulb." If these conditions are not met, "alt" will be displayed (indicating that the evaporator fans will alternate their speed) and the display cannot be changed.
	If a dehumidification setpoint has been selected along with Bulb Mode then "alt" may be selected for alternating speed, "Lo" for low speed evaporator fan only, or "Hi" for high speed evaporator fan only.
	If a setting other than "alt" has been selected and Bulb Mode is deactivated in any manner, then selection reverts back to "alt."
	If CnF50, Enhanced Bulb Mode, is active then Cd36 will instead show settings for Cd48.
Cd37	Variable DTT Setting (Bulb Mode)
	Cd37 displays the variable Defrost Termination Thermostat (DTT) setting to be used with the optional Bulb Mode functionality. This item is only displayed if the Bulb Mode option is configured on.
	If CnF50, Enhanced Bulb Mode, is active then Cd37 will instead show settings for Cd48.
Display	Only Functions - Cd38 through Cd40 are display only functions.
Cd38	Secondary Supply Temperature Sensor
	Cd38 displays the current Supply Recorder Sensor (SRS) reading only if the unit is configured for four probes and the DataCORDER is configured OFF. Otherwise, Cd38 will display dashes ""
	If the DataCORDER suffers a failure (alarm AL55), Cd38 will display the SRS reading.
Cd39	Secondary Return Temperature Sensor
	Cd39 displays the current Return Recorder Sensor (RRS) reading only if the unit is configured for four probes and the DataCORDER is configured OFF. Otherwise, Cd39 will display dashes ""
	If the DataCORDER suffers a failure (alarm AL55), Cd39 will display the RRS reading.
Cd40	Container Identification Number
	Cd40 displays the Container ID number. If a valid container id exists, the default display for Cd40 will be "XXXXX" where "XXXXX" is the 5th character through the 9th character of the container id. Pressing the ENTER key on Cd40 will display "id Y" "YYYYYYY" where "YYYYYYY" is the 5th character to the 11th character of the container id.
	If no valid container id exists or the container id is blank, the right display will alternate between "_nEEd" and "id". Pressing the ENTER key while on Cd40 in the state will prompt the Set Id Interface.
	On start up, if the container id is not valid, Cd40 will be brought up on the display for the first minute of power up. This can be left by either entering a container id or leaving the code select normally.
	Cd40 is configured at commissioning to read a valid container identification number. The reading will not display alpha characters; only the numeric portion of the number will display.
Cd41	Valve Override
	Cd41 is a SERVICE FUNCTION. This code is for troubleshooting and allows manual positioning of the Economizer Solenoid Valve (ESV), Electronic Expansion Valve (EEV), and Digital Unloader Valve (DUV). Provides readings such as: Percent Capacity, EEV, Capacity Mode, LIV and DUV. See Section 7.25 for operating instructions.

T-362

	lable 4–4 Controller Function Codes		
Code	Description		
Cd43	XtendFRESH Mode		
	Cd43 controls the XtendFRESH controlled atmosphere option. If a unit does not have the XtendFRESH option, dashes "" will be displayed.		
	Cd43 contains four selectable modes of operation:		
	 FrESh - All XtendFRESH operations are enabled and setpoints for CO₂ and O₂ can be edited. 		
	OFF - All XtendFRESH operations are disabled.		
	 tESt - Allows the user to test mechanical components, test and calibrate the CO₂ sensor and verify the validity of the O₂ sensor. 		
	 PUrgE - Allows the user to suspend XtendFRESH operations while pre-charging gas levels in the container. All XtendFRESH control actions and alarms 29 and 96 are suspended. 		
	Turn On XtendFRESH (Fresh Mode):		
	Use the Arrow keys to bring up "FrESh" and press ENTER.		
	2. The display will show "CO2SP" "#" , where # is the CO2 setpoint value. Use the Arrow keys to select a CO2 setpoint and press ENTER to confirm. Or, just press ENTER to keep the originally displayed value.		
	The CO2 setpoint is the maximum level of CO2 allowed for the cargo. The range is 0% to 19% in 1% increments, with a default setting of 5%.		
	3. The display will show "O2 SP" "#" , where # is the O2 setpoint value. Use the Arrow keys to select an O2 setpoint and press ENTER to confirm. Or, just press ENTER to keep the originally displayed value.		
	The O2 setpoint is the minimum level of oxygen allowed for the cargo. The range is 3% to 21% in 1% increments, with a default setting of 10%.		
	Turn Off XtendFRESH:		
	To manually turn XtendFRESH Mode Off from the Cd43 menu, use the Arrow keys to bring up "OFF" and press ENTER.		
	For detailed procedures and technical information related to the XtendFRESH controlled atmosphere, refer to the T-366 XtendFRESH Manual.		
Display	Only Function - Cd44 is a display only function.		
Cd44	XtendFRESH Values		
	Cd44 displays the following XtendFRESH values:		
	CO2 setpoint		
	CO2 percentage		
	O2 setpoint		
	O2 percentage		
	O2 voltage		
	For the CO ₂ setpoint, the range is from 0 to 19% in 1% increments with a default setting of 5%.		
	For the O ₂ setpoint, the range is from 3% to 21% in 1% increments with a default setting of 10%.		
	For detailed procedures and technical information related to the XtendFRESH controlled atmosphere, refer to the T-366 XtendFRESH Manual.		

Code	Description		
	Configurable Functions - Cd45 through Cd48 are user-selectable functions. The operator can change the value of these functions to meet the operational needs of the container.		
Cd45	Vent Position Sensor (VPS) Position		
	Cd45 displays positional values for the Vent Position Sensor (VPS). Values are to 240 for UPPER, 0 to 225 for LOWER. If a unit does not configured for a VPS, dashes will be displayed "".		
	When configured for VPS, Cd45 displays the current VPS position in units of 5 CMH (displayed as "CM") or CFM (displayed as "CF") depending on the selection of Cd46 (Airflow display units), Cd28 (Metric/Imperial) or the pressing of the deg C/F key.		
	Cd45 will display whenever the control detects movement via the VPS unless AL50 is active. Cd45 will display for 30 seconds, then time out and return to the normal display mode.		
Cd46	Airflow Display Units		
	Cd46 selects the airflow units to be displayed by Cd45 if configured for Vent Position Sensor (VPS) or displayed by "USER/FLO" under Cd43 if configured for Autoslide.		
	CF = Cubic Feet per Minute		
	CM = Cubic Meters per Hour		
	bOth = Displays CF or CM depending on the setting of Cd28 (Metric/Imperial) or the pressing of the degree C/F key.		
Cd47	Variable Economy Temperature Setting		
	Cd47 controls the Variable Economy Temperature setting. This is applicable when Economy Mode (CnF22) is set to 3-cust. Cd47 will show dashes "" if the unit is not configured for Economy Mode.		
	When the unit has a perishable setpoint and Economy Mode is active, at the start of each cooling or heating cycle, high speed evaporator fans will run for three minutes. After three minutes, the evaporator fans will be switched to low speed any time that the supply temperature is within +/- 0.25°C of the setpoint and the return temperature is less than or equal to the supply temperature + the user selected Cd47 (values are 0.5°C - 4.0°C, default is 3.0°C).		

4–11 T-362

	Table 4–4 Controller Function Codes
Code	Description
Cd48	Dehumidification / Bulb Cargo Mode Parameter Selection
	Initially Cd48 will display current Dehumidification Mode: bUlb (bulb cargo mode), dEhUM (normal dehumidification), or OFF.
	Pressing ENTER key will take the interface down into a hierarchy of parameter selection menus (mode, setpoint, evaporator speed, DTT setting). Pressing ENTER key in any parameter selection menu commits to selection of the currently displayed parameter and causes the interface to descend into the next parameter selection menu. All parameter selection menus alternate between a blank display and the current selection in the right hand display.
	Available parameters and parameter ranges are a function of configuration options and previously selected parameters as indicated above.
	Whenever any pre-trip test is initiated, Dehumidification Mode goes to OFF.
	Whenever Dehumidification Mode goes to OFF:
	 Dehumidification control setpoint goes to 0% RH internally but will then initialize to 95% RH when Dehumidification Mode leaves OFF.
	 Evaporator speed select goes to Alt for units without PWM Compressor Control (Cnf57 = Out), Evaporator speed select goes to Hi for units with PWM Compressor Control (Cnf57 = In).
	DTT setting goes to 25.6°C or 18.0°C, depending on Cnf41.
	Whenever Dehumidification Mode is set to bUlb, DTT setting goes to 18.0°C if it had been set higher.
	Whenever Dehumidification Mode is set to dEhUM, DTT setting goes to 25.6°C or 18.0°C, depending on Cnf41.
	For units without PWM Compressor Control (Cnf57 = Out):
	 Whenever dehumidification control setpoint is set below 65% RH evaporator speed select goes to LO if it had been set to Hi.
	 Whenever dehumidification control setpoint is set above 64% RH evaporator speed select goes to Alt if it had been set to LO.
	For units with PWM Compressor Control (Cnf57 = In):
	 Whenever dehumidification control setpoint is set below 60% RH, the evaporator fan speed is set to LO, the user has the ability to set the evaporator fan speed to Hi via the keypad.
	Whenever dehumidification control setpoint is set equal to or above 60% RH, the evaporator fan speed is set to Hi, the user has the ability to set the evaporator fan speed to LO via the keypad.
Display	Only Function - Cd49 is a display only function.
Cd49	Days Since Last Successful Pre-Trip
	Cd49 displays the number of days since last successful pre-trip sequence.
	Press ENTER to view the number of days since the last successful pre-trip for AUTO1, AUTO2, and AUTO3 in sequence.
	Press CODE SELECT to step back through the list and ultimately to exit the Cd49 display.
_	trable Functions - Cd50 through Cd53 are user-selectable functions. The operator can change the value functions to meet the operational needs of the container.

	Table 4–4 Controller Function Codes		
Code	Description		
Cd50	QUEST Enable / Disable		
	Cd50 enables or disables QUEST Mode, which is a power saving option that reduces energy requirements. Cd50 applies to either QUEST or QUEST II, depending on which option was chosen for the particular unit. QUEST II provides additional savings over QUEST. Configuration variables CnF60 and CnF65 determine the QUEST option available for the unit.		
	If the unit is not configured for QUEST Mode, then dashes will be displayed "".		
	Turn On QUEST Mode:		
	Select "On" and press the ENTER key to enable QUEST Mode.		
	When QUEST Mode is enabled:		
	Setpoint is maintained in Steady State Perishable mode after Perishable Pulldown.		
	 QUEST cycles the compressor on and off according to Return Air temperature and dehumidification is not allowed. 		
	 QUEST II cycles the compressor or the heaters on and off according to Return Air temperature and dehumidification is allowed. 		
	QUEST Mode Suspended:		
	If "On" is selected, QUEST operation may be suspended as indicated by one of the suspension codes listed below. If QUEST is not "OFF" and is not suspended, "On" will be displayed.		
	"SEtPt" = suspended by setpoint too low.		
	"CAHUM" = suspended by CA or humidity control.		
	"ACt" = suspended by ACT active.		
	"FAIL" = all return temperature probe failure for QUEST.		
	"PrtrP" = Pre-Trip Active.		
	"C LIM" = suspended by cool limit logic.		
	"PULL" = pulldown active.		
	"ALArM " = suspended by shutdown alarm		
	Turn Off QUEST Mode:		
	QUEST Mode is turned off automatically when any Trip Start occurs or Pre-Trip test is initiated.		
	Select "OFF" and press ENTER to disable QUEST Mode manually.		

Select "OFF" and press ENTER to disable QUEST Mode manually.

4–13 T-362

	Table 4–4 Controller Function Codes		
Code	Description		
Cd51	Automatic Cold Treatment (ACT) Mode Parameter Selection		
	Cd51 controls the Automated Cold Treatment (ACT) Mode option, which is a method to simplify the task of completing cold treatment by automating the process of changing the setpoints. Cold treatment is an effective post-harvest method to control Mediterranean and certain other tropical fruit flies.		
	If the unit is not configured for ACT or a valid probe setup is not detected (minimum of 3 USDA probes configured and detected), ACT can not be enabled. Cd51 will display dashes "".		
	Cd51 initially displays the countdown timer in days and hours remaining, regardless of whether it is enabled. In the Cd51 menu, pressing the ENTER key will take the interface down into a hierarchy of parameter selections. After the last parameter selection, pressing ENTER will return to "Cd 51".		
	Cd51 Parameter Selections:		
	"Cd 51" "X- X" (default "0-0") Countdown timer in days, hours		
	"ACt" "On" "OFF" or "" (default "OFF") Enabled or disabled status		
	"trEAt" "X.X°C" (default "0.0°C") Cold treatment setpoint edited in increments of 0.1 degrees		
	"DAyS" "X" (default "0") 0 to 99 in increments of 1		
	"ProbE" "XXXX" (default "") Probe positions, ex: "1234"		
	"SPnEW" "X.X°C" (default "10.0°C") Setpoint after ACT, edited in increments of 0.1 degrees		
	Turn On ACT:		
With "ACt" displayed, select "On" and press the ENTER key to enable ACT Mode. See Sec detail procedure to set ACT values using Cd51.			
	While ACT is On:		
	The left display will flash "COLd" and the right display will flash "trEAt", and this will alternate between the unit setpoint and control temperature at 5 second intervals. Once ACT is successful, the cargo setpoint (SPnEW setting) will be displayed in the left display and control temperature in the right display, alternating with "COLd" "Done". This will continue until ACT is turned off.		
	ASC (Cd53) is disabled. ACT and ASC can not be enabled simultaneously.		
	Setpoint change via the keypad is disabled.		
	QUEST Mode is suspended but QUEST II can still operate.		
	ACT Complete:		
	When ACT has completed, including reaching the new setpoint, the 2nd selection in the Cd51 menu will display "done" on the left display and the MONTH DAY of completion on the right display. Turning ACT off clears this entry. This action also resets Cd51 to initial time remaining. ACT must then be turned on to view or modify the additional parameters.		
	Turn Off ACT:		
	ACT mode is turned off automatically when any Auto Pre-Trip test or Trip Start is initiated.		
With "ACt" displayed, select "OFF" and press the ENTER key to disable ACT Mode manu			

	Table 4–4 Controller Function Codes			
Code	Description			
Cd53				
	Cd53 controls the Automated Setpoint Change (ASC) Mode option, which allows up to 6 setpoint changes to be pre-programmed over defined periods.			
	If the unit is not configured for ASC, then this will not be allowed and Cd53 will display dashes "".			
	Cd53 initially displays the countdown timer in days and hours remaining in the right display, regardless of whether it is enabled. In the Cd53 menu, pressing the ENTER key takes the interface down into a hierarchy of parameter selections. After the last parameter selection, pressing the ENTER key will return to "Cd 53".			
	Cd53 Parameter Selections:			
	"Cd 53" "X- X" (default "0-0") Countdown timer in days, hours			
	"ASC" "On" "OFF" or "" (default "OFF") Enabled or disabled status			
	"nSC" "X" (default "1") Number of setpoint changes, select from 1 to 6			
	"SP X" "XX.X°C" (default "0.0°C") Setpoint edited in increments of 0.1 degrees			
	"DAY (nSC-1)" "X" (default "1") 1 to 99 in increments of 1			
	"SP (nSC)" "X.X°C" (default "10.0°C") Setpoint after ACT, edited in increments of 0.1 degrees			
	Turn On ASC:			
	With "ASC" displayed, select "On" and press the ENTER key to enable ASC Mode. See Section 5.10.5 for detail procedure to set ASC values using Cd53.			
	While ASC is On:			
	The left display will alternate between current unit setpoint and "ASC". The right display will alternate between current control temperature and "ACtiV".			
	ACT (Cd51) is disabled. ASC and ACT can not be enabled simultaneously.			
	QUEST Mode is suspended but QUEST II can still operate			
	ASC Complete:			
	At completion of ASC mode, the left hand display will alternate between current unit setpoint and "ASC". The right hand display will alternate between current control temperature and "Done". The display will remain this way until ASC is turned off. With ASC complete, the second entry in the Cd53 menu will show "done" in the left display, and the Month / Day of completion in the right display.			
	Turn Off ASC:			
	ASC Mode is turned Off automatically when any Auto Pre-Trip test or Trip Start is initiated.			
	With "ASC" displayed, select "OFF" and press the ENTER key to disable ASC Mode manually.			
Display	Only Functions - Cd54 through Cd58 are display only functions.			
Cd54	Suction Port Superheat / Electronic Expansion Valve Status			
	Cd54 displays the reading for evaporator superheat (suction temperature minus suction saturation temperature as calculated from suction pressure) in the right display.			
	Press the ENTER key at Cd54 to show the reading for EEV position (in %) in the left display.			
Cd55	Discharge Superheat			
	Cd55 displays the discharge superheat (discharge temperature minus discharge saturation temperature as calculated from discharge pressure) values in C /F as calculated by the discharge temperature minus the discharge saturation temperature as calculated from discharge pressure.			
	If this selection is not valid, dashes "" will be displayed.			

4–15 T-362

Code	Description		
Cd58	Water Pressure Switch / Condenser Fan Switch State or Override Logic State		
	Cd58 displays "CLOSE" if the WPS or CFS switch contacts are closed or if these options are not installed "OPEn" is displayed when the WPS or CFS switch contacts are open.		
	When the WPS/CFS Override Logic is "TRUE", the right display will flash on all units. This is always the case, whether the unit has a WPS or CFS installed or not.		
	NOTES:		
	This CLOSE/OPEn state displayed in this Code Select function only applies to units that have the abilit to detect the state of a WPS/CFS. This function should not be relied upon to display the condition of the switch on units that don't have a WPS/CFS switch connected to ECG2 exclusively.		
	The ability of the WPS/CFS Override Logic to control the condenser fan is limited. It is not possible for thi logic to control the fan on units that have the WPS or CFS wired in series with the fan contactor. Units wired in this configuration can indicate that the WPS/CFS Override Logic is active by flashing the right display, however, the wiring will not allow for control of the condenser fan.		
	irable Functions - Cd59 through Cd65 are user-selectable functions. The operator can change the value functions to meet the operational needs of the container.		
Cd59	Pump Down Logic		
	Cd59 allows setting of the pump down logic control. The display will flash between "STArT PdN" and "PrESS EnTEr".		
	Upon entering Cd59 the operator will be required to acknowledge that they want to initiate the pump dow control. The display will flash between "STArT PdN" and "PrESS EnTEr". Once the decision to continuis confirmed pump down logic will begin, and will take complete control of the unit until pump down either succeeds or fails. This operation can not be halted once it begins without power cycling the unit.		
	After pump down logic has been initiated, the operator will be notified to close the Liquid Line Valve, th display will flash between "CLOSE LLV" and "PrESS EnTEr". Once complete the display will read "P dN to the left, and the current suction pressure to the right.		
	If the automatic pump down logic succeeds within 20 minutes, the unit will turn itself off, and the displa will notify the operator that pump down is complete by flashing between "P dN DOnE" and "SHUT OFF The operator must then shut off the unit.		
	If the automatic pump down logic does not complete within 20 minutes, the unit will drop out of Cd59 an return to its previous control condition.		
Cd60	Evaporator Fan Pulsing Temperature Setting		
	Cd60 contains a selectable temperature range used to determine the engagement point of the Evaporate Fan Pulsing logic. Default setting is -18.1°C. The user may change the temperature by pressing ENTEF then scrolling to the desired temperature using either Arrow key. Press Enter to accept the change. The temperature setting will be retained until either a pre-trip or Trip Start is initiated at which time the temperature will set to the default setting.		
	"" will be displayed if CnF68 is configured OUT.		
Cd62	High Speed Evaporator Fan Setting		
	Cd62 allows the evaporator fan speed to be forced to high while temperature control is being performe in the perishable setpoint range. When set to "On", evaporator fans operate in high speed regardless of any other active option that can control evaporator fan speed.		
	Following a power cycle, the state of the function select code is retained at its state prior to the power cycle. If "On", this function select code will be set to "OFF" when any Trip Start occurs or any pre-trip teris initiated.		
	"" will be displayed if setpoint is in frozen range or if CnF66 is configured OFF.		

Code	Description			
Cd63	FuelWise			
	Cd63 controls FuelWise Mode, which is an option that saves energy while operating in the perishable setpoint range. When operating in the frozen setpoint range, Frozen Economy Mode complements FuelWise. Note : FuelWise was previously referred to as Enhanced Economy Mode.			
	If the unit is not configured for FuelWise, then this will not be allowed and Cd63 will display dashes ""			
	Following a power cycle, the state of the function select code is retained at its state prior to the power cycle if CNF72 = Default ON else if Default OFF this will be set to OFF.			
	<u>Turn On FuelWise</u> :			
	Select "On" and press the ENTER key to enable FuelWise Mode.			
	<u>Turn Off FuelWise</u> :			
	FuelWise Mode is turned off automatically when any Trip Start occurs or Pre-Trip test is initiated.			
	Select "OFF" and press ENTER to disable FuelWise Mode manually.			
Cd65	TripWise Setting			
	Cd65 controls TripWise Mode, which is an option that can run software logic to check whether a standard Pre-trip Inspection (PTI) is needed and skip unless necessary.			
	If the unit is not configured for TripWise, then this will not be allowed and Cd65 will display dashes "".			
	Turn On TripWise:			
	Select "On" and press the ENTER key to enable TripWise Mode. See Section 5.10.2 for detail procedure to set TripWise values using Cd53.			
	Turn Off TripWise:			
	Select "OFF" and press the ENTER key to disable TripWise Mode manually.			
	Checking TripWise Status:			
	To check the status of the container, press the PRE-TRIP key on the keypad. The message "SELCt PrtrP" will appear on the display module, alternating with one of the following TripWise status messages			
	trIPW OFF. The TripWise option is turned off.			
	 trIPW EX (Expired). It is recommended to pre-trip the unit prior to the unit's next trip following customer-specific guidelines. 			
	 trIPW PASS. The container should be ready for use after the operator has conducted a visua inspection. Standard PTI is not required. 			
	 trIPW CHECK. If any TripWise test(s) execute and do not meet the pass / fail requirements, It is recommended to pre-trip the unit following customer-specific guidelines prior to the unit's next trip 			
Display	Only Functions - Cd66 and Cd67 are display only functions.			
Cd66	Instantaneous Power (kW)			
	Cd66 displays real power currently being used by the system in kW.			
Cd67	Total Power (kW-hr)			
	Cd67 displays energy used by the system since last Trip Start in kW-hrs.			
	rable Functions - Cd70 through Cd75 are user-selectable functions. The operator can change the value functions to meet the operational needs of the container.			

4–17 T-362

Code	Description			
Cd70	Temperature Setpoint Lock			
	Cd70 enables or disables the Temperature Setpoint Lock feature. When set to "On", this will prevent setpoint change from the keypad. The default setting is "OFF". An event will be recorded in the DataCorder each time an action is taken at Cd70.			
	Turn On Setpoint Lock:			
	Press the ENTER key. Use the Arrow keys to select "On" and press ENTER to confirm.			
	If Cd70 is set to "On" and a setpoint change is attempted with the keypad, "SPLk" "On" is displayed for five seconds to show that setpoint lock is turned On.			
	Turn Off Setpoint Lock:			
	Press the ENTER key. Use the Arrow keys to select "OFF" and press ENTER to confirm.			
	Cd70 will automatically be set to "OFF" with the selection of PTI or a TripWise on the unit.			
Cd75	Pharma Mode			
	Cd75 controls the Pharma Mode option, which allows cargoes to be maintained at temperature setpoints of either 5°C (41°F) or 20°C (68°F), while maintaining lower humidity levels.			
	Pharma mode is an available option for units that have installed software versions 5381 or higher and a humidity sensor that has not been disabled. Cd75 will show dashes "" if software version and humidity sensor state are not applicable.			
	Turn On Pharma Mode:			
	Select "On" and press the ENTER key. Use the Arrow keys to choose your selected setpoint of "05" or "20" and then press ENTER to confirm.			
	While Pharma Mode is On:			
	The left display toggles between Pharma setpoint and "PhArM". The right display shows the Return Temperature Sensor (RTS) reading.			
	The controller maintains the Return Air Temperature at setpoint, the yellow RETURN indicator light is illuminated.			
	The unit operates in a normal perishable control mode, while disabling any power saving features such as QUEST, etc.			
	Keypad entries such as MANUAL DEFROST, PRE-TRIP and setpoint temperature change are locked out. If setpoint temperature change is attempted, then display will show "SpLK On".			
	• Function codes related to operating modes are disabled and show dashes "" (Cd33, Cd34, Cd35, Cd36, Cd37, Cd41, Cd48 Cd50, Cd51, Cd53 Cd63, Cd65).			
	Turn Off Pharma Mode:			
	To disable Pharma Mode manually at Cd75, use the Arrow keys to select "OFF" and press ENTER to confirm.			

4.3 Modes of Operation

General operation sequences for cooling, heating and defrost are described in the following paragraphs.

Operational software responds to various inputs. These inputs come from the temperature sensors and pressure transducers, the temperature setpoint, the settings of the configuration variables and the function code assignments. The action taken by the operational software changes as the input values change. Overall interaction of the inputs is described as a "mode" of operation. The modes of operation include perishable (chill) mode and frozen mode. Descriptions of the controller interaction and modes of operation are provided in the following sub paragraphs.

4.3.1 Start Up - Compressor Phase Sequence

At start up, the controller logic checks for proper phase sequencing and compressor rotation. If incorrect sequencing is causing the compressor and three-phase evaporator fan motors to rotate in the wrong direction, the controller will energize or de-energize relay TCP as required. Relay TCP will switch its contacts, energizing or de-energizing relays PA and PB. Relay PA is wired to energize the circuits on L1, L2 and L3. Relay PB is wired to energize the circuits on L3, L2, and L1, thus providing reverse rotation.

4.3.2 Start Up - Compressor Bump Start

At start up, the controller logic will initiate a compressor bump start procedure to clear liquid refrigerant from the compressor. If suction and discharge pressures have equalized, the compressor will perform three compressor bump starts. A compressor bump start may also occur after a defrost cycle has been completed.

During bump start, the EEV will close. Relays TS, TQ, TN, TE, and TV will be de-energized (opened). The result of this action will close the ESV and shut all fans off. The compressor will start for 1 second, then pause for five seconds. This sequence will be repeated two more times. After the final bump start, the unit will pre-position the EEV to the correct starting position, pause and then start up.

4.3.3 Perishable Mode Temperature Control

In Perishable mode, the controller maintains the supply air temperature at setpoint, the SUPPLY indicator light is illuminated and the default reading on the display window is the supply temperature sensor reading.

When the supply air temperature enters the in-range temperature tolerance (Cd30), the green IN-RANGE light will energize. When CnF26 (Heat Lockout Temperature) is set to -10°C, Perishable mode is active with setpoints above -10°C (+14°F). When CnF26 is set to -5°C, Perishable mode is active with setpoints above -5°C (+23°F).

4.3.4 Perishable Pulldown

When the system is in Perishable Pulldown mode, the highest priority is given to bringing the container down to setpoint. When cooling from a temperature that is more than 2.5°C (4.5°F) above setpoint, the system will be in Perishable Pulldown mode in economized operation. However, pressure and current limit functions may restrict the valve if either exceeds the preset value.

4.3.5 Perishable Steady State

In Perishable Steady State mode, the control temperature is maintained near a setpoint that is above the heat lockout temperature. Once setpoint is reached, the unit will transition to Perishable Steady State mode. This results in unloaded operation by cycling the DUV to limit capacity and maintain steady temperature control.

The unit is capable of maintaining supply air temperature to within +/- 0.2°C (+/- 0.36°F) of setpoint. Supply air temperature is controlled by positioning of the electronic expansion valve (EEV), cycling of the digital unloader valve (DUV), cycling of the compressor, and cycling of the heaters.

4.3.6 Perishable Idle, Air Circulation

When it is unnecessary to run the compressor to maintain control temperature, the system enters Perishable Idle mode. If the controller has determined that cooling is not required or the controller logic determines suction pressure is at the low pressure limit, the unit will transition to Perishable Idle mode. During Perishable Idle mode, the compressor is turned off, but the evaporator fans continue to run to circulate air throughout the container. If temperature rises +0.2°C (0.4°F) above setpoint, the unit will transition back to Perishable Steady State mode.

4–19 T-362

4.3.7 Perishable Heating

When it is necessary to raise the control temperature, the system will enter Perishable Heating mode. If the temperature drops to 0.5°C (0.9°F) below setpoint, the unit will transition to Perishable Heating mode, and the heaters will be energized. The unit will transition back to Perishable Idle mode when the temperature rises to 0.2°C (0.4°F) below the setpoint, and the heaters will de-energize.




Figure 4.3 Controller Operation - Perishable Mode

4.3.8 Perishable Dehumidification

Dehumidification is provided to reduce the humidity levels inside the container. The dehumidification setpoint range is from 50% to 95%. Dehumidification is activated when a humidity value is set at Cd33. The yellow SUPPLY LED will flash ON and OFF every second to indicate that Dehumidification is active. Once Dehumidification is active and the following conditions are satisfied, the controller will activate the heat relay to begin Dehumidification.

- The humidity sensor reading is above the humidity setpoint (Cd33).
- The unit is in Perishable Steady State and supply air temperature is less than 0.25°C (0.45°F) above setpoint.
- The heater debounce timer (three minutes) has timed out.
- Heater Termination Thermostat (HTT) is closed.

If the above conditions are true for at least one hour, the evaporator fans will switch from high speed to low speed. Evaporator fan speed will then switch every hour, as long as the four conditions are met. See Bulb mode, **Section 4.3.9**, for different evaporator fan speed options.

If any condition except item (1) becomes false OR if the relative humidity sensed is 2% below the dehumidification setpoint, the high speed evaporator fans will be energized.

During dehumidification, power is applied to the defrost heaters. This added heat load causes the controller to open the EEV to match the increased heat load while still holding the supply air temperature very close to the setpoint.

Opening the EEV reduces the temperature of the evaporator coil surface, which increases the rate at which water is condensed and removes water from the passing air. Removing water from the air reduces the relative humidity. When the relative humidity sensed is 2% below setpoint, the controller de-energizes the heat relay. The controller

will continue to cycle heating to maintain relative humidity below the selected setpoint. If dehumidification is terminated by a condition other than the humidity sensor, e.g., an out-of-range or compressor shutdown condition, the heat relay is de-energized immediately.

Two timers are activated during dehumidification to prevent rapid cycling and consequent contactor wear:

- Heater debounce timer (three minutes) The heater debounce timer is started whenever the heater contactor status is changed. The heat contactor remains energized (or de-energized) for at least three minutes even if the setpoint criteria are satisfied.
- 2. Out-of-range timer (five minutes) The out-of-range timer is started to maintain heater operation during a temporary out-of-range condition. If supply air temperature remains outside of the user selected in-range setting for more than five minutes, the heaters will be de-energized to allow the system to recover. The out-of-range timer starts as soon as temperature exceeds in-range tolerance value set by Cd30.

4.3.9 Perishable Dehumidification - Bulb Mode

Bulb mode is an extension of dehumidification which allows changes to the evaporator fan speed and/or defrost termination setpoints.

Bulb mode is active when Cd35 is set to "Bulb." Once Bulb mode is activated, the user may then change dehumidification evaporator fan operation from the default (speed alternates from low to high each hour) to constant low or constant high speed. This is done by toggling Cd36 from its default of "alt" to "Lo" or "Hi" as desired. If low speed evaporator fan operation is selected, this gives the user the additional capability of selecting dehumidification setpoints from 50 to 95%.

In addition, if Bulb mode is active, Cd37 may be set to override the previous defrost termination thermostat (DTT) settings. The temperature at which the DTT will be considered "open" may be changed [in 0.1°C (0.2°F) increments] to any value between 25.6°C (78°F) and 4°C (39.2°F). The temperature at which the DTT is considered closed for interval timer start or demand defrost is 10°C (50°F) for "open" values from 25.6°C (78°F) down to a 10°C (50°F) setting. For "open" values lower than 10°C, the "closed" values will decrease to the same value as the "open" setting. Bulb mode is terminated when:

- Bulb mode code Cd35 is set to "Nor."
- Dehumidification code Cd33 is set to "Off."
- The user changes the setpoint to one that is in the frozen range.

When Bulb mode is disabled by any of the above conditions, evaporator fan operation for dehumidification reverts to "alt" and the DTS termination setting resets to the value determined by CnF41.

4.3.10 Perishable Economy

Economy Fan mode is an extension of the Perishable mode, and is provided for power saving purposes. Economy Fan mode is activated when Cd34 (also used for Frozen Economy mode) is set to "ON." Economy Fan mode is used in the transportation of temperature-tolerant cargo or non-respiration items which do not require high airflow for removing respiration heat.

There is no active display that indicates that Economy Fan mode has been initiated. To check for Economy Fan mode, perform a manual display of Cd34.

In order to initiate Economy Fan mode, a perishable setpoint must be selected prior to activation. When Economy Fan mode is active, the evaporator fans will be controlled as follows:

- a. At the start of each cooling or heating cycle, the evaporator fans will run in high speed for three minutes.
- b. They will then be switched to low speed any time the supply air temperature is within +/- 0.2°C (0.36°F) of the setpoint and the return air temperature is less than or equal to the supply air temperature + 3°C (5.4°F).
- c. The fans will continue to run in low speed for one hour.
- d. At the end of the hour, the evaporator fans will switch back to high speed and the cycle will be repeated. If Bulb mode is active, Economy Fan mode will be overridden.

4–21 T-362

4.3.11 Perishable Mode Cooling - Sequence of Operation

NOTE

In Standard Perishable mode, the evaporator motors run in high speed. In Economy Fan mode, the fan speed is varied.

a. When supply air temperature is above setpoint and decreasing, the unit will cool with the condenser fan motor (CF), compressor motor (CH), and evaporator fan motors (EF) energized, and the white COOL light illuminated (see **Figure 4.4**). Also, if current or pressure limiting is not active, the controller will close contacts TS to open the economizer solenoid valve (ESV) and place the unit in economized operation.




Figure 4.4 Perishable Mode Cooling

- b. When supply air temperature decreases to a predetermined tolerance above setpoint (Cd30), the green IN RANGE light is illuminated.
- c. As air temperature continues to fall, unloaded cooling starts (DUV pulses opens) as the supply air temperature approaches setpoint (see Figure 4.3).
- d. When unloaded cooling starts, EEV control will transition from a full cool superheat setpoint to a lower modulated cool superheat setpoint. Once unloading starts, the EEV controls evaporator superheat based on the system duty cycle where instantaneous superheat will vary.
- e. When the supply air temperature has fallen to within 1.9°C (3.4°F) of setpoint temperature and the average capacity of the system has fallen below 70%, the unit will open contacts TS to close the ESV and take the unit out of economized operation.
- f. The controller continuously monitors supply air temperature. Once the supply air temperature falls below setpoint, the controller periodically records supply air temperature, setpoint and time. A calculation is then performed to determine temperature drift from setpoint over time. If the calculation determines that cooling is no longer required, contacts TC and TN are opened to de-energize the compressor motor and the condenser fan motor. In addition the controller will close the EEV.
- g. The evaporator fan motors continue to run to circulate air throughout the container. The green IN RANGE light remains illuminated as long as the supply air temperature is within tolerance of the setpoint.
- h. If the supply air temperature increases to 1.0°C (1.8°F) above setpoint and three minutes have elapsed, contacts TC and TN close to restart the compressor and condenser fan motors in standard mode (non-economized) operation. The white COOL light is also illuminated.
- i. If the average system capacity has risen to 100% during unloaded cooling and three minutes off time has elapsed, relay TS will energize to open the ESV, placing the unit in economized mode.
- j. If the supply air increases more than 2.5°C (4.5°F) above setpoint temperature, the microprocessor will transition the evaporator superheat control from modulation back to full cool control.

4.3.12 Perishable Mode Heating - Sequence of Operation

- a. If the supply air temperature decreases 0.5°C (0.9°F) below setpoint, the system enters the heating mode (see Figure 4.3). The controller closes contacts TH (see Figure 4.5) to allow power flow through the heat termination thermostat (HTT) to energize the heaters (HR). The orange HEAT light is also illuminated. The evaporator fans continue to run to circulate air throughout the container.
- b. When the supply air temperature rises to 0.2°C (0.4°F) below setpoint, contact TH opens to de-energize the heaters. The orange HEAT light is also de-energized. The evaporator fans continue to run to circulate air throughout the container.
- c. The safety heater termination thermostat (HTT) is attached to an evaporator coil circuit and will open the heating circuit if overheating occurs.




Figure 4.5 Perishable Mode Heating

NOTE

The EEV and DUV are independently operated by the microprocessor. For full diagrams and legend, see **Section 8**.

4.3.13 Perishable Mode - Trim Heat

If the system capacity has been decreased to the lowest allowable capacity and conditions exist that warrant maximum temperature stability the controller will pulse the HR relay to energize the evaporator heaters in sequence with the compressor digital signal.

4.3.14 Frozen Mode - Temperature Control

In Frozen mode, the controller maintains the return air temperature at setpoint, the yellow RETURN indicator light is illuminated, and the default reading on the display window is the return temperature sensor (RTS) reading. When the return air temperature enters the in-range temperature tolerance (Cd30), the green IN-RANGE light will energize.

When CnF26 (Heat Lockout Temperature) is set to -10°C, frozen mode is active with setpoints below -10°C (+14°F). When CnF26 is set to -5°C, frozen mode is active with setpoints below -5°C (+23°F).

When the system is in Frozen mode, the highest priority is given to bringing the container down to setpoint, the system will remain in economized operation.

4.3.15 Frozen Steady State

Frozen cargos are not sensitive to minor temperature changes, and the frozen temperature control system takes advantage of this to greatly improve the energy efficiency of the unit. Frozen range temperature control is accomplished by cycling the compressor on and off as the load demand requires.

Once the frozen setpoint is reached, the unit will transition to frozen steady state (economized operation).

4–23 T-362

4.3.16 Frozen Idle Mode

When temperature drops to setpoint minus 0.2°C (0.4°F) and the compressor has run for at least five minutes, the unit will transition to the Frozen Idle mode. The compressor is turned off and the evaporator fans continue to run to circulate air throughout the container. If temperature rises above setpoint +0.2°C, (0.4°F) the unit will transition back to the frozen steady state mode.




Figure 4.6 Controller Operation - Frozen Mode

4.3.17 Frozen "Heat" Mode

If the temperature drops 10°C (18°F) below setpoint, the unit will transition to the Frozen "Heating" mode. The evaporator fans are brought to high speed, and the heat from the fans is circulated through the container. The unit will transition back to Frozen Steady State when the temperature rises back to the transition point.

4.3.18 Frozen Economy Mode

In order to activate Frozen Economy mode, a frozen setpoint temperature must be selected, and Cd34 (Economy Mode) set to "ON." When economy mode is active, the system will perform normal frozen mode operations except that the entire refrigeration system, excluding the controller, will be turned off when the control temperature is less than or equal to the setpoint -2°C (4°F).

After an off-cycle period of 60 minutes, the unit will turn on high speed evaporator fans for three minutes, and then check the control temperature. If the control temperature is greater than or equal to the frozen setpoint +0.2°C (0.4°F), the unit will restart the refrigeration system and continue to cool until the off-cycle temperature criteria are met. If the control temperature is less than the frozen setpoint +0.2°C (0.4°F) the unit will turn off the evaporator fans and restart another 60 minute off-cycle.

4.3.19 Frozen Mode Cooling - Sequence of Operation

- a. When the return air temperature is above setpoint and decreasing, the unit will transition to economized cooling with the condenser fan motor (CF), compressor motor (CH), economizer solenoid valve (ESV), low speed evaporator fan motors (ES) energized and the white COOL light illuminated (see Figure 4.7).
- b. When the return air temperature decreases to a predetermined tolerance above setpoint, the green INRANGE light is illuminated.

- c. When the return air temperature decreases to 0.2°C (0.4°F) below setpoint, contacts TC, TS and TN are opened to de-energize the compressor, economizer solenoid valve and condenser fan motor. The white COOL light is also de-energized. The EEV will close.
- d. The evaporator fan motors continue to run in low speed to circulate air throughout the container. The green IN-RANGE light remains illuminated as long as the return air is within tolerance of setpoint.
- e. If return air temperature drops to 10°C (18°F) or more below setpoint, the evaporator fans switch to high speed.
- f. When the return air temperature increases to 0.2°C (0.4°F) above setpoint and three minutes have elapsed, the EEV opens and contacts TC, TS and TN close to restart the compressor, open the ESV and restart the condenser fan motor. The white COOL is illuminated.




Figure 4.7 Frozen Mode

NOTE

The EEV and DUV are independently operated by the microprocessor. Complete schematics and legends are located in **Section 8**.

4.3.20 Defrost

Defrost is initiated to remove ice buildup from the evaporator coil which can obstruct air flow and reduce the cooling capacity of the unit. The defrost cycle may consist of up to three distinct operations depending upon the reason for the defrost or model number configuration. The first is de-icing of the coil, the second is defrost due to a probe check cycle and the third is a snap freeze process based on the unit model configuration.

- De-icing the coil consists of removing power to the cooling components (compressor, evaporator fans, and condenser fan), closing the EEV, and turning on the heaters, which are located below the evaporator coil.
 During normal operation, de-icing will continue until temperatures indicate that the ice on the coil has been removed, proper air flow has been restored, and the unit is ready to control temperature efficiently.
- If defrost was initiated by the probe check logic, then the Probe Check is carried out after the completion of the
 defrost cycle. A Probe Check is initiated only when there is an inaccuracy between the controller temperature
 sensors.
- Snap Freeze allows the system to cool for a period of time after de-icing, with the evaporator fans turned off and
 is only carried out if configured by model number. Snap-Freeze allows for the removal of latent de-icing heat
 from the evaporator coils, and freezes any remaining moisture that might otherwise be blown into the container.

For more information on Probe Check and Probe Diagnostics, see Section 5.9.

4–25 T-362

4.3.21 Defrost Operation


Initiation of defrost is dependent on the state of the Defrost Temperature Sensor (DTS). When the DTS senses a temperature less than 10°C (50°F), the defrost options become active and the timer is engaged for the initiation of the defrost cycle. The defrost time accumulates when the compressor is running. In the perishable mode this is the same as real time as the compressor in general runs continuously. In frozen mode the actual time necessary to count down to the next defrost will exceed the defrost interval depending on the compressor duty-cycle.

When the defrost mode is in the active state, defrost can be initiated when any one of the following additional conditions become true:

- Manually: While in the Defrost screen, when the Manual Defrost soft key is selected, if conditions will allow for a defrost, a manual defrost is initiated. The Defrost Indicator light is lit, and the user is brought back to the Main / Default screen.
 - While in the Defrost screen, when Manual Defrost soft key is selected, and conditions will NOT allow a defrost, a pop up message screen appears.
- Timer: The Defrost Interval Timer reaches the user selectable Interval. The user-selected intervals are 3, 6, 9, 12, 24 Hours, Off, AUTO, Pulse, or AUTO2; factory default is AUTO. See Defrost Interval setting on the Trip Settings screen.
 - a. Automatic defrost starts with an initial defrost at three hours and then adjusts the interval to the next defrost based on the accumulation of ice on the evaporator coil. Following a start-up or after termination of defrost, the time will not begin counting down until the DTS reading falls below 10°C (50°F). If the reading of DTS rises above termination setting any time during the timer count down, the interval is reset and the countdown starts over. The Auto defrost time is reset to three hours start time after every PTI initiation or Trip Start interval.
 - b. Fan Pulsing Logic is used to help prevent ice formation in the drain gutter and drain cup and ice buildup in supply air channel by using the evaporator fans to blow the warm air onto these areas during unit defrost. When cooling at lower set points, evaporator fan pulsing can be used during Defrost/De-ice when the "Pulse" option is selected for the Defrost Interval setting on the Trip Settings screen. When enabled, evaporator fan pulsing will occur based on the unit temperature set point and the Evap Fan Pulsing Temp setting on the Trip Settings screen. QUEST II also pulses the evaporator fans during Defrost/De-ice within a narrow perishable set point range. The logic for each evaporator fan pulsing feature is described below.
 - c. After a new Defrost Interval is selected, the previously selected Interval is used until the next defrost termination, the next time the DTS contacts are OPEN, or the next time power to the control is interrupted. If the previous value or the new value is "OFF", the newly selected value will be used immediately.
- 3. **Probe Check:** If defrost is initiated due to Probe Check immediately following the defrost cycle the evaporation fans are started and run for eight minutes to stabilize the temperature throughout the container. A probe check comparison is carried out at the end of the eight minute period if any sensor is found out of calibration. At this time its alarm set is no longer used for control/reorder purposes.
- 4. **Probe Check Logic:** The logic determines that a Probe Check is necessary based on temperature values currently reported by the supply and return probes
- 5. **Delta T Logic:** If the difference between return and supply air temperature (Delta T) becomes too great indicating possible reduced airflow over the evaporator coil caused by ice buildup requiring a defrost.
 - a. In Perishable Pull Down Delta T increases to greater than 12°C, and 90 minutes of compressor run time have been recorded.
 - b. In Perishable Steady State A baseline Delta T is recorded following the first defrost cycle after steady state conditions are reached, (the unit is cooling, and the evaporator fans and heaters must remain in a stable state for a period of five minutes). Defrost will be initiated if Delta T increases to greater than 4°C above the baseline, and 90 minutes of compressor run time have been recorded.
 - c. In Frozen Mode Defrost will be initiated if Delta T increases to greater than 16°C and 90 minutes of compressor run time have been recorded.

When defrost is initiated, the controller closes the EEV, opens contacts TC, TN and TE (or TV) to de-energize the compressor, condenser fan and evaporator fans. The controller then closes contacts TH to supply power to the heaters. The orange DEFROST light and heat light are illuminated and the COOL light is also de-energized.

Figure 4.8 Defrost



The EEV and DUV are independently operated by the microprocessor. Complete schematics and legends are located in Section 9.

Defrost will terminate when the DTS reading rises above one of two model number configurable options selection, either an upper setting of 25.6°C (78°F) which is default or lower setting of 18°C (64°F). When the DTS reading rises to the configured setting, the de-icing operation is terminated.

4.3.22 Defrost Related Settings

Defrost Temperature Sensor (DTS) Failure

When the return air temperature falls to 7°C (45°F), the controller ensures that the defrost temperature sensor (DTS) reading has dropped to 10°C or below. If it has not, it indicates a failed DTS. A DTS failure alarm is triggered and the defrost mode is operated by the return temperature sensor (RTS). Defrost will terminate after 1 hour.

If the DTS fails to reach is termination setting, the defrost terminate after 2 hours of operation.

Defrost Timer

If CnF23 is configured to "SAv" (save), then the value of the defrost interval timer will be saved at power down and restored at power up. This option prevents short power interruptions from resetting an almost expired defrost interval, and possibly delaying a needed defrost cycle. If the save option is not selected the defrost timer will reinitiate and begin recounting.

If CnF11 is model number configured to OFF the operator will be allowed to choose "OFF" as a defrost interval option.

If CnF64 is configured in the operator will be allowed to choose "PuLS" as a defrost interval option. For units operating with "PuLS" selected, defrost interval is determined by the unit temperature set point and the Evap Fan Pulsing Temp setting on the Trip Settings screen. When the unit temperature set point is equal to or less than the Evaporator Fan Pulsing Temperature Setting, the defrost interval is set to 6 hours. Otherwise, the defrost interval is determined using the Automatic Defrost Interval Determination logic. In either case, "PuLS" remains displayed in this function select code.

If any Auto Pretrip sequence is initiated, the Defrost Interval setting will be set to 'AUTO' unless CnF49 (OEM Reset) is set to "Custom" AND CnF64 (Evaporator Fan Pulsing Logic) configuration variable is set to IN, in which case the Defrost Interval setting on the Trip Settings screen will be set to "Pulse".

If defrost does not terminate correctly and temperature reaches the set point of the Heat Termination Thermostat (HTT) 54°C (130°F), the HTT will open to de-energize the heaters (AL059 & AL060). If the HTT does not open and termination does not occur within two hours, the controller will terminate defrost. AL060 will be activated to inform of a possible DTS failure.

4–27 T-362

4.3.23 Protection Modes of Operation

Evaporator Fan Operation

Opening of an evaporator fan internal protector will shut down the unit.

Failure Action

Function code Cd29 may be operator set to select the action the controller will take upon a system failure. The factory default is full system shutdown. See **Table 4–4**.

Generator Protection

Function codes Cd31 (Stagger Start, Offset Time) and Cd32 (Current Limit) may be operator set to control the start up sequence of multiple units and operating current draw. The factory default allows on demand starting (no delay) of units and normal current draw. See **Table 4–4**.

Compressor High Temperature Protection

The controller continuously monitors compressor discharge pressure and temperature, and suction pressure. If discharge pressure or temperature rises above the allowed limit or suction pressure falls below the allowed limit, the compressor will be cycled off and on every 3 minutes. Condenser and evaporator fans will continue to operate during the compressor off cycle.

If high compressor dome temperature occurs, as measured by the CPDS, the controller will allow additional refrigerant to be released into the system in order to provide cooling to the evaporator coil and compressor dome. The controller is alerted to high compressor dome temperatures via the CPDS when ambient temperature is greater than 43.3°C (110°F), return air temperature is less than -17.5°C (0.5°F) and the compressor discharge temperature is greater than 117.7°C (244°F).

Dome temperature control logic will disengage when return air temperature and ambient temperature return to allowed limits or when the compressor turns off.

Compressor Low Pressure Protection

If the suction pressure low limit is triggered, the DUV will energize to raise the suction pressure.

Perishable Mode - System Pressure Regulation

In Perishable mode, system pressures may need to be regulated at ambient temperatures of 20°C (68°F) and below. Once below this ambient temperature, the condenser fan may cycle on and off based on limits imposed for discharge pressure. For extremely cold ambient temperatures, -18°C (0°F), heater cycling may occur within normal system operation based on discharge pressure limits.

Condenser Fan Override

When CnF17 (Discharge Temperature Sensor) is set to "In" and CnF48 (Condenser Fan Switch Override) is set to "On", the condenser fan switch override logic is activated. If condenser cooling water pressure is sufficient to open the water pressure switch (de-energizing the condenser fan) when water flow or pressure conditions are not maintaining discharge temperature, the logic will energize the condenser fan as follows:

- 1. If the DUV is less than 80% open when the controller calls for it to be100% open, the condenser fan is energized. When the DUV is 100% open, the fan will de-energize.
- 2. If DPT reading is invalid or out of range (AL65), the condenser fan is energized and will remain energized until system power is cycled.
- 3. If the system is running on condenser fan override and the high pressure switch opens, the condenser fan is energized and will remain energized until the system power is cycled.

4.3.24 QUEST Mode

QUEST is a method of temperature control using compressor-cycle during steady-state perishable cooling (also referred to as Compressor-Cycle Perishable Cooling, CCPC) that cycles the compressor on and off according to return air temperature.

To be eligible for steady-state control, the unit must first complete a setpoint pulldown phase and a QUEST pulldown phase:

During setpoint pulldown, supply air temperature is controlled according to the unit's nominal supply air setpoint.

During QUEST pulldown, supply air temperature is lowered somewhat relative to the nominal setpoint.
 Evaporator fans are forced to operate at high speed.

Steady-state QUEST mode control maintains the same lowered supply air temperature that was used during QUEST pulldown. The compressor cycles on and off according to return air high and low limits. Depending on the fan mode of operation selected, the evaporator fans may be programmed to run at low speed some or all of the time according to the control logic.

4.4 Controller Alarms

Alarm display is an independent controller software function. If an operating parameter is outside of expected range or a component does not return the correct signals back to the controller, an alarm is generated. A listing of alarms is described in **Table 4–5**.

The alarm philosophy balances the protection of the refrigeration unit and that of the refrigerated cargo. The action taken when an error is detected always considers the survival of the cargo. Rechecks are made to confirm that an error actually exists.

Some alarms requiring compressor shutdown have time delays before and after to try to keep the compressor on line. An example is alarm code "LO," (low main voltage), when a voltage drop of over 25% occurs, an indication is given on the display, but the unit will continue to run.

When an Alarm Occurs:

- The red alarm light will illuminate for alarm code numbers 15, 17, 20, 21, 22, 23, 24, 25, 26, and 27.
- If a detectable problem exists, its alarm code will be alternately displayed with the setpoint on the left display.
- The user should scroll through the alarm list to determine what alarms exist or have existed. Alarms must be diagnosed and corrected before the Alarm List can be cleared.

To Display Alarm Codes:

- 1. While in the Default Display mode, press the ALARM LIST key. This accesses the Alarm List Display mode, which displays any alarms archived in the alarm queue.
- 2. The alarm queue stores up to 16 alarms in the sequence in which they occurred. The user may scroll through the list by pressing an Arrow key.
- 3. The left display will show "AL##," where ## is the alarm number sequentially in the queue.
- 4. The right display will show the actual alarm code. "AA##" will display for an active alarm, where "##" is the alarm code. Or "IA##" will display for an inactive alarm. See **Table 4–5** for alarm listing.
- 5. "END" is displayed to indicate the end of the alarm list if any alarms are active.
- 6. "CLEAr" is displayed if all alarms are inactive. The alarm queue may then be cleared by pressing ENTER. The alarm list will clear and "-----" will be displayed.

NOTICE

AL26 is active when none of the sensors are responding. Check the connector at the back of the controller, if it is loose or unplugged, reconnect it, then run a pre-trip test (P5) to clear AL26.

4-29 T-362

Table 4–5 Alarm Indications and Descriptions

AL03	Loss of Superheat C	control
Cause:	running. Compressor	ned below 1.66°C (3°F) degrees for five minutes continuously while compressor drawing more than 2.0 amps, compressor pressure ratio is greater than 1.8, and Valve (EEV) is at 0% open.
	Component	Electronic Expansion Valve (EEV)
	Troubleshooting	Check the operation of the EEV at code Cd41.
	Corrective Action	Replace EEV if defective.
	Component	Evaporator Temperature Sensor(s) ETS & ETS1.
	Troubleshooting	Verify accuracy of temperature sensors. See Sensor Checkout Procedure Section 7.29.2.
	Corrective Action	Replace ETS or ETS1 if defective.
	Component	Evaporator Fans
	Troubleshooting	Confirm fans operating properly
	Corrective Action	Replace fan(s) if defective. See Evaporator Fan Motor Assembly Section 7.17.
AL05	Manual Defrost Switch Failure	
Cause:	Controller has detected	ed continuous Manual Defrost Switch activity for five minutes or more.
	Component	Keypad
	Troubleshooting	Power cycle the unit.
	Corrective Action	Resetting the unit may correct problem, monitor the unit.
		If the alarm reappears after 5 minutes, replace the keypad.
AL06	Keypad or Keypad F	larness Fail
Cause:	Controller has detected	ed one of the keypad keys is continuously activity.
	Component	Keypad or Harness
	Troubleshooting	Power cycle the unit.
	Corrective Action	Resetting the unit may correct problem, monitor the unit.
		If the alarm reappears, replace the keypad and harness.
AL07	Fresh Air Vent Open	
Cause:	For units equipped with XtendFRESH and a Vent Position Sensor (VPS), the controller will monitor the manual fresh air opening at a pre-determined time. If during this time the fresh air vent is open and XtendFRESH is active, an alarm will be generated. If alarm is active, the controller monitors the manual fresh air once per hour. Upon clearing the alarm, the controller goes back to monitoring at the predetermined time.	
	Component	Vent Position Sensor (VPS)
	Troubleshooting	Manually reposition vent to 0% and confirm at code Cd45. If Cd45 is not reading 0%, perform a calibration of the panel. See VPS Service Section 7.30 .
	Corrective Action	If unable to obtain a zero reading, replace the defective VPS.
		If unit is loaded, ensure vent is closed. Note and replace VPS on next PTI. The alarm will not affect the XtendFRESH system from operating.

Table 4–5 Alarm Indications and Descriptions

AL08	High Compressor Pressure Ratio	
Cause:		charge pressure to suction pressure ratio is too high.
		empt to correct the situation by restarting the compressor.
	-	Discharge Pressure Transducer (DPT)
		Confirm accurate DPT pressure readings. See Manifold Gauge Set Section 7.2.
	Corrective Action	Replace DPT if defective.
AL09	O2 Sensor Failure	
Cause:	Triggered anytime the was detected.	$\ensuremath{\text{O}}_2$ sensor reading is outside of the normal operation range, after an initial signal
	Component	O ₂ Sensor, O ₂ Amplifier, Sensor Switch Module (if equipped)
	Troubleshooting	Check Cd44 and scroll down to 02V. The $\rm O_2$ sensor output will be displayed in millivolts (130mV to 4100mV).
		<u>Switch equipped</u> : If voltage is not present at Cd44 and a sensor switch module is installed, check for O_2 voltage on the black wire connected to the sensor switch module, connecting ground of meter to TP9. If the voltage is in the 130mV to 4.1V range, directly wire the black wire to KD04. This may cause an AL07 depending on O_2 reading but XtendFRESH will operate normally. If no voltage on the black wire, proceed to next step.
		Check wiring (see schematic), and correct if found mis-wired.
		If O_2 sensor is available, remove the upper fresh air panel and evaporator motor and replace the sensor. If after replacing sensor AL09 continues, replace amplifier.
		If parts are not available, turn XtendFRESH option off at code Cd43 and open the Manual Fresh Air Vent.
AL10	CO2 Sensor Failure	
Cause:	e: Triggered anytime the CO ₂ sensor reading is outside of the normal operation range, after an initial si was detected.	
	Component	CO ₂ Sensor
	Troubleshooting	Check the voltage at MC5 to the ground pin on TP9 (1 - 4.7 vdc).
		Check wiring (see schematic), and correct if found mis-wired.
		If part is available, remove upper fresh air panel and evaporator motor; replace sensor. If no part is available, take no action and service at next PTI. XtendFRESH will continuously run the scrubber. O2 level will be controlled with the opening and closing of the fresh air vents as required.
	Corrective Action	The alarm is triggered off when voltage is within operating range.
AL14	Phase Sequence De	tect Fault
Cause:	Controller is unable to	determine the correct phase relationship.
	Component	N/A
	Troubleshooting	Power cycle the unit.
	Corrective Action	Resetting the unit may correct problem, monitor the unit.
	Component	Wiring
	<u>-</u>	-

4–31 T-362

Table 4–5 Alarm Indications and Descriptions

		Table 4–5 Alarm indications and Descriptions
	Troubleshooting	Check unit wiring.
		Confirm pressure readings during start-up; suction pressure should decrease and discharge pressure should increase.
	Corrective Action	Correct wiring.
	Component	Current Sensor
	Troubleshooting	Check the right-most digit in display at code Cd41.
		If display is 3 or 4, check compressor / sensor wiring.
		If display is 5, the current sensor is defective.
	Corrective Action	Replace current sensor if defective.
AL16	Compressor Current	t High
Cause:	Compressor current d	raw is over the calculated maximum for 10 minutes.
	Component	Current Sensor
	Troubleshooting	Compare value at code Cd03 to actual measured current at wire T1-T2 or T3 going to the compressor contactor. If there is a difference, determine whether this is caused by current sensor or amp clamp tool.
	Corrective Action	Replace current sensor if defective.
	Component	Amperage is indeed too high.
	Troubleshooting	Confirm supply voltage / frequency is within specification and balanced according to Electrical Data Section 3.3.
	Corrective Action	Correct power supply.
	Component	Operating Conditions
	Troubleshooting	Make sure system pressures are relevant to operating conditions.
	Corrective Action	Check air flow of condenser.
		Check Refrigerant charge. See Refrigeration System Service Section 7.3.
	Component	Monitor Unit
	Troubleshooting	Alarm is display only the alarm may clear itself during operation.
	Corrective Action	If alarm remains active or is repetitive replace compressor at next available opportunity. See Compressor Service Section 7.9.
AL17	Compressor Pressu	re Delta Fault
Cause:	Compressor has attention between SPT and DP	npted to start in both directions and fails to generate sufficient pressure differential T.
	Component	N/A
	Troubleshooting	Controller will attempt to restart every 20 minutes and deactivate the alarm if successful.
	Corrective Action	Resume normal operation.
	Component	Discharge Pressure Transducer (DPT)
	Troubleshooting	Confirm accurate DPT pressure readings. See Manifold Gauge Set Section 7.2.
	Corrective Action	Replace DPT if defective.
	Component	Suction Pressure Transducer (SPT)
	Troubleshooting	Confirm accurate SPT pressure readings. See Manifold Gauge Set Section 7.2.
	Corrective Action	Replace SPT if defective.

Table 4-5 Alarm Indications and Descriptions

		Table 4–5 Alarm Indications and Descriptions
	Component	Monitor Unit
	Troubleshooting	Alarm is display only; the alarm may clear itself during operation.
	Corrective Action	If alarm remains active or is repetitive, replace compressor at next available opportunity.
AL18	Discharge Pressure	High
Cause:		over the maximum for 10 minutes within the last hour.
	Component	Restrictions in the refrigeration system.
	Troubleshooting	Ensure Liquid Line Service Valve is fully open.
	Corrective Action	Open Liquid Line Service Valve as needed.
	Component	Filter Drier
	Troubleshooting	Check the filter drier. If it is iced up or very cold, it indicates that the filter drier needs replacement.
	Corrective Action	Replace the filter drier if needed. See Filter Drier Service Section 7.14.
	Component	Condenser Fan
	Troubleshooting	Check Condenser Fan for proper operation.
	Corrective Action	Correct as required.
	Component	Discharge Pressure Transducer (DPT)
	Troubleshooting	Confirm accurate DPT pressure readings. See Manifold Gauge Set Section 7.2.
	Corrective Action	Replace DPT if defective.
	Component	Non-condensables in the refrigeration system.
	Troubleshooting	With the unit off, allow system to stabilize to ambient temperature.
		Check system pressure against Pressure Temperature Chart. See Table 7–5 , Table 7–6 .
	Corrective Action	Correct as required. See Refrigerant Charge Section 7.7.1.
	Component	Refrigerant
	Troubleshooting	Check refrigerant level.
	Corrective Action	Correct as required. See Refrigerant Charge Section 7.7.1.
AL19	Discharge Temperat	ure High
Cause:	Discharge temperatur	e exceeds 135°C (275°F) for 10 minutes within the last hour.
	Component	Restrictions in the refrigeration system.
	Troubleshooting	Ensure the Discharge Service Valve is fully open.
	Corrective Action	Open the Discharge Service Valve as needed.
	Troubleshooting	Check the unit for air flow restrictions.
	Corrective Action	Clean or remove any debris from coils.
	Component	Non-condensables in the refrigeration system.
	Troubleshooting	With the unit off allow system to stabilize to ambient temperature.
		Check system pressure against Pressure Temperature Chart. See Table 7–5 , Table 7–6 .
	Corrective Action	Correct as required. See Refrigerant Charge Section 7.7.1.
	Component	Additional Alarms such as AL16, AL24.
	-	

T-362

Table 4–5 Alarm Indications and Descriptions

	Troubleshooting	Check compressor operation.
	Corrective Action	If the alarm persists, it may indicate a failing compressor, replace the compressor. See Compressor Service Section 7.9.
AL20	Control Contactor F	use (F3)
Cause:	Control power fuse (F	3A or F3B) is open.
	Component	Check F3A fuse.
	Troubleshooting	If fuse is open, check PA, PB, CH coils for short to ground.
	Corrective Action	If short is found, replace the defective coil.
		Replace the fuse.
	Component	Check F3B fuse.
	Troubleshooting	If fuse is open, check ESV coil resistance at TP7 to TP9. If short to ground, or if resistance is less than 4 ohms, coil is defective.
		Check CF, ES, EF, HR coils for short to ground. If short is found, coil is defective
	Corrective Action	Replace the defective coil.
		Replace the fuse.
	Component	Check Voltage at QC1.
	Troubleshooting	If voltage is present, it indicates a defective microprocessor.
	Corrective Action	See Controller Service Section 7.27.
AL21	Control Circuit Fuse	See Controller Service Section 7.27. (F1 / F2)
AL21 Cause:	Control Circuit Fuse One of the 18 VAC co	See Controller Service Section 7.27.
	Control Circuit Fuse One of the 18 VAC co	See Controller Service Section 7.27. (F1 / F2) Introller fuses (F1 / F2) is open. See Cd08.
	Control Circuit Fuse One of the 18 VAC co Component Troubleshooting	See Controller Service Section 7.27. (F1 / F2) Introller fuses (F1 / F2) is open. See Cd08. System Sensors
	Control Circuit Fuse One of the 18 VAC co Component Troubleshooting Corrective Action	See Controller Service Section 7.27. (F1 / F2) Introller fuses (F1 / F2) is open. See Cd08. System Sensors Check system sensors for short to ground. Replace defective sensor(s).
	Control Circuit Fuse One of the 18 VAC co Component Troubleshooting Corrective Action Component	See Controller Service Section 7.27. F(F1 / F2) Introller fuses (F1 / F2) is open. See Cd08. System Sensors Check system sensors for short to ground. Replace defective sensor(s). Wiring
	Control Circuit Fuse One of the 18 VAC co Component Troubleshooting Corrective Action Component	See Controller Service Section 7.27. (F1 / F2) Introller fuses (F1 / F2) is open. See Cd08. System Sensors Check system sensors for short to ground. Replace defective sensor(s). Wiring Check wiring for short to ground.
	Control Circuit Fuse One of the 18 VAC co Component Troubleshooting Corrective Action Component Troubleshooting	See Controller Service Section 7.27. (F1 / F2) Introller fuses (F1 / F2) is open. See Cd08. System Sensors Check system sensors for short to ground. Replace defective sensor(s). Wiring Check wiring for short to ground. Repair as needed.
	Control Circuit Fuse One of the 18 VAC co Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Corrective Action Component	See Controller Service Section 7.27. (F1 / F2) Introller fuses (F1 / F2) is open. See Cd08. System Sensors Check system sensors for short to ground. Replace defective sensor(s). Wiring Check wiring for short to ground. Repair as needed.
	Control Circuit Fuse One of the 18 VAC co Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting	See Controller Service Section 7.27. (F1 / F2) Introller fuses (F1 / F2) is open. See Cd08. System Sensors Check system sensors for short to ground. Replace defective sensor(s). Wiring Check wiring for short to ground. Repair as needed. Controller
	Control Circuit Fuse One of the 18 VAC co Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting	See Controller Service Section 7.27. (F1 / F2) Introller fuses (F1 / F2) is open. See Cd08. System Sensors Check system sensors for short to ground. Replace defective sensor(s). Wiring Check wiring for short to ground. Repair as needed. Controller Controller may have an internal short.
	Control Circuit Fuse One of the 18 VAC co Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting	See Controller Service Section 7.27. (F1 / F2) Introller fuses (F1 / F2) is open. See Cd08. System Sensors Check system sensors for short to ground. Replace defective sensor(s). Wiring Check wiring for short to ground. Repair as needed. Controller Controller may have an internal short.
Cause:	Control Circuit Fuse One of the 18 VAC co Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action	See Controller Service Section 7.27. (F1 / F2) Introller fuses (F1 / F2) is open. See Cd08. System Sensors Check system sensors for short to ground. Replace defective sensor(s). Wiring Check wiring for short to ground. Repair as needed. Controller Controller may have an internal short.
Cause:	Control Circuit Fuse One of the 18 VAC co Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action	See Controller Service Section 7.27. (F1 / F2) Introller fuses (F1 / F2) is open. See Cd08. System Sensors Check system sensors for short to ground. Replace defective sensor(s). Wiring Check wiring for short to ground. Repair as needed. Controller Controller may have an internal short. Replace controller. See Controller Service Section 7.27.
Cause:	Control Circuit Fuse One of the 18 VAC co Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Component Component Component	See Controller Service Section 7.27. Introller fuses (F1 / F2) is open. See Cd08. System Sensors Check system sensors for short to ground. Replace defective sensor(s). Wiring Check wiring for short to ground. Repair as needed. Controller Controller may have an internal short. Replace controller. See Controller Service Section 7.27.

Table 4–5 Alarm Indications and Descriptions

AL23	Loss of Phase B	
Cause:	Controller fails to dete	ct current draw.
	Component	Incoming Power
	Troubleshooting	Check incoming power source.
	Corrective Action	Correct power source as required.
AL24	Compressor IP	
Cause:	Compressor internal p	protector (IP) is open.
	Component	Compressor
	Troubleshooting	Shut down unit disconnect power and check resistance of compressor windings at contactor T1-T2, T2-T3.
	Corrective Action	Monitor unit, if alarm remains active or is repetitive replace the compressor at the next available opportunity. See Compressor Service Section 7.9 .
AL25	Condenser IP	
Cause:	Condenser fan motor	internal protector (IP) is open.
	Component	Insufficient Air Flow
	Troubleshooting	Shut down unit and check condenser fan for obstructions.
	Corrective Action	Remove obstructions.
	Component	Condenser Fan Motor
	Troubleshooting	Shut down unit, disconnect power and check Condenser Fan Motor IP at plug connection pins 4 & 6.
	Corrective Action	Replace defective condenser fan motor. See Condenser Fan Motor Assembly Service Section 7.12.
AL26	All Sensors Failure:	Supply / Return Probes
Cause:	Sensors out of range.	
	Component	All sensors detected as out of range.
	Troubleshooting	Perform pre-trip P5.
	Corrective Action	If P5 passes, no further action is required.
	Corrective Action	If P5 fails, replace the defective sensor as determined by P5. See Temperature Sensor Service Section 7.29.
AL27	Analog to Digital Ac	curacy Failure
Cause:	Controller AD convert	er faulty.
	Component	Controller
	Troubleshooting	$\label{power_power_power} \mbox{Power cycle the unit. If the alarm persists, it indicates a defective microprocessor.}$
	Corrective Action	Replace defective microprocessor. See Controller Service Section 7.27.
AL28	Low Suction Pressu	re
Cause:	Suction pressure too l	ow for normal operation.
	Component	N/A
	Troubleshooting	Power cycle the unit.

4–35 T-362

Table 4–5 Alarm Indications and Descriptions

		Table 4–5 Alarm Indications and Descriptions
	Corrective Action	Resetting the unit may correct problem, monitor the unit.
	Component	Suction Pressure Transducer (SPT)
	Troubleshooting	Confirm accurate SPT pressure readings. See Manifold Gauge Set Section 7.2.
	Corrective Action	Replace SPT if defective.
	Component	Discharge Pressure Transducer (DPT)
	Troubleshooting	Confirm accurate DPT pressure readings. See Manifold Gauge Set Section 7.2.
	Corrective Action	Replace DPT if defective.
AL29	Loss of Atmospheric	c Control (XtendFRESH)
Cause:	is greater than 1% be	ne CO2 level is above its upper limit by 1% for 60 minutes. Or, when the O2 level low its setpoint for longer than 30 minutes after the unit has been in range. The when the levels return to within the normal range.
	Setup	Run test mode at code Cd43 for troubleshooting the below components. At the end of test mode, a sensor calibration will be attempted. Under loaded box conditions, the sensor values may post "No Cal" or "CAL FAIL". Results from original calibration will be retained. If test mode times out, then hold the code select key for 3 seconds to exit test mode.
	Troubleshooting	If components do not energize, check FX1 and FX2 for power (460 VAC). If fuse is open, check heater continuity (XHT1 to ground). Must be greater than 1 mega ohm. If less than 1, disconnect the heater at XHT1 and XHT2. Replace fuse. Unit will control on fresh air solenoids.
	Component	Solenoid Air Vents.
	Troubleshooting	Visually inspect to see if the Solenoid Valves are opening air vents. If vents open, troubleshoot the next component. If vents do not open, continue with troubleshooting below.
		Check FX4 fuse for power (~20 volts dc).
		If fuse is open, check wiring and or replace solenoid if part is available.
		If no part is available, open manual fresh air vent.
	Component	XtendFRESH Fan(s) / XtendFRESH Scrubber Motor
	Troubleshooting	Visually inspect to see if the XtendFRESH Fan(s) are running (air blowing on left, intake on right), check current draw of motor at the XST1 (~40 to 200 milliamps / contactor load side). Troubleshoot the non-operating component. If both are running, proceed to next component.
		Verify XS contactor is pulling in. If not, check FX6 fuse for power (24 VAC). If not, check power at controller KB4.
		Check FX3 fuse for power (\sim 20 vdc). If no power, replace fuse. If fuse opens a second time, take no further action. O ₂ level will be controlled with the opening and closing of the fresh air vents.
		If part is available, replace either fan or scrubber motor. Fan is replaceable from the front on a loaded unit; Scrubber motor is not. If no part is available or accessible, take no action and service at next PTI. O_2 level will be controlled with the opening and closing of the fresh air vents.
	Component	Heater
	Troubleshooting	Verify XH contactor is pulling in. If not, check FX6 for power (24 VAC). If open ohm contactors XHA1 and XSA1 to ground. Replace (12 Amp) contactor. If contactor is pulling, power unit off and check heater resistance from XH1 to XH2 (450 to 500 ohms). If heater is outside of the range, disconnect heater at XHT1 and XHT2 and replace at next PTI. Unit will control on fresh air solenoids.

Table 4–5 Alarm Indications and Descriptions

		Table 4–5 Alarm Indications and Descriptions
AL50	Air Vent Position Se	nsor (VPS)
Cause:	Vent Position Sensor	(VPS) Sensor out of range.
	Component	Vent Position Sensor (VPS)
	Troubleshooting	Make sure VPS is secure.
	Corrective Action	Manually tighten panel.
	Troubleshooting	If the alarm persists, replace the VPS or the assembly.
	Corrective Action	Replace VPS.
AL51	EEPROM Failure	
Cause:	Controller Memory Failure	
	Component	Controller
	Troubleshooting	Pressing the ENTER key when "CLEAr" is displayed will result in an attempt to clear the alarm.
	Corrective Action	If action is successful (all alarms are inactive), alarm 51 will be reset.
	Troubleshooting	Power cycle the unit. If the alarm persists, it indicates defective controller memory.
	Corrective Action	Replace defective controller. See Controller Service Section 7.27.
AL52	EEPROM Alarm List	Full
Cause:	Alarm list queue is ful	I
	Component	Active Alarms
	Troubleshooting	Repair any alarms in the queue that are active. Indicated by "AA".
	Corrective Action	Clear alarms. See Controller Alarms Section 4.4.
AL53	Battery Pack Failure	
Cause:	Battery voltage low	
	Component	Battery
	Troubleshooting	If this alarm occurs on start up, allow a unit fitted with rechargeable batteries to operate for up to 24 hours to charge rechargeable batteries sufficiently. Once fully charged, the alarm will deactivate.
	Corrective Action	To clear the alarm press ENTER and ALT simultaneously at the startup of code Cd19 (Battery Check). If alarm persists, replace the battery pack. See Section 7.27.4 Battery Replacement.
AL54	Primary Supply Sens	sor (STS)
Cause:	Invalid Supply Tempe	` ,
Cause:		Supply Temperature Sensor (STS)
Cause:	Component	
Cause:	Component Troubleshooting	Supply Temperature Sensor (STS)

4–37 T-362

Table 4–5 Alarm Indications and Descriptions

AL56	Primary Return Sens	sor (RTS)
Cause:	·	rature Sensor (RTS) reading.
Cause.	•	, , ,
	•	Return Temperature Sensor (RTS)
		Perform pre-trip P5.
	Corrective Action	If P5 passes, no further action is required.
		If P5 fails, replace the defective sensor as determined by P5. See Temperature Sensor Service Section 7.29 .
AL57	Ambient Sensor (AM	IBS)
Cause:	Invalid Ambient Temp	erature Sensor (AMBS) reading.
	Component	Ambient Temperature Sensor (AMBS)
	Troubleshooting	Test the AMBS. See Sensor Checkout Procedure Section 7.29.2.
	Corrective Action	Replace AMBS if defective. See Temperature Sensor Service Section 7.29.
AL58	Compressor High Pr	ressure Safety (HPS)
Cause:	High pressure safety	switch remains open for at least one minute.
	Component	High Pressure Switch (HPS)
	Troubleshooting	Test the HPS. See Checking High Pressure Switch, Section 7.10.1.
	Corrective Action	Replace HPS if defective. See Sensor Replacement, Section 7.29.
	Component	Refrigeration System
	Troubleshooting	Check unit for air flow restrictions.
	Corrective Action	Clean or remove any debris from coils.
AL59	Heater Termination	Thermostat (HTT)
Cause:	Heat Termination The	rmostat (HTT) is open.
	Component	Heat Termination Thermostat (HTT)
	Troubleshooting	Check for 24 volts at test point TP10. If no voltage at TP10 after unit has reached setpoint, HTT is open.
	Corrective Action	Replace HTT if defective. See Sensor Replacement Section 7.29.
AL60	Defrost Temperature	e Sensor (DTS)
Cause:	Failure of the Defrost	Temperature Sensor (DTS) to open.
	Component	Defrost Temperature Sensor (DTS)
	Troubleshooting	Test the DTS; see Sensor Checkout Procedure Section 7.29.2.
	Corrective Action	Replace the DTS if defective. See Sensor Replacement Section 7.29.
AL61	Heater Current Draw	Fault
Cause:	Improper current draw	during heat or defrost mode.
	Component	Heater(s)
	Troubleshooting	While in heat or defrost mode, check for proper current draw at heater contactors. See Electrical Data Section 3.3 .

Table 4–5 Alarm Indications and Descriptions

	Corrective Action	Replace heater(s) if defective. See Evaporator Heater Removal and Replacement Section 7.16.
	Component	Contactor
	Troubleshooting	Check voltage at heater contactor on the heater side.
	Corrective Action	If no voltage present, replace heater contactor if defective.
AL62	O2 Out of Range	
Cause:	indication that O2 leve the alarm is activated. reaching its O2 setpoi	larm and does not pose a risk to fresh produce. It is triggered when there is an I is rising after reaching its setpoint (+ 1%). If O2 level exceeds 4% above setpoint The alarm does not activate if the unit was pre-tripped or trip started between last and exceeding the plus 4%, or if power has been turned off for eight hours. The O2 drops below setpoint (+ 1%) or if a Pre-Trip or Trip Start is performed.
	Component	Scrubber Failure
	Troubleshooting	See the troubleshooting of the Scrubber Motor in the AL29 alarm.
	Component	XtendFRESH Solenoid Valves
	Troubleshooting	See the troubleshooting of the Solenoid Air Vent in the AL29 alarm.
	Component	Container Air Tightness
	Troubleshooting	Seal container where possible (access panels, rear doors, mounting hardware, etc).
AL63	Current Limit	
Cause:		
	-	Refrigeration System
		Check unit for air flow restrictions.
		Clean or remove any debris from coils.
	Troubleshooting	Check unit for proper operation.
		Office unit for proper operation.
	Corrective Action	Repair as needed.
	Corrective Action Component	Repair as needed. Power supply
	Corrective Action Component	Repair as needed. Power supply
	Corrective Action Component Troubleshooting	Repair as needed. Power supply Confirm supply voltage/frequency is within specification and balanced according
	Corrective Action Component Troubleshooting Corrective Action	Repair as needed. Power supply Confirm supply voltage/frequency is within specification and balanced according to Electrical Data Section 3.3.
	Corrective Action Component Troubleshooting Corrective Action Component	Repair as needed. Power supply Confirm supply voltage/frequency is within specification and balanced according to Electrical Data Section 3.3. Correct power supply.
	Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting	Repair as needed. Power supply Confirm supply voltage/frequency is within specification and balanced according to Electrical Data Section 3.3. Correct power supply. Current limit set too low
AL64	Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting	Repair as needed. Power supply Confirm supply voltage/frequency is within specification and balanced according to Electrical Data Section 3.3. Correct power supply. Current limit set too low Check current limit setting Code Cd32. The current limit can be raised (maximum of 23 amps) using Cd32.
AL64 Cause:	Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Corrective Action	Repair as needed. Power supply Confirm supply voltage/frequency is within specification and balanced according to Electrical Data Section 3.3. Correct power supply. Current limit set too low Check current limit setting Code Cd32. The current limit can be raised (maximum of 23 amps) using Cd32.
	Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Discharge Temperat Compressor Discharge	Repair as needed. Power supply Confirm supply voltage/frequency is within specification and balanced according to Electrical Data Section 3.3. Correct power supply. Current limit set too low Check current limit setting Code Cd32. The current limit can be raised (maximum of 23 amps) using Cd32.
	Corrective Action Component Troubleshooting Corrective Action Component Troubleshooting Corrective Action Discharge Temperat Component Component	Repair as needed. Power supply Confirm supply voltage/frequency is within specification and balanced according to Electrical Data Section 3.3. Correct power supply. Current limit set too low Check current limit setting Code Cd32. The current limit can be raised (maximum of 23 amps) using Cd32. Fure Sensor (CPDS) The Temperature Sensor (CPDS) out of range.

4–39 T-362

Table 4–5 Alarm Indications and Descriptions

AL65	Discharge Pressure	, ,
Cause:		e Pressure Transducer (DPT) is out of range.
	Component	Compressor Discharge Pressure Transducer (DPT)
	Troubleshooting	Confirm accurate DPT pressure readings. See Manifold Gauge Set Section 7.2.
	Corrective Action	Replace DPT if defective.
AL66	Suction Pressure Tr	ansducer (SPT), Evaporator Pressure Transducer (EPT)
Cause:	Suction Pressure Tran	nsducer (SPT) out of range.
	Component	Suction Pressure Transducer (SPT)
	Troubleshooting	Confirm accurate EPT and SPT pressure readings. See Manifold Gauge Set Section 7.2.
		Performing a pre-trip 5-9 test will also check the transducers.
	Corrective Action	Replace EPT/SPT if defective.
	Troubleshooting	Monitor
	Corrective Action	If the alarm persists, it may indicate a failing compressor. See Compressor Service Section 7.9.
AL67	Humidity Sensor	
Cause:	Humidity Sensor (HS)	reading out of range.
	Component	Humidity Sensor (HS)
	Troubleshooting	Make sure the HS is properly connected in the socket.
		Make sure the HS wires have not been damaged.
		See Section 7.20 to test operation of Humidity Sensor.
	Corrective Action	Monitor, replace HS if alarm persists.
AL69	Evaporator Temp Se	ensor (ETS1)
Cause:	Evaporator Temperatu	ure Sensor (ETS1) out of range.
	Component	Evaporator Temperature Sensor (ETS1)
	Troubleshooting	Test the ETS1. See Sensor Checkout Procedure Section 7.29.2.
	Corrective Action	Replace Evaporator Temperature Sensor (ETS1) if defective.
AL70	Secondary Supply S	ensor (SRS)
Cause:		nsor (SRS) is out of range.
	Component	Secondary Supply Sensor (SRS)
	-	Perform pre-trip P5.
		If P5 passes, no further action is required.
		If P5 fails, replace the defective sensor as determined by P5. See Temperature Sensor Service Section 7.29.
	<u> </u>	
AL71	Secondary Return S	ensor (RRS)
Cause:		nsor (RRS) is out of range.
	•	Secondary Return Sensor (RRS)
l	= = ::: = :: : : : : : : : : : : : : :	,/

Table 4-5 Alarm Indications and Descriptions

		Table 4–5 Alarm Indications and Descriptions
	Troubleshooting	Perform pre-trip P5.
	Corrective Action	If P5 passes, no further action is required.
	Corrective Action	If P5 fails, replace the defective sensor as determined by P5. See Temperature Sensor Service Section 7.29 .
AL72	Control Temp Out of	f Range
Cause:	After the unit goes in-	range for 30 minutes then out of range for a continuous 120 minutes.
	Component	Refrigeration System
	Troubleshooting	Ensure unit is operating correctly.
	Corrective Action	Power cycle unit.
		Control Temperature is in range.
		Any pre-trip mode resets the timers.
AL96	Scrubber Rotational	Feature (option)
Cause:	Feedback from the So	crubber Motor to the controller is not sensed when the motor is turning.
	Component	Scrubber Fuse
	Troubleshooting	Check to see if Scrubber Fuse is blown. Replace Fuse if necessary.
	Component	Scrubber Motor
	Troubleshooting	Run Test Mode and verify scrubber bed is turning. If back panel cannot be removed to check, verify the scrubber amperage consumption, read at XS contactor wire XSL1. If between 40 and 200mA, motor is rotating properly. If no current detected, check and replace FX3. If current spiking to 350mA for 2 seconds then dropping to 90mA, the scrubber motor is located. If scrubber motor is locked, further inspection of the scrubber bed is required. Unit will control CO ₂ with the fresh air solenoid when this alarm occurs if scrubber inaccessible.
		If Scrubber Motor not operating, follow the troubleshooting flowchart in XtendFresh manual and take appropriate action.
	Component	Ground Interface Module (GIM)
	Troubleshooting	Once it has been verified that the scrubber motor is rotating, check the wiring connections to the GIM module. If all wires secured properly, re-place the GIM module if one is available. If not, the unit will control CO ₂ using the fresh air solenoids.
		NOTICE red for four probes without a DataCORDER, the DataCORDER alarms AL70 d as Controller alarms AL70 and AL71. See Table 4–10.
	,	
Entr StPt	Enter Set point (Pres	ss Arrow & Enter)
Cause:	The controller is prom	pting the operator to enter a setpoint.
LO	Low Main Voltage (F	unction Codes Cd27-38 disabled and NO alarm stored.)
Cause:	<u> </u>	alternately displayed with the setpoint whenever the supply voltage is less than

4–41 T-362

4.5 Pre-Trip Diagnostics

Pre-Trip Diagnostics is an independent controller function that suspends normal refrigeration controller activities and provides preprogrammed test routines. The test routine can be run in Auto Mode, which automatically performs a pre programmed sequence of tests, or Manual Mode, which allows the operator to select and run any of the individual tests.



Pre-trip inspection should not be performed with critical temperature cargoes in the container.



When the pre-trip key is pressed economy, dehumidification and Bulb Mode will be deactivated. At the completion of the pre-trip test, economy, dehumidification and Bulb Mode must be reactivated.

A pre-trip test may be initiated by use of the keypad or via communication, but when initiated by communication the controller will execute the entire battery of tests (auto mode).

At the end of a pre-trip test, the message "P," "rSLts" (pretest results) will be displayed. Pressing ENTER will allow the user to see the results for each of the sub-tests. The results will be displayed as "PASS" or "FAIL" for each test run to completion.

A detailed description of the pre-trip tests and test codes is described in **Table 4–6**. Detailed operating instructions are described in **Section 5.8**.

4.5.1 Controller Pre-Trip Test Codes

The pre-trip selection menu provides the user the option of selecting one of two automatic tests (short sequence or long sequence). These tests will automatically perform a series of individual pre-trip tests. The user may also scroll down to select any of the individual tests.

The short pre-trip test sequence will appear as either "AUTO" or "AUTO1" in the display. This runs tests P0 through P6, which includes most functions, sensors and system components.

The long pre-trip test sequence is selected by either "AUTO2" or "AUTO3" in the display. "AUTO2" runs tests P0 through P10 and "AUTO3" runs tests P0 through P8. The long test sequence includes all of the short sequence tests and also tests for the high pressure switch, heater performance and cooling performance.

Table 4-6 Controller Pre-Trip Test Codes

Code	Description	
P0-0	Pre-Trip Initiated: Configuration Display, Indicator Lamps, LEDs, and Displays	
	Container identifier code, Cd18 Software Revision Number, Cd20 Container Unit Model Number, & configuration database identifier CFMMYYDD are displayed in sequence.	
	Next the unit will indicate the presence or non-presence of an RMU according to whether any RMU inquiry messages have been received since the unit was booted.	
	Units equipped with Autoslide Enabled (Cnf44) will cause the vent to seek to its closed position, followed by two sequences of opening to 100% and returning to the closed position. No other autoslide mode of operation will be available until the two cycles of opening and closing have completed.	
	Since the system cannot recognize lights and display failures, there are no test codes or results associated with this phase of pre-trip. To know if the test passes the operator must observe that the LCD display elements and the indicator lights behave as described below.	
	Current Draw: For P1 tests, the heater is turned on, then off. Current draw must fall within specified to other system components will change state during this test.	
P1-0	Heaters Turned On	
	Heater starts in the off condition, current draw is measured, and then the heater is turned on. After 15 seconds, the current draw is measured again. The change in current draw is then recorded.	
	Test passes if the change in current draw test is in the range specified.	

	Table 4–6 Controller Pre-Trip Test Codes (Continued)
P1-1	Heaters Turned Off
	Heater is then turned off. After 10 seconds, the current draw is measured. The change in current draw is then recorded.
	Test passes if change in current draw test is in the range specified.
specified	ser Fan Current Draw: For P2 tests, the condenser fan is turned on, then off. Current draw must fall within range. No other system components will change state during this test. If the Water Pressure Switch is test will be skipped.
P2-0	Condenser Fan On
	Condenser fan starts in the off condition and current draw is measured. Condenser fan is then turned on and after 15 seconds the current draw is measured again. The change in current draw is recorded.
	Test passes if change in current draw test is in the specified range.
P2-1	Condenser Fan Off
	Condenser fan is on and current draw is measured. Condenser fan is then turned off and after 10 seconds the current draw is measured. The change in current draw is recorded.
	Test passes if change in current draw test is in the specified range.
evaporat	eed Evaporator Fan Current Draw: For P3 tests, the system must be equipped with a low speed or fan, as determined by CnF02, the Evaporator Fan Speed Select configuration variable. Low speed or fan is turned on, then off. Current draw must fall within specified range. No other system components ge state during this test.
then the	s configured for single evaporator fan operation and either AL11 or AL12 is active at the start of either test, test will fail immediately. If AL11 or AL12 become active during the test, then the test will fail upon on of the test.
P3-0	Low Speed Evaporator Fan Motors On
	Low speed evaporator fans start in the off condition and current draw is measured. Low speed evaporator fans are then turned on and after 60 seconds the current draw is measured again. The change in current draw is recorded.
	Test passes if change in current draw test is in the specified range.
P3-1	Low Speed Evaporator Fan Motors Off
	Low speed evaporators are on and current draw is measured. Low speed evaporator fans are then turned off and after 10 seconds the current draw is measured again. The change in current draw is recorded.
	Test passes if change in current draw test is in the specified range.
Current	eed Evaporator Fans Current Draw: For P4 tests, high speed evaporator fans are turned on, then off. draw must fall within specified range and measured current changes must exceed specified ratios. No stem components will change state during this test.
then the	s configured for single evaporator fan operation and either AL11 or AL12 is active at the start of either test, test will fail immediately. If AL11 or AL12 become active during the test, then the test will fail upon on of the test.
P4-0	High Speed Evaporator Fan Motors On
	High speed evaporator fans start in the off condition and current draw is measured. High speed evaporator fans are then turned on and after 60 seconds the current draw is measured again. The change in current draw is recorded.
	Test passes if change in current draw in the specified range AND measured current changes exceed specified ratios.
	If the three phase motors are configured IN, the change ratio test is skipped.

4–43 T-362

P4-1	High Speed Evaporator Fan Motors Off
	High speed evaporator fans are on and current draw is measured. High speed evaporator fans are then turned off and after 10 seconds the current draw is measured again. The change in current draw is then recorded.
	Test passes if change in current draw test is in the specified range.
Air Stre Sensors	am Temperature Sensor Tests: The P5 tests are to check the validity of the Air Stream Temperature.
P5-0	Supply / Return Probe Test
	The High Speed Evaporator Fan is turned on and run for eight minutes, with all other outputs de- energized. A temperature comparison is made between the return and supply probes.
	Test passes if temperature comparison falls within the specified range.
	NOTE
	If this test fails, "P5-0" and "FAIL" will be displayed. If both Probe tests (this test and the PRIMARY/ SECONDARY) pass, display will read "P5" "PASS."
P5-1	Supply Probe Test
	This test is for units equipped with secondary supply probe only.
	The temperature difference between primary supply probe and secondary supply probe is compared.
	Test passes if temperature comparison falls within the specified range.
	NOTE
	If this test fails, "P5-1" and "FAIL" will be displayed. If both Probe tests (this and the SUPPLY/RETURN TEST) pass, because of the multiple tests, the display will read "P5" "PASS."
P5-2	Return Probe Test
	This test is for units equipped with secondary return probe only.
	The temperature difference between return temperature sensor (RTS) and return temperature sensor (RRS) probe is compared.
	Test passes if temperature comparison falls within the specified range.
	NOTES
	1. If this test fails, "P5-2" and "FAIL" will be displayed. If both Probe tests (this test and the SUPPLY RETURN) pass, because of the multiple tests, the display will read "P 5," "PASS."
	2. The results of pre-trip tests 5-0, 5-1 and 5-2 will be used to activate or clear control probe alarms
P5-3	Evaporator Fan Direction Test
	With evaporator fan running on high speed, measure the temperature difference between the primary supply and primary return probes. Turn the heaters on for 60 seconds then measure the temperature difference between the primary supply and primary return probes for up to 120 additional seconds.
	This is a Pass/Fail test. The test passes if differential of STS is 0.25°C higher than RTS.
	Test P5-0 must pass before this test is run.
P5-7	Primary vs. Secondary Evaporator Temperature Sensor Test
	This is a Pass / Fail test of the primary Evaporator Temperature Sensor (ETS1) and secondary Evaporator Temperature Sensor (ETS2).
	Test passes if secondary Evaporator Temperature Sensor (ETS2) is within +/- 0.5°C of the primary Evaporator Temperature Sensor (ETS1).
P5-8	Future Expansion
	This is no longer active and will be displayed as "" at this time.

P5-9	Primary vs. Secondary Evaporator Pressure Transducer Test
	This is a Pass / Fail test of the primary Evaporator Pressure Transducer and secondary Evaporator Pressure Transducer.
	Test passes if secondary Evaporator pressure is within +/- 1.5 psi of the primary Evaporator pressure.
P5-10	Humidity Sensor Controller Configuration Verification Test
	This is a Pass / Fail / Skip test of the humidity sensor configuration.
	Test passes if the controller configuration has humidity sensor in.
	Test fails if the controller configuration has humidity sensor out and Vout is greater than 0.20 Volts for the humidity sensor.
	Test is skipped if the controller configuration has the humidity sensor out and Vout is less than 0.20 Volts.
	Test P5-9 must pass before this test is run.
P5-11	Humidity Sensor Installation Verification Test
	This is a Pass / Fail test of humidity sensor installation (sensor is present).
	Test passes if Vout is greater than 0.20 Volts for the humidity sensor.
	Test fails if Vout is less than 0.20 Volts for the humidity sensor.
	Test P5-10 must pass before this test is run.
P5-12	Humidity Sensor Range Check Test
	This is a Pass / Fail test of the Humidity Sensor Range.
	Test passes if Vout for the humidity sensor is between 0.33 Volts and 4 Volts.
	Test fails if Vout is outside of this range.
	Test P5-11 must pass before this test is run.
_	rant Probes, Compressor and Refrigerant Valves: The P6 tests are for Pass / Fail testing performed for pressor, EEV, DUV, LIV (if equipped), ESV, and the refrigerant pressure and temperature sensors.
P6-0	Discharge Thermistor Test
	If Alarm 64 is active the test fails. Otherwise, the test passes. Alarm 64 monitors the range of the Discharge Temperature Sensor (CPDS).
P6-1	Evaporator Temperature Sensor (Suction) Test
	If the Evaporator Temperature Sensor (ETS1/ETS2) is invalid, the test fails. Otherwise the test passes.
P6-2	Discharge Pressure Transducer Test
	If Alarm 65 is active any time during the first 45 second period, the test fails. Otherwise, the test passes. Alarm 65 monitors the range of the Discharge Pressure Transducer (DPT).
P6-3	Suction Pressure Transducer Test
	If Alarm 66 is active the test fails. Otherwise the test passes. Alarm 66 monitors the range of the Suction Pressure Transducer (SPT).
P6-4	Compressor Current Draw Test
	Compressor current is tested before and 10 seconds after start up. If current does not increase, the test fails. P6-7 is run at the end of P6-4. If this test fails, P6-6 is skipped.
P6-5	Compressor Leak Test
	Pre-trip P6-5 ensures that the compressor holds pressure. After compressor pump up and pump down, the compressor is turned off for 62 seconds. When suction side pressure holds (less than 8 psi rise) for 10 seconds, P6-5 passes, otherwise the Compressor Leak Test fails.
	See the July 2017 issue of TechLine for a procedure to assist the technician in troubleshooting a P6-5 occurrence.

4–45 T-362

Tests P6-6 through P6-10 are conducted by changing status of each valve and comparing suction pressure
change and/or compressor current change with predetermined values. Tests will cause compressor and
condenser fans to cycle on and off as needed to generate the pressure required for individual pre-trip sub tests.
The compressor will start in order to build discharge pressure, followed by compressor pump down sequence. At
the conclusion of compressor pump down sequence, the compressor will shut down and the valve test will start.

P6-6	Economizer Valve Test	
	Passes if suction pressure increases a minimum of 4 psia when the valve opens for 15 seconds.	
P6-7	Digital Unloader Valve Test	
	Passes if pressure and current changes are within 3 seconds of DUV switch signal and either the pressure change or the current draw change is above 5 psi or above 1.5A, respectively.	
P6-9	Liquid Injection Valve Test	
	(If equipped) Test passes if change of suction pressure is greater than 4 psia when the valve opens for 10 seconds. Otherwise, it fails.	
P6-10	Electronic Expansion Valve Test	
	The test records the suction pressure during the open valve position and passes if the suction pressure increase is above 3 psi when the valve opens for 10 seconds.	

NOTE

P7-0 & P8 are included with "Auto 2 & Auto 3" only. P9-0 through P10 are included with "Auto2" only.

High Pressure Tests: For the P7 tests, the unit is run at full capacity without condenser fan running to make sure that the HPS opens and closes properly.

P7-0 High Pressure Switch (HPS) Opening Test

Test is skipped if sensed ambient temperature is less than 7.2°C (45°F), return air temperature is less than -17.8°C (0°F), or the water pressure switch is open.

With the unit running, the condenser fan is turned off and a 900 second (15 minute) timer is started. The right display shows Discharge Pressure if the sensor is configured and valid, else Discharge Temperature. The unit needs to disable Discharge Pressure limit and enable Current Limit checks.

The test fails immediately if:

- · Ambient Temperature Sensor invalid
- Composite Return Temperature Sensor invalid
- · HPS is open

The test fails if:

- HPS fails to open before 900 seconds total test time.
- Evaporator or Compressor IP Alarm.
- Calculated Dome Temperature exceeds 137.78°C (280°F).
- Discharge pressure exceeds 370 psig.
- Compressor Current exceeds limits

The test passes if HPS opens within the 15 minute time limit.

P7-1 High Pressure Switch (HPS) Closing Test

If return temperature greater than -2.4°C, set setpoint to -5.0°C, else set setpoint to -30°C. Restart unit according to normal startup logic. Run unit normally for 120 seconds.

The test passes if the high pressure switch closes within 75 seconds after end of Test 7-0, else the test fails.

Test P7-0 must pass for this test to execute.

P8-0	Perishable Mode Test
P8-0	
	If the control temperature is below 15.6°C, the setpoint is changed to 15.6°C, and a 180 Minute timer is started. The control will then be placed in the equivalent of normal heating. If the control temperature is above 15.6°C. at the start of the test, then the test proceeds immediately to test 8-1. While in test 8-0 the right display will show the value of the control temperature.
	The test fails if the 180 Minute timer expires before the control temperature reaches setpoint - 0.3°C. I the test fails, it will not auto-repeat. There is no pass display for this test. Once the control temperature reaches setpoint, the test proceeds to test 8-1.
P8-1	Perishable Mode Pull Down Test / CO2 Sensor Calibration
	Control temperature must be at least 15.6°C (60°F).
	The setpoint is changed to 0°C (32°F), and a 180-minute timer is started. The left display will read "P8 1," the right display will show the supply air temperature. The unit will then start to pull down the temperature to the 0°C setpoint.
	The test passes if the container temperature reaches setpoint before the 180-minute timer expires.
	On units where the CO_2 Sensor Status indicates that a CO_2 sensor is present, calibration of the CO_2 sensor will be attempted during P8-1. Once P8-1 begins, calibration will be attempted when the supply temperature goes below 5°C. If the CO_2 sensor voltage reads within the 0.95 <>1.15 Vdc range before the end of P8-1, the sensor will be calibrated by holding the CO_2 zero line low for 4 seconds. Once calibration is performed, the sensor voltage will be verified to make sure it is in the 0.95 to 1.05 Vdc range If the voltage is not within this range, CO_2 sensor calibration fails.
P8-2	Perishable Mode Maintain Temperature Test
	Test P8-1 must pass for P8-2 to execute.
	A fifteen minute timer is started, and the system will attempt to minimize control temperature error (suppl temperature minus setpoint) until the timer expires. The control temperature will be sampled each minute starting at the beginning of P8-2.
	During P8-2, the left display will read "P8-2," and the right display will show the supply air temperature
	When the test is completed, the average control temperature error will be compared to the pass/fail criteria.
	Test passes if the average temperature error is within +/- 1.0°C.
	Test fails if the average temperature error is greater than +/- 1.0°C, or if the DataCORDER supply temperature probe is invalid. If the test fails, the control probe temperature will be recorded as -50.0°C
contacts function	se and Open Test: For the P9 tests, the DTT in this control is not a physical device, with actual metallic, it is a software function that acts similar to a thermostat. Using various temperature inputs, the DTT determines whether a thermostat mounted on the Evaporator Coil would have OPEN or CLOSED. Primarily, the DTT function operates based on the temperature reading from the Defrost Termination
P9-0	DTT Closed and Open Test
	During P9-0 the defrost temperature sensor (DTS) reading will be displayed on the left display. The right display will show the supply air temperature.
	The unit will run FULL COOL for 30 minutes maximum until the DTT is considered closed. This step may not have to be executed. Once the DTT is considered closed, the unit simulates defrost by running the heaters for up to two hours, or until the DTT is considered open.
	Test fails if The DTT is not considered closed after the 30 minutes of full cooling. Or, if the HTT opens when DTT is considered closed or if return air temperature rises above 48°C (120°F).
	Test passes if the DTT is considered open within the 2 hour heat cycle time limit.

4–47 T-362

Table 4–6 Controller Pre-Trip Test Codes (Continued)

Frozen Mode Tests:		
P10-0	Frozen Mode Heat Test	
	If the container temperature is below 7.2°C, the setpoint is changed to 7.2°C, and a 180 Minute timer is started. The control will then be placed in the equivalent of normal heating. If the container temperature is above 7.2°C. at the start of the test, then the test proceeds immediately to test 10-1. During this test, the control temperature will be shown on the right display.	
	The test fails if the 180 Minute timer expires before the control temperature reaches setpoint - 0.3°C. If the test fails, it will not auto-repeat. There is no pass display for this test. Once the control temperature reaches setpoint, the test proceeds to test 10-1.	
P10-1	Frozen Mode Pulldown Test	
	Control temperature must be at least 7.2°C (45°F)	
	The setpoint is changed to -17.8°C. The system will then attempt to pull down the control temperature to setpoint using normal frozen mode cooling. During this test, the control temperature will be shown on the right display.	
	The test passes if the control temperature reaches setpoint minus 0.3°C before the 180 minute timer expires. Otherwise, the test fails. Upon failure and when initiated by an automatic pre-trip sequence, P10-1 will auto-repeat once by starting P10-0 over again.	
P10-2	Frozen Mode Maintain Temperature Test	
	Test P10-1 must pass for this test to execute.	
	Same as for test 8-2 except control temperature is the return probe temperature.	
	The average error must be +/-1.6°C. If the DataCORDER supply temperature probe is invalid, the test fails and the control probe temperature will be recorded as -50°C. Upon failure and when initiated by an automatic pre-trip sequence, P10-2 will auto-repeat by starting P10-0 over again.	

4.6 DataCORDER

4.6.1 DataCORDER Description

Carrier Transicold "DataCORDER" software is integrated into the controller and serves to eliminate the temperature recorder and paper chart. DataCORDER functions may be accessed by keypad selections and viewed on the display module. The unit is also fitted with interrogation connections which may be used with the Carrier Transicold DataReader to download data. A personal computer with Carrier Transicold DataLINE software installed may also be used to download data and configure settings.

The DataCORDER consists of:

- · Configuration Software
- Operational Software
- Data Storage Memory
- Real Time Clock (with internal battery backup)
- Six Thermistor Inputs
- Interrogation Connections
- Power Supply (battery pack)

The DataCORDER performs the following functions:

- a. Logs data at 15, 30, 60 or 120 minute intervals and stores two years of data (based on one hour interval).
- b. Records and displays alarms on the display module.
- c. Records results of pre-trip testing.
- d. Records DataCORDER and temperature control software generated data and events as follows:
 - Container ID Change
 - Software Upgrades
 - · Alarm Activity

- Battery Low (battery pack)
- Data Retrieval
- Defrost Start and End
- · Dehumidification Start and End
- Power Loss (with and without battery pack)
- Power Up (with and without battery pack)
- Remote Probe Temperatures in the Container (USDA Cold treatment and Cargo probe recording)
- Return Air Temperature
- Setpoint Change
- Supply Air Temperature
- · Real Time Clock Battery (Internal) Replacement
- · Real Time Clock Modification
- · Trip Start
- ISO Trip Header (When entered via Interrogation program)
- · Economy Mode Start and End
- "Auto 1 / Auto 2 / Auto 3" Pre-Trip Start and End
- · Bulb Mode Start
- · Bulb Mode Changes
- Bulb Mode End
- USDA Trip Comment
- · Humidification Start and End
- USDA Probe Calibration
- · Fresh Air Vent Position

4.6.2 DataCORDER Configuration Software

The configuration software controls the recording and alarm functions of the DataCORDER. Reprogramming to the factory-installed configuration is achieved via a configuration card. Changes to the unit DataCORDER configuration may be made using the DataLINE interrogation software.

A list of the configuration variables is provided in **Table 4–7**. Descriptions of DataCORDER operation for each variable setting are provided in the following paragraphs.

Table 4–7 DataCORDER Configuration Variables

Config	Title	Default	Option
dCF01	(Future Use)		
dCF02	Sensor Configuration	2	2, 5, 6, 9, 54, 64, 94
dCF03	Logging Interval (Minutes)	60	15, 30, 60, 120
dCF04	Thermistor Format	Short	Long
dCF05	Thermistor Sampling Type	Α	A, b, C
dCF06	Controlled Atmosphere / Humidity Sampling Type	Α	A, b
dCF07	Alarm Configuration USDA Sensor 1	Α	Auto, On, Off
dCF08	Alarm Configuration USDA Sensor 2	Α	Auto, On, Off
dCF09	Alarm Configuration USDA Sensor 3	Α	Auto, On, Off
dCF10	Alarm Configuration Cargo Sensor	Α	Auto, On, Off

Sensor Configuration (dCF02)

Two modes of operation may be configured: Standard Mode and Generic Mode.

Standard Mode

4–49 T-362

In the Standard Mode, the user may configure the DataCORDER to record data using one of several standard configurations. The standard sensor configurations are described in **Table 4–8**.

The inputs of the six thermistors (Supply, Return, USDA #1, #2, #3 and Cargo probe) and the Humidity Sensor input will be generated by the DataCORDER.

NOTE

The DataCORDER software uses the Supply Recorder Sensor (SRS) and Return Recorder Sensor (RRS). While the temperature control software uses the Supply Temperature Sensor (STS) and Return Temperature Sensor (RTS).

Table 4-8 Sensor Configuration

Standard Config	Description
2 sensors (dCF02=2)	2 thermistor inputs (supply & return)
5 sensors (dCF02=5)	2 thermistor inputs (supply & return)
	3 USDA thermistor inputs
6 sensors (dCF02=6)	2 thermistor inputs (supply & return)
	3 USDA thermistor inputs
	1 humidity input
9 sensors (dCF02=9)	Not Applicable
6 sensors (dCF02=54)	2 thermistor inputs (supply & return)
	3 USDA thermistor inputs
	1 cargo probe (thermistor input)
7 sensors (dCF02=64)	2 thermistor inputs (supply & return)
	3 USDA thermistor inputs
	1 humidity input
	1 cargo probe (thermistor input)

Generic Mode

The Generic Recording Mode allows user selection of the network data points to be recorded. The user may select up to a total of eight data points for recording. Changing the configuration to generic and selecting which data points to record may be done using the Carrier Transicold Data Retrieval Program. A list of the data points available for recording follows.

- 1. Control mode
- 2. Control temperature
- 3. Frequency
- 4. Humidity
- 5. Phase A, B, C current
- 6. Main voltage
- 7. Electronic Expansion Valve (EEV) percentage
- 8. Discrete outputs (Bit mapped require special handling if used)
- 9. Discrete inputs (Bit mapped require special handling if used)
- 10. Ambient Temperature Sensor (AMBS)
- 11. Evaporator Temperature Sensor (ETS)
- 12. Compressor Discharge Sensor (CPDS)
- 13. Return Temperature Sensor (RTS)
- 14. Supply Temperature Sensor (STS)
- 15. Defrost Temperature Sensor (DTS)

- 16. Discharge Pressure Transducer (DPT)
- 17. Suction Pressure Transducer (SPT)
- 18. Vent Position Sensor (VPS)

Logging Interval (dCF03)

The user may select four different time intervals between data recordings. Data is logged at exact intervals in accordance with the real time clock. The clock is factory set at Greenwich Mean Time (GMT).

Thermistor Format (dCF04)

The user may configure the format in which the thermistor readings are recorded. The short resolution is a 1 byte format and the long resolution is a 2 byte format. The short requires less memory and records temperature with variable resolutions depending on temperature range. The long records temperature in 0.01°C (0.02°F) steps for the entire range.

Sampling Type (dCF05 & dCF06)

Three types of data sampling are available: average, snapshot and USDA. When configured to average, the average of readings taken every minute over the recording period is recorded. When configured to snapshot, the sensor reading at the log interval time is recorded. When USDA is configured, supply and return temperature readings are averaged and the three USDA probe readings are snapshot.

Alarm Configuration (dCF07 - dCF10)

USDA and cargo probe alarms may be configured to OFF, ON or AUTO.

If a probe alarm is configured to OFF, the alarm for this probe is always disabled.

If a probe alarm is configured to ON, the associated alarm is always enabled.

If the probes are configured to AUTO, they act as a group. This function is designed to assist users who keep the DataCORDER configured for USDA recording, but do not install the probes for every trip. If all the probes are disconnected, no alarms are activated. As soon as one of the probes is installed, all of the alarms are enabled and the remaining probes that are not installed will give active alarm indications.

4.6.3 DataCORDER Operational Software

The DataCORDER operational software reads and interprets inputs for use by the configuration software. The inputs are labeled function codes. Controller functions (see **Table 4–9**) which the operator may access to examine the current input data or stored data.

To access DataCORDER function codes, do the following:

- 1. Press the ALT. MODE and CODE SELECT keys.
- 2. Press an Arrow key until the left window displays the desired code number. The right window will display the value of this item for five seconds before returning to the normal display mode.
- 3. If a longer display time is desired, press the ENTER key to extend the display time to 30 seconds.
- 4. If a function is not applicable for the unit, dashes "----" are shown on the display for that code.

4–51 T-362

Table 4–9 DataCORDER Function Code Assignments

Code	Description
dC1	Recorder Supply Temperature
	Current reading of the Supply Recorder Sensor (SRS).
dC2	Recorder Return Temperature
	Current reading of the Return Recorder Sensor (RRS).
dC3-5	USDA 1,2,3 Temperatures
	Current readings of the three USDA probes.
dC6-13	Network Data Points 1-8
	Current values of the network data points (as configured). Data point 1 (Code 6) is generally the humidity sensor and its value is obtained from the controller once every minute.
dC14	Cargo Probe 4 Temperature
	Current reading of the cargo probe #4.
dC15-19	Future Expansion
	These codes are for future expansion, and are not in use at this time.
dC20-24	Temperature Sensors 1-5 Calibration
	Current calibration offset values for each of the five probes: supply, return, USDA #1, #2, and #3. These values are entered via the interrogation program.
dC25-27	Future Expansion
	These codes are for future expansion, and not in use at this time.
dC28	Minimum Days Left
	An approximation of the number of logging days remaining until the DataCORDER starts to overwrite the existing data.
dC29	Days Stored
	Number of days of data that are currently stored in the DataCORDER.
dC30	Date of Last Trip Start
	The date when a Trip Start was initiated by the user. In addition, if the system goes without power for seven continuous days or longer, a Trip Start will automatically be generated on the next AC power up. Press and hold "ENTER" key for five seconds to initiate a "Trip Start."
dC31	Battery Test Results
	Shows the current status of the optional battery pack.
	PASS: Battery pack is fully charged. FAIL: Battery pack voltage is low.
dC32	Time: Hour, Minute
	Current time on the real time clock (RTC) in the DataCORDER.
dC33	Date: Month, Day
	Current date (month and day) on the RTC in the DataCORDER.
dC34	Date: Year
	Current year on the RTC in the DataCORDER.
dC35	Cargo Probe 4 Calibration
	Current calibration value for the Cargo Probe. This value is an input via the interrogation program.

4.6.4 DataCORDER Power Up

The DataCORDER may be powered up in any one of four ways:

- 1. Normal AC power: The DataCORDER is powered up when the unit is turned on via the Stop-Start switch.
- 2. Controller DC battery pack power: If a battery pack is installed, the DataCORDER will power up for communication when an interrogation cable is plugged into an interrogation receptacle.
- 3. External DC battery pack power: A 12 volt battery pack may also be plugged into the back of the interrogation cable, which is then plugged into an interrogation port. No controller battery pack is required with this method.
- 4. Real Time Clock demand: If the DataCORDER is equipped with a charged battery pack and AC power is not present, the DataCORDER will power up when the real time clock indicates that a data recording should take place. When the DataCORDER is finished recording, it will power down.

During DataCORDER power-up, while using battery-pack power, the controller will perform a hardware voltage check on the battery. If the hardware check passes, the controller will energize and perform a software battery voltage check before DataCORDER logging. If either test fails, the real time clock battery power-up will be disabled until the next AC power cycle. Further DataCORDER temperature logging will be prohibited until that time.

An alarm will be generated when the battery voltage transitions from good to bad indicating that the battery pack needs recharging. If the alarm condition persists for more than 24 hours on continuous AC power, it indicates that the battery pack needs replacement.

4.6.5 DataCORDER Alarms

The alarm display is an independent DataCORDER function. If an operating parameter is outside of the expected range or a component does not return the correct values to the DataCORDER, an alarm is generated. The DataCORDER contains a buffer of up to eight alarms. A listing of the DataCORDER alarms is described in **Table 4–10**. See **Section** for configuration information.

Displaying Alarm Codes:

- 1. While in the Default Display Mode, press the ALT. MODE and ALARM LIST keys. This brings up the DataCORDER Alarm List Display Mode, which displays any alarms stored in the alarm queue.
- 2. To scroll to the end of the alarm list, press the Up Arrow key. Pressing the Down Arrow key will scroll the list backward.
- 3. The left display will show "AL#" where # is the alarms number in the queue. The right display will show "AA##," if the alarm is active, where ## is the alarm number. "IA##," will show if the alarm is inactive
- 4. "END" is displayed to indicate the end of the alarm list if any alarms are active. "CLEAr" is displayed if all the alarms in the list are inactive.
- 5. If no alarms are active, the alarm queue may be cleared. The exception to this rule is the DataCORDER alarm queue Full alarm (AL91), which does not have to be inactive in order to clear the alarm list. To clear the alarm list:
 - a. Press the ALT. MODE and ALARM LIST keys.
 - b. Press the Up or Down Arrow key until "CLEAr" is displayed.
 - c. Press the ENTER key. The alarm list will clear and "----" will be displayed.
 - d. Press the ALARM LIST key. "AL" will show on the left display and "-----" on the right display when there are no alarms in the list.
 - e. Upon clearing of the alarm queue, the alarm light will be turned off.

4–53 T-362

Table 4-10 DataCORDER Alarm Indications

Code	Description
dAL70	Recorder Supply Temperature Out of Range
	The supply recorder sensor reading is outside of the range of -50°C to 70°C (-58°F to +158°F), or the probe check logic has determined there is a fault with this sensor.
	NOTE: The P5 pre-trip test must be run to inactivate the alarm.
dAL71	Recorder Return Temperature Out of Range
	The return recorder sensor reading is outside of the range of -50°C to 70°C (-58°F to +158°F), or the probe check logic has determined there is a fault with this sensor.
	NOTE: The P5 pre-trip test must be run to inactivate the alarm.
dAL72-74	USDA Temperatures 1, 2, 3 Out of Range
	The USDA probe temperature reading is outside of -50°C to 70°C (-58°F to +158°F) range.
dAL75	Cargo Probe 4 Out of Range
	The cargo probe temperature reading is outside of -50°C to 70°C (-58°F to +158°F) range.
dAL76, 77	Future Expansion
	These alarms are for future expansion and are not in use at this time.
dAL78-85	Network Data Point 1 - 8 Out of Range
	The network data point is outside of its specified range. The DataCORDER is configured by default to record the supply and return recorder sensors. The DataCORDER may be configured to record up to eight additional network data points. An alarm number (AL78 to AL85) is assigned to each configured point. When an alarm occurs, the DataCORDER must be interrogated to identify the data point assigned. When a humidity sensor is installed, it is usually assigned to AL78.
dAL86	RTC Battery Low
	The real time clock (RTC) backup battery is too low to adequately maintain the RTC reading.
	A real time clock failure is critical to the operation of the unit. If this alarm occurs, replace the RTC battery at the next available opportunity. After replacing the battery the following actions are required:
	Update the RTC setting
	Update the unit's software configuration
	Update the operational software
	Update all user selectable function code settings (defrost, setpoint, etc)
dAL87	RTC Failure
	An invalid time has been detected. Either the DataCORDER run time hour and minute have not changed at the start of the hour, or the real time clock (RTC) time has gained or lost more than 2 minutes in the hour. This situation may be corrected by cycling the power, setting the clock or meeting the above criteria for an hour.
dAL88	DataCORDER EEPROM Failure
	A write of critical DataCORDER information to the EEPROM has failed.
dAL89	Flash Memory Error
	An error has been detected in the process of writing daily data to the non-volatile FLASH memory.
dAL90	Future Expansion
	This alarm is for future expansion, and is not in use at this time.
dAL91	Alarm List Full
	The DataCORDER alarm queue is determined to be full (eight alarms).

4.6.6 Pre-Trip Data Recording

The DataCORDER will record the initiation of a pre-trip test (see **Section 4.5**) and the results of each test included in pre-trip. The data is time-stamped and may be extracted via the Data Retrieval program. See **Table 4–11** for a description of the data stored in the DataCORDER for each corresponding pre-trip test.

Table 4-11 DataCORDER Pre-Trip Result Records

Test	Title	Data
P1-0	Heater On	Pass / Fail / Skip Result, Change in current for Phase A, B & C
P1-1	Heater Off	Pass / Fail / Skip Result, Change in currents for Phase A, B & C
P2-0	Condenser Fan On	Pass / Fail / Skip Result, Water pressure switch (WPS) - Open/Closed, Change in currents for Phase A, B and C
P2-1	Condenser Fan Off	Pass / Fail / Skip Result, Change in currents for Phase A, B & C
P3-0	Low Speed Evaporator Fan On	Pass / Fail / Skip Result, Change in currents for Phase A, B & C
P3-1	Low Speed Evaporator Fan Off	Pass / Fail / Skip Result, Change in currents for Phase A, B & C
P4-0	High Speed Evaporator Fan On	Pass / Fail / Skip Result, Change in currents for Phase A, B & C
P4-1	High Speed Evaporator Fan Off	Pass / Fail / Skip Result, Change in currents for Phase A, B & C
P5-0	Supply / Return Probe Test	Pass / Fail / Skip Result, STS, RTS, SRS and RRS
P5-1	Secondary Supply Probe (SRS) Test	Pass / Fail / Skip
P5-2	Secondary Return Probe (RRS) Test	Pass / Fail / Skip
P5-3	Evaporator Fan Direction Test	Pass / Fail / Skip
P5-7	Primary vs. Secondary Evaporator Temperature Sensor Test	Pass / Fail / Skip
P5-8	Future Expansion	Not Run
P5-9	Primary vs. Secondary Evaporator Pressure Transducer Test	Pass / Fail / Skip
P5-10	Humidity Sensor Controller Configuration Verification Test	Pass / Fail / Skip
P5-11	Humidity Sensor Installation Verification Test	Pass / Fail / Skip
P5-12	Humidity Sensor Range Check Test	Pass / Fail / Skip
P6-0	Discharge Thermistor Test	Pass / Fail / Skip
P6-1	Evaporator Temperature Sensor (Suction) Test	Pass / Fail / Skip
P6-2	Discharge Pressure Transducer Test	Pass / Fail / Skip
P6-3	Suction Pressure Transducer Test	Pass / Fail / Skip
P6-4	Compressor Current Draw Test	Pass / Fail / Skip
P6-5	Compressor Leak Test	Pass / Fail / Skip
P6-6	Economizer Valve Test	Pass / Fail / Skip

4–55 T-362

Table 4–11 DataCORDER Pre-Trip Result Records (Continued)

Test	Title	Data
P6-7	Digital Unloader Valve Test	Pass / Fail / Skip
P6-9	Liquid Injection Valve Test (If equipped)	Pass / Fail / Skip
P6-10	Electronic Expansion Valve Test	Pass / Fail / Skip
P7-0	High Pressure Switch Closed	Pass / Fail / Skip Result, AMBS, DPT or CPT (if equipped)
		Input values that component opens
P7-1	High Pressure Switch Open	Pass / Fail / Skip Result, STS, DPT or CPT (if equipped)
		Input values that component closes
P8-0	Perishable Mode Heat Test	Pass / Fail / Skip Result, STS, time it takes to heat to 16°C (60°F)
P8-1	Perishable Mode Pulldown Test	Pass / Fail / Skip Result, STS, time it takes to pull down to 0°C (32°F)
P8-2	Perishable Mode Maintain Test	Pass / Fail / Skip Result, Averaged DataCORDER supply temperature (SRS) over last recording interval.
P9-0	Defrost Test	Pass / Fail / Skip Result, DTS reading at end of test, line voltage, line frequency, time in defrost.
P10-0	Frozen Mode Heat Test	Pass / Fail / Skip Result, STS, time unit is in heat.
P10-1	Frozen Mode Pulldown Test	Pass / Fail / Skip Result, STS, time to pull down unit to - 17.8°C (0°F).
P10-2	Frozen Mode Maintain Test	Pass / Fail / Skip Result, Averaged DataCORDER return temperature (RRS) over last recording interval.

4.6.7 DataCORDER Communications

Hardware

DataCORDER uploads or downloads on a unit with an ML3 controller can be accomplished with one of the following methods:

- Using the programming slot in the controller with the choice of hardware options:
 - PCMCIA sRAM Card. (This is obsolete but still supported)
 - USB Adapter with USB. (One USB for upload, one USB for download)
 - MUA Adapter with USB (PN 07-00571-00). (The adapter stays in the controller)
 - MST Service Tool with USB (PN 07-00572-00). (The service tool is temporary in the controller)
- Connecting a laptop to the Interrogator port.

Refer to Controller Programming procedures in the Service chapter for upload / download procedures.

Software

Downloaded and real-time data from the DataCORDER can be viewed in the original DataLINE software or the ContainerLINK™ app.

- DataLINE is the original windows program that allows interrogation, configuration variable assignment, screen view of the data, hard copy report generation, cold treatment probe calibration and file management.
 DataLINE 3.12 is most likely the last release of DataLINE. See DataLINE operations manual 62-10629 for detailed procedures.
- ContainerLINK is an app for smart phones, tablets and Windows computers. The functionality of the original DataLINE software is now integrated into ContainerLINK.

T-362 4–56

.

4.6.8 USDA Cold Treatment

Sustained cold temperature has been employed as a post-harvest method for the control of fruit flies and other insect genera. The commodity, insect species, treatment temperatures and exposure times are found in sections T107, T108, and T109 of the USDA Treatment Manual.

In response to the demand to replace fumigation with this environmentally sound process, Carrier has integrated Cold Treatment capability into its microprocessor system. These units have the ability to maintain supply air temperature within one quarter degree Celsius of set point and record minute changes in product temperature within the DataCORDER memory, thus meeting USDA criteria. Information on USDA is provided in the following sub-paragraphs.

USDA Recording

A special type of recording is used for USDA cold treatment purposes. Cold treatment recording requires three remote temperature probes be placed at prescribed locations in the cargo. Provision is made to connect these probes to the DataCORDER via receptacles located at the rear left-hand side of the unit. Four or five receptacles are provided. The four 3-pin receptacles are for the probes. The 5-pin receptacle is the rear connection for the Interrogator. The probe receptacles are sized to accept plugs with tricam coupling locking devices. A label on the back panel of the unit shows which receptacle is used for each probe.

The standard DataCORDER report displays the supply and return air temperatures. The cold treatment report displays USDA #1, #2, #3 and the supply and return air temperatures. Cold treatment recording is backed up by a battery so recording can continue if AC power is lost.

USDA / Message Trip Comment

A special feature in DataLINE allows the user to enter a USDA (or other) message in the header of a data report. The maximum message length is 78 characters. Only one message will be recorded per day.

USDA Cold Treatment Procedure

The following is a summary of the steps required to initiate a USDA Cold Treatment. If configured for USDA probes, setup can be verified as follows. This procedure is applicable for DataLINE software.

- 1. Ensure the DataCorder is configured as follows from the Configuration Screen (see Figure 4.9):
 - a. Configuration Option is set for USDA probes.
 - b. Logging Interval is set for 60 minutes.
 - c. DataCorder Sample Type is set for 2 Averaged 3-USDA.
 - d. Resolution is set for Normal.




Figure 4.9 DataCORDER Configuration Screen

4–57 T-362

Calibrate the three USDA probes by ice bathing the probes and performing the calibration function (see
Figure 4.10) with the DataLINE. Refer to the Ice Bath Preparation procedure. This calibration procedure
generates the probe offsets which are stored in the controller and applied to the USDA sensors for use in
generating sensor type reports.

Current Probe Offset Temperatures Probe UnCal-Offset Calibrated USDA1 0.0 C 0.0 C 0.0 C USDA2 0.0 C 0.0 C 0.0 C USDA3 0.0 C 0.0 C 0.0 C CARGO 0.0 C 0.0 C Auto C Internal Enter Ice Bath Temperature 0.0 Auto USDA Probe 1 USDA Probe 3 C External USDA Probe 2 Cargo Probe Send Close Successfully connected with the refrigeration unit 5307 🥝


Figure 4.10 DataCorder Probe Calibration Screen

- 3. Pre-cool the container to the treatment temperature or below.
- 4. Install the DataCORDER module battery pack (if not already installed).
- 5. Place the three probes. See USDA Treatment Manual for directions on placement of probes in fruit and probe locations in container.

Sensor 1	Place the first sensor, labeled USDA1, in a box at the top of the stack of the fruit nearest to the air return intake.
Sensor 2	Place the second sensor, labeled USDA2, slightly aft of the middle of the container, halfway between the top and bottom of the stack.
Sensor 3	Place the third sensor, labeled USDA3, one pallet stack in from the doors of the container, halfway between the top and bottom of the stack.

6. To initiate USDA recording, connect the personal computer and Enter ISO Trip header information (**Figure 4.11**) using the DataLINE software. Enter all fields along with a trip comment if desired.

Figure 4.11 DataCorder Probe Calibration Screen



e. Using the System Tools screen (see Figure 4.12) in the DataLine software perform a "Trip Start."

🚟 System Tools Current Configurations Controller Information ABCU1234567 94=SRS, RRS, (USDA:1,2,3), H Container ID: DataCorder Recording Intervals 60 Minutes Setpoint: 25.7 Compressor Hour Meter: Hours Custom Controller Controller Parameters Change DataCorder Date Date and Time 07/26/2001 15:26 DataCorder Date/Time: 07/26/2001 15:24 PC Date/Time: 07/26/2001 15:26 Sunchronize with PC Send Trip Functions Last Trip Start: 07/20/2001 09:00 Send Comment with New Trip Start New Trip Trip Comment ISO Trip Header Close 5117 🕝 5117 🖁 F1=Help Successfully connected with the refrigeration unit

Figure 4.12 DataCorder Systems Tool Screen

4.6.9 ISO Trip Header

DataLINE provides the user with an interface to view/ modify current settings of the ISO trip header through the ISO Trip Header screen.

The ISO Trip Header screen is displayed when the user clicks on the "ISO Trip Header" button in the "Trip Functions" Group Box on the System Tools screen.

F9 function - Provides the user with a shortcut for manually triggering the refresh operation. Before sending modified parameter values, the user must ensure that a successful connection is established with the controller.

If the connection is established with the DataCORDER, the current contents of the ISO Trip Header from the DataCORDER will be displayed in each field. If the connection is not established with the DataCORDER, all fields on the screen will be displayed as "Xs." If at any time during the display of the ISO Trip Header screen the connection is not established or is lost, the user is alerted to the status of the connection.

After modifying the values and ensuring a successful connection has been made with the DataCORDER, click on the "Send" button to send the modified parameter values.

The maximum allowed length of the ISO Trip Header is 128 characters. If the user tries to refresh the screen or close the utility without sending the changes made on the screen to the DataCORDER, the user is alerted with a message.

4–59 T-362

SECTION 5 OPERATION

5.1 Inspection



Beware of unannounced starting of the evaporator and condenser fans. The unit may cycle the fans and compress or unexpectedly as control requirements dictate.

- 1. Check inside the unit for the following conditions:
 - Check channels or "T" bar floor for cleanliness. Channels must be free of debris for proper air circulation.
 - Check container panels, insulation and door seals for damage. Perform permanent or temporary repairs.
 - Check visually that the evaporator fan motor mounting bolts are properly secured (see Section 7.17).
 - Check for visible corrosion on the evaporator stator and fan deck (see Section 7.18).
 - Check for dirt or grease on evaporator fans or fan deck and clean if necessary (see Section 7.18).
 - Check evaporator coil for cleanliness or obstructions. Wash with fresh water (see Section 7.18).
 - Check defrost drain pans and drain lines for obstructions and clear if necessary. Wash with fresh water.
 - Check panels on refrigeration unit for loose bolts and condition of panels. Make sure T.I.R. devices are in place on access panels.
- 2. Check condenser coil for cleanliness. Wash with fresh water (see Section 7.11).
- 3. Open the control box door. Check for loose electrical connections or hardware.
- 4. Check color of moisture-liquid indicator.

5.2 Connect Power



Do not attempt to remove power plug(s) before turning OFF the Start-Stop switch (ST), unit circuit breaker(s) and external power source.

⚠ WARNING

Make sure the power plugs are clean and dry before connecting to power receptacle.

5.2.1 Connecting to 380/460 VAC Power

- 1. Make sure the Start-Stop switch (ST), located on the control panel, is in "0" position (Off).
- 2. Make sure circuit breaker CB-1, located in the control box, is in "0" position (Off).
- 3. Plug the 460 VAC (yellow) cable into a de-energized 380/460 VAC, 3-phase power source and energize the power source.
- 4. Place circuit breaker CB-1 in "I" position (On).
- 5. Close and secure the control box door.

5.2.2 Connecting to 190/230 VAC Power

To allow unit operation on nominal 230 volt power, an autotransformer (see **Figure 5.1**) is required. The autotransformer is fitted with a 230 VAC cable and a receptacle to accept the standard 460 VAC power plug. The 230 volt cable is black in color while the 460 volt cable is yellow. The transformer may also be equipped with a circuit breaker (CB-2). The transformer is a step-up transformer that provides 380/460 VAC, 3-phase, 50/60 Hz power to the unit when the 230 VAC power cable is connected to a 190/230 VAC, 3-phase power source.

5–1 T-362

PROCEDURE:

- 1. Make sure the Start-Stop switch (ST), located on the control panel, is in "0" position (Off).
- 2. Make sure circuit breaker CB-1, located in the control box, and CB-2, located on the transformer, are both in "0" position (Off).
- 3. Plug in and lock the 460 VAC power plug at the receptacle on the transformer.
- 4. Plug the 230 VAC (black) cable into a de-energized 190/230 VAC, 3-phase power source and energize the power source.
- 5. Set circuit breakers CB-1 and CB-2 to "I" position (On).
- 6. Close and secure the control box door.




Figure 5.1 Autotransformer

- 1) Circuit Breaker (CB-2) 230-Volt
- 3) Dual Voltage Module Autotransformer

2) 460 VAC Power Receptacle

5.3 Adjust Fresh Air Makeup Vent

The purpose of the fresh air makeup vent is to provide ventilation for commodities that require fresh air circulation. The vent *must be closed* when transporting frozen foods.

Air exchange depends on static pressure differential, which will vary depending on the container and how the container is loaded.

Units may be equipped with a vent position sensor (VPS). The VPS determines the position of the fresh air vent (upper or lower, as equipped) and sends data to the controller display.

5.3.1 Upper Fresh Air Makeup Vent

Two slots and a stop are designed into the Upper Fresh Air disc for air flow adjustments. The first slot allows for a 0 to 30% air flow; the second slot allows for a 30 to 100% air flow.


To adjust the percentage of air flow, loosen the wing nut and rotate the disc until the desired percentage of air flow matches with the arrow. Tighten the wing nut.

To clear the gap between the slots, loosen the wing nut until the disc clears the stop.

See Figure 5.2 for air exchange values for an empty container. Higher values can be expected for a fully loaded container.

T-362 5–2

Figure 5.2 Upper Fresh Air Make Up Flow Chart



5.3.2 Lower Fresh Air Makeup Vent

a. Full Open or Closed Positions

Maximum air flow is achieved by loosening the wing nuts and moving the cover to the maximum open (100%) position. The closed position is 0% air flow position. The operator may also adjust the opening to increase or decrease the air flow volume to meet the required air flow.

b. Reduced Flow for Lower Fresh Air Makeup

NOTE

In order to prevent inaccurate display readings on units equipped with a VPS, ensure that the rack and pinion drive of the VPS is not disrupted when adjusting the air makeup vent.

NOTE

Do not loosen the hex nut beyond its stop. Doing so may cause inaccurate display readings and errors in DataCORDER reports.

Similar to the Upper Fresh Air Makeup vent, two slots and a stop are designed into the Lower Fresh Air slide for air flow adjustments. The first slot allows for a 0 to 25% air flow; the second slot allows for a 25 to 100% air flow. To adjust the percentage of air flow, loosen the hex nut and rotate the disc until the desired percentage of air flow matches with the arrow. Tighten the hex nut. To clear the gap between the slots, loosen the hex nut until the disc clears the stop.

On some models the air slide is supplied with two adjustable air control discs. The fresh air makeup can be adjusted for 15, 35, 50 or 75 cubic meters per hour (CMH). The air flow has been established at 60 Hz power and 2-1/2 inch T bar and with 15 mm (0.6 inch) H_2O external static above free blow.

Loosen the hex nut, adjust each disc to the required air flow, then tighten the hex nut.

NOTE

The main air slide is in the fully closed position during reduced air flow operation when equipped with air control discs.

c. Air Sampling for Carbon Dioxide (CO₂) Level

Loosen the hex nuts and move the cover until the arrow on the cover is aligned with the "atmosphere sampling port" label. Tighten the hex nuts and attach a 3/8 in. hose to the sampling port.

If the internal atmosphere content has reached an unacceptable level, the operator may adjust the disc opening to meet the required air flow volume to ventilate the container.

5–3 T-362

5.3.3 Vent Position Sensor

The vent position sensor (VPS) allows the user to determine the position of the fresh air vent via Cd45. This function code is accessible via the Code Select key.

The vent position will display for 30 seconds whenever motion corresponding to 5 CMH (3 CFM) or greater is detected. It will scroll in intervals of 5 CMH (3 CFM). Scrolling to Cd45 will display the Fresh Air Vent Position.

The position of the vent will be recorded in the DataCORDER whenever the unit is running under AC power and during any of the following conditions:

- Trip start
- Every power cycle
- Midnight
- · Manual changes greater than 5 CMH (3 CFM) remaining in the new position for at least four minutes

NOTE

The user has four minutes to make necessary adjustments to the vent setting. This time calculation begins on the initial movement of the sensor. The vent can be moved to any position within the four minutes. On completion of the first four minutes, the vent is required to remain stable for the next four minutes. If vent position changes are detected during the four-minute stability period, AL50 will be generated. This provides the user with the ability to change the vent setting without generating multiple events in the DataCORDER.

5.4 Connect Water-Cooled Condenser

The water-cooled condenser is used when cooling water is available and heating the surrounding air is objectionable, such as in a ship's hold. If water-cooled operation is desired, connect in accordance with the following subparagraphs.

5.4.1 Water-Cooled Condenser with Water Pressure Switch

- 1. Connect the water supply line to the inlet side of the condenser and the discharge line to the outlet side of the condenser (see Figure 3.6, Figure 3.7).
- 2. Maintain a flow rate of 11 to 26 liters per minute (3 to 7 gallons per minute). The water pressure switch will open to de-energize the condenser fan relay. The condenser fan motor will stop and will remain stopped until the water pressure switch closes.
- 3. To shift to air-cooled condenser operation, disconnect the water supply and the discharge line to the watercooled condenser. The refrigeration unit will shift to air-cooled condenser operation when the water pressure switch closes.

5.4.2 Water-Cooled Condenser with Condenser Fan Switch

- 1. Connect the water supply line to the inlet side of condenser and the discharge line to the outlet side of the condenser (see Figure 3.6, Figure 3.7).
- 2. Maintain a flow rate of 11 to 26 lpm (3 to 7 gpm).
- 3. Set the condenser fan switch to position "O." This will de-energize the condenser fan relay. The condenser fan motor will stop and remain stopped until the CFS switch is set to position "I."



When condenser water flow is below 11 lpm (3 gpm) or when water-cooled operation is not in use, the CFS switch MUST be set to position "1" or the unit will not operate properly.

4. To shift to air-cooled condenser operation, stop the unit, set the CFS switch to position "I" and restart the unit. Disconnect the water lines to the water-cooled condenser

T-362 5–4

5.5 Connect Remote Monitoring Receptacle

If remote monitoring is required, connect the remote monitor plug at the unit receptacle (see Figure 3.10).

When the remote monitor plug is connected to the remote monitoring receptacle, the following remote circuits are energized:

- Sockets B to A: Energizes remote cool light
- Sockets C to A: Energizes remote defrost light
- · Sockets D to A: Energizes remote in-range light

5.6 Starting and Stopping Instructions



Make sure that the unit circuit breaker(s) CB-1 & CB-2 and the Start-Stop switch (ST) are in the "O" (OFF) position before connecting to any electrical power source.

NOTE

The electronic phase detection system will check for proper compressor rotation within the first 30 seconds. If rotation is not correct, the compressor will be stopped and restarted in the opposite direction. If the compressor is producing unusually loud and continuous noise after the first 30 seconds of operation, stop the unit and investigate.

5.6.1 Starting the Unit

- Verify that power is properly applied, the fresh air vent is in proper position, and (if required) the watercooled condenser is connected.
- 2. Place the Start-Stop switch (ST) to position "I" (ON) (see **Figure 3.10**). The controller function codes for the container ID (Cd40), software version (Cd18) and unit model number (Cd20) will be displayed in sequence.
- 3. Continue with the Start Up Inspection. See Section 5.7.

5.6.2 Stopping the Unit

1. To stop the unit, place the Start-Stop switch (ST) in position "0" (OFF).

5.7 Start-Up Inspection

5.7.1 Physical Inspection

Check rotation of condenser fan and evaporator fans.

5.7.2 Check Controller Function Codes

Check, and if required, adjust controller function codes (Cd27 through Cd37) in accordance with desired operating parameters. See **Table 4–4**.

5.7.3 Start Temperature Recorder

- Check and, if required, set the DataCORDER Configuration in accordance with desired recording parameter. See Section.
- 2. Enter a "Trip Start" with the following instructions:
 - a. Press the ALT MODE key. When the left display shows "dC", press the ENTER key.
 - b. Scroll to code dC30.
 - c. Press and hold the ENTER key for five seconds.
 - d. The "Trip Start" event will be entered in the DataCORDER.

5.7.4 Complete Inspection

Allow the unit to run for five minutes to stabilize conditions, and then perform a pre-trip diagnosis in accordance with **Section 5.8**.

5–5 T-362

5.8 Pre-Trip Diagnosis

⚠ CAUTION

Pre-trip inspection should not be performed with critical temperature cargoes in the container.



When PRE-TRIP key is pressed, economy, dehumidification and bulb mode will be deactivated. At the completion of pre-trip activity, economy, dehumidification and bulb mode must be reactivated.

Pre-trip diagnosis provides automatic testing of the unit components using internal measurements and comparison logic. The program will provide a "PASS" or "FAIL" display to indicate test results.

The testing begins with access to a pre-trip selection menu. The user may have the option of selecting one of two automatic tests. These tests will automatically perform a series of individual pre-trip tests. The user may also scroll down to select any of the individual tests.

When only the short sequence is configured, it will appear as "AUtO" in the display. Otherwise "AUtO1" will indicate the short sequence and "AUtO2" will indicate the long sequence. The test short sequence will run tests P0 through P6. The long test sequence will run tests P0 through P10.

A detailed description of the pre-trip test codes is listed in **Table 4–6**. If no selection is made, the pre-trip menu selection process will terminate automatically. However, dehumidification and bulb mode must be reactivated manually if required.

Scrolling down to the "rSLts" code and pressing ENTER will allow the user to scroll through the results of the last pre-trip testing run. If no Pre-testing has been run (or an individual test has not been run) since the unit was powered up, "- - - -" will be displayed.

NOTE

Pre-trip may also be initiated via communications. The operation is the same as for the keypad initiation described below except that should a test fail, the pre-trip mode will automatically terminate. When initiated via communications, a pre-trip test may not be interrupted with an Arrow key, but the pre-trip test can be terminated with the PRE-TRIP key.

5.8.1 Prior to Starting a Pre-Trip

Verify the following conditions prior to starting a pre-trip.

- Unit voltage (Cd07) is within tolerance.
- Unit amperage draw (Cd04, Cd05, Cd06) are within expected limits.
- All alarms are cleared and rectified.

5.8.2 Starting a Pre-Trip

- 1. Press the PRE-TRIP key to access the pre-trip test selection menu.
- 2. <u>To Run an Automatic Test</u>: Scroll through the selections by pressing the Up or Down Arrow keys to display AUTO, AUTO 1, AUTO 2 or AUTO 3 as desired, then press the ENTER key.
 - The unit will execute the series of tests without any need for direct user interface. These tests vary in length, depending on the component under test.
 - While tests are running, "P#-#" will appear on the left display; the #'s indicate the test number and subtest. The right display will show a countdown time in minutes and seconds, indicating the amount of time remaining in the test.

When a Pre-trip Auto 1 test runs to completion without a failure, the unit will exit pre-trip mode and return to normal control operation. However, dehumidification and bulb mode must be reactivated manually if required.

T-362 5–6



When a Pre-trip Auto 2 test runs to completion without being interrupted, the unit will terminate Pre-trip and display "Auto 2" "end." The unit will suspend operation until the user depresses the ENTER key!

3. When an automatic test fails, it will be repeated once. A repeated test failure will cause "FAIL" to be shown on the right display, with the corresponding test number to the left. Press the Down Arrow key to repeat the test, the Up Arrow key to skip to the next test, or the PRE-TRIP key to terminate testing. The unit will wait indefinitely or until a command is entered.

⚠ CAUTION

When a failure occurs during automatic testing, the unit will suspend operation awaiting operator intervention.

- 4. <u>To Run an Individual Test</u>: Scroll through the selections by pressing the Up or Down Arrow keys to display an individual test code. Press the ENTER key when the desired test code is displayed.
 - Individually selected tests, other than the LED / Display test, will perform the operations necessary to
 verify the operation of the component. At the conclusion, "PASS" or "FAIL" will be displayed. This message will remain displayed for up to three minutes, during which time a user may select another test. If
 the three minute time period expires, the unit will terminate Pre-trip and return to control mode operation.
 - While the tests are being executed, the user may terminate the Pre-trip diagnostics by pressing and holding the PRE-TRIP key. The unit will then resume normal operation. If the user decides to terminate a test but remain at the test selection menu, the user may press the Up Arrow key. When this is done, all test outputs will be de-energized and the test selection menu will be displayed.
 - Throughout the duration of any Pre-trip test (except during P-7 high pressure switch tests), the current limiting and pressure limiting processes are both active. The current limiting process is only active for P-7.

5.8.3 Displaying Pre-Trip Test Results

- 1. Press the PRE-TRIP key to access the Pre-trip test selection menu. "SELCt Prtrp" will be displayed.
- 2. Press the Arrow keys until the message "P," "rSLts" (Pre-trip results) is displayed.
- 3. Press the ENTER key. The results for all Pre-trip sub tests are available from this menu (i.e., 1-0, 1-1, etc).

The results will be displayed as "PASS" or "FAIL" for all the tests run to completion since power up. If a test has not been run since power up, "- - - - -" will be displayed.

Once all Pre-test activity is completed, dehumidification and bulb mode must be reactivated manually if required.

5.9 Probe Diagnostics

A complete temperature probe check is performed during the P5 pre-trip test. A probe check is also run at the end of a defrost cycle; the defrost light will remain on during this period. If supply probes are within limits and return probes are within limits, the unit will return to normal operation. During normal operation, the controller continuously monitors and compares adjacent temperature probe readings.

The probe check procedure consists of running the evaporator fans for up to eight minutes in order to compare the readings from the adjacent temperature probes. If a significant difference in temperature readings is detected between probes, a defrost cycle, followed by another probe check may be initiated. Any continued disagreement between probes will prompt the controller to invalidate the failed temperature probe, and the backup probe will be used for temperature control.

In Perishable Mode, both pairs of supply and return probes are monitored for probe disagreement. Probe disagreement is considered a difference of 0.5°C (0.9°F) or greater between the supply air sensors and/ or a difference of 2.0°C (3.6°F) between the return air sensors. Probe disagreement found in either pair can trigger a defrost probe check.

5-7

T-362

In Frozen Mode, only the controlling probes are considered. Disagreement of the controlling probes can trigger a defrost probe check, which will occur when the difference between the sensors is greater than 2.0°C (3.6°F). Normally, the controlling probes are the return probes but if both return probes are invalidated, the supply probes are used for control purposes. Probe disagreement of the non-controlling probe pair will not trigger a defrost probe check.

If after the defrost probe check the supply probes agree and return probes agree, all supply and return sensors are considered valid and the unit returns to normal control.

Probe Disagreement:

If the supply probes disagree and the return probes agree, the controller will invalidate the worst supply probe. If the probe check is run as part of pre-trip P-5, an alarm will be triggered for the invalidated probe. If it is a run time defrost probe check, the invalidated probe will be passed over and no alarm will be triggered. However, if the best supply probe is greater than 1.2°C (2.2°F) difference with respect to its return probes, the best supply probe is also invalidated. If unit is in Perishable Mode, a probe alarm will be triggered for both supply probes.

If the supply probes agree and the return probes disagree, invalidate the worst return probe. If the probe check is being run as part of pre-trip P-5, an alarm will be triggered for the invalidated probe. If it is a run time defrost probe check, the invalidated probe will be passed over and no alarm will be necessary. If the best return probe is greater than 1.2°C (2.2°F) difference with respect to its supply probes, then the best return probe is also invalidated. If the unit is in perishable mode, a probe alarm will be triggered for both return probes.

5.10 Optional Operating Modes

5.10.1 Emergency Bypass Operation

Emergency Bypass operation is used to override the controller, in the case of a controller malfunction, to keep the unit cooling. When Emergency Bypass is installed and turned on, the unit will remain in a continuous state of full cool until the Emergency Bypass switch is turned off.

To Place the Unit in the Emergency Bypass Operation:

- 1. Locate the connection diagram and connectors for the emergency bypass (EB) sensors behind the top left side of the compressor.
- 2. Disconnect the emergency bypass connector from the controller connector and attach it to the emergency bypass module connector (See Figure 5.3).
- 3. Locate the wire tire located at the EB switch in the control box.
- 4. Cut the wire tie, then place the EB switch in the On position.
- 5. Place the Mode Switch (MS) in the Full Cool position to enable the system for cooling.
- Manually control container air temperature by cycling the Mode switch between Full Cool and evaporator Fans Only.

To operate the fans only, the MODE switch must be in the Fans Only position and the EMERGENCY BYPASS switch must be in the Bypass position.

The EBS module uses the system's safety devices (high pressure switch, motor internal protectors, and heat termination thermostat) to protect the system while in Emergency Bypass Mode.



The unit will remain in the full cooling mode as long as the EB switch is in the On position and the Mode Switch is in the Full Cool position. If the cargo can be damaged by low temperatures, the operator must monitor container temperature and manually cycle operation as required to maintain temperature within required limits.

When the Emergency Bypass switch is in the Bypass position, the EBS will be enabled.

With the Mode switch in Full Cool mode, the following will occur simultaneously:

- The EBS switch will enable EBS input.
- The phase detection circuit will detect the phase rotation and close to provide power to the compressor contactor.


T-362 5–8

- The condenser fan contact will close to energize the condenser contactor and provide power to the condenser fan motor.
- The evaporator fan contact will close to energize the high speed evaporator contactor and provide power to the evaporator fan motor.
- The EBS electronic module will operate the EEV to control superheat.

To Return the Unit to Normal Operation:

- 1. Locate the connectors behind the compressor.
- 2. Disconnect the Emergency Bypass connector from the EBS module connector and reconnect it to the controller connector (see Figure 5.3).
- 3. Inside the control box, place the EB switch in the Off position.
- 4. Re-install the wire tie at the switch mounting.

Figure 5.3 Diagram of Emergency Bypass Connections



5.10.2 TripWise

TripWiseTM is a new premium option available for PrimeLINE and PrimeLINE with Edge units. TripWise is software logic that runs during every voyage as often as possible to indicate whether a standard Pre-trip Inspection (PTI) is needed and skip unless necessary. The tests run in the background and are similar to those completed as part of the standard PTI selection.

TripWise is set up through function code Cd65. Refer to **Table 4–4** for detail description of Cd65 menu selections and descriptions.

Components Checked during TripWise:

- Alarm Presence
- RMU Presence
- Compressor Test
- Temperature Control
- Current: Compressor, Condenser Motor, Evaporator Motor, Heater
- Sensors: Defrost Temperature Sensor (DTS), Evaporator Pressure Transducer (EPT), Evaporator Temperature Sensor (ETS), Humidity Sensor (HS), Return Sensors (RRS/RTS), Supply Sensors (SRS/STS), Suction Pressure Transducer (SPT), Discharge Pressure Transducer (DPT), Discharge Temperature Sensor (CPDS)
- Valves: Electronic Expansion Valve (EEV), Economizer Expansion Valve (ESV), Digital Unloader Valve (DUV)

5–9 T-362

Checking TripWise Status

To check the status of the container, press the PRE-TRIP key on the keypad. The message "SELCt | PrtrP" will appear on the display module, alternating with a TripWise status message described below:





"trIPW" "OFF"	The TripWise option is turned off.
"trlPW" "EX" (Expired)	It is recommended to pre-trip the unit prior to the unit's next trip following customer-specific guidelines.
"trIPW" "PASS"	The container should be ready for use after the operator has conducted a visual inspection. Standard PTI is not required.
"trIPW" "CHECK"	If any TripWise test(s) execute and do not meet the pass / fail requirements, It is recommended to pre-trip the unit following customer-specific guidelines prior to the unit's next trip.

Pressing the ENTER key while | "SELCt | "PrtrP" | is displayed will enter into the Pre-trip test menu. Pressing the Arrow keys will navigate through the standard PTI test selections menu.

Enabling or Disabling TripWise Option

- 1. Press the CODE SELECT key on the keypad.
- 2. Use the Arrow keys to bring up code Cd65 in the display.
- 3. Press the ENTER key. The display will show either "-----", "OFF" or "ON".

NOTE

If "----" is displayed, the TripWise function option is not active on the unit. To add this option to the unit, the equipment owner would need to contact their Regional Carrier Sales Manager.

- 4. Use the Arrow keys to toggle between "ON" and "OFF" and then press the ENTER key to select the desired option.
- 5. If "ON" is selected, the display will show "dAYS". This is the expiration time (2 through 365 in 1 day increments). Use the Arrow keys to change the parameter and then press the ENTER key to confirm.

NOTE

The expiration interval is the total maximum days allowed between the running of each test. For example, if days are set to 30 and the low speed evaporator fan test has not run within those 30 days, the TripWise expired message will be displayed. If the TripWise expired message is displayed, it is recommended to Pre-trip the unit following customer specific guidelines prior to the next trip.

TripWise Status Event

A TripWise status event will be recorded in the DataCorder recorder when the PTI is selected. In the current DataLINE software release, the event will show the status of the unit.

Figure 5.4 TripWise Status in DataCorder

Time Event Data
12:48 Operating Mode Changed to Cool Max
12:54 Operating Mode Changed to Low Speed Evaps Only
13:49 Operating Mode Changed to Cool Max
13:50 TripWise Status Logged by User
Status: Check
13:55 Operating Mode Changed to Low Speed Evaps Only

T-362 5–10

In DataLINE version 3.2, perform an all data download by selecting from the drop down menu "TripWise Summary" and then select a date in "User Logged Events" as shown in the Figure below. This will generate the status / results in a DataLINE TripWise Summary Report

Graphic... CreateReport Temperature Chart User Logged Events Sensor... 03/16/2016 07:40 Pass Sensor Data... 03/15/2016 14:50 Pass Event... 03/15/2016 14:47 Check Sensor and Event... 03/15/2016 14:43 Check Cold Treatment Summary... 03/15/2016 14:43 Pass TripWise Summary... 03/14/2016 15:27 Pass Controller Pretrips... 03/14/2016 15:26 03/14/2016 15:26 Pass Alarm Summary... Raw Data... Cancel Custom...

Figure 5.5 Generating TripWise Summary Report

5.10.3 XtendFRESH

XtendFRESH™, setup through function code Cd43, is a controlled atmosphere option that helps slow the ripening process by removing ethylene and simultaneously controlling CO2 and O2 levels in multiple combinations. Refer to Table 4–4 for detail description of Cd43 and Cd44 XtendFRESH Mode menu selections.

For detailed procedures and technical information related to the XtendFRESH controlled atmosphere, refer to the T-366 XtendFRESH Manual.

Turning On XtendFRESH Fresh Mode:

When XtendFRESH is in Fresh Mode, all XtendFRESH operations are enabled and setpoints for CO2 and O2 are confirmed.

- 1. Press the CODE SELECT key.
- 2. Use the Arrow keys to bring up Cd43 and press the ENTER key.
- 3. Use the Arrow keys to bring up "FrESh" and press ENTER.
- 4. The display will show | "CO2SP" | "#" |, where # is the CO2 setpoint value. Use the Arrow keys to select a CO2 setpoint and press ENTER to confirm. Or, just press ENTER to keep the originally displayed value.
 - The CO2 setpoint is the maximum level of CO2 allowed for the cargo. The range is 0% to 19% in 1% increments, with a default setting of 5%.
- 5. The display will show | "O2 SP" | "#" |, where # is the O2 setpoint value. Use the Arrow keys to select an O2 setpoint and press ENTER to confirm. Or, just press ENTER to keep the originally displayed value.
 - The O2 setpoint is the minimum level of oxygen allowed for the cargo. The range is 3% to 21% in 1% increments, with a default setting of 10%.

Turning Off XtendFRESH Fresh Mode:

When Off mode is active, all XtendFRESH operations will be disabled. The XtendFRESH vents will be closed and the scrubber will remain off. This will be the default mode anytime a frozen mode of operation has been selected. Whenever a frozen setpoint is selected, the current XtendFRESH setting will be saved.

- To manually turn XtendFRESH Mode Off, press the CODE SELECT key.
- 2. Use the Arrow keys to bring up Cd43 and press the ENTER key.
- 3. Use the Arrow keys to bring up "OFF" and press ENTER.

5–11 T-362

5.10.4 Automatic Cold Treatment Mode

Automated Cold Treatment (ACT) Mode is a method to simplify the task of completing cold treatment by automating the process of changing the setpoints. ACT is set up through function code Cd51. Refer to **Table 4–4** for detail description of Cd51 menu selections and display values.

NOTE

Automatic Cold Treatment (ACT) and Automatic Setpoint Change (ASC) can not be enabled simultaneously. Setting one will deactivate the other.

Turning On and Setting ACT Mode:

- 1. Press the CODE SELECT key.
- 2. Use the Arrow keys to bring up Cd51 and press the ENTER key.
- 3. Use the Arrow keys to bring up "On" and press the ENTER key.
- 4. The display will show | "trEAt" | "##.#"C" | with the right display flashing the last setting. Use the Arrow keys to select the desired cold treatment setpoint and press ENTER to confirm.

This is the maximum value that the USDA probes need to remain below to pass the Cold Treatment protocol. For instance, if the treat value is set at 35.0°F (1.7°C) then the USDA probe temperatures must remain below 35.0°F (1.7°C) to pass.



5. The display will show | "dAyS" | "#" | with the right display flashing the days for cold treatment. Use the Arrow keys to select the desired days and press ENTER to confirm.



6. The display will show | "ProbE" | "1234" | with the right display showing the probe numbers that are connected. Press ENTER.



7. The display will show | "SPnEW" | "##.#°C" | with the right display flashing the setpoint for when cold treatment process has completed. Use the Arrow keys to select the setpoint and press ENTER to confirm.



8. The Cd51 menu is returned to the top level and the display will show | "Cd 51" | "# #" |. The right display is the countdown timer of days and hours remaining. The unit will start to countdown once all detected USDA probes have reached the specified cold treatment temperature. The countdown timer will remain in the Cd51 display until the cold treatment process is complete.

Turning Off ACT Mode:

ACT is turned off automatically with a Trip Start, or if a Pre-Trip is initiated.

- 1. To manually turn ACT off, press the CODE SELECT key.
- 2. Use the Arrow keys to bring up Cd51 and press the ENTER key.
- 3. Use the Arrow keys to bring up "OFF" and press the ENTER key.

T-362 5–12

5.10.5 Automatic Setpoint Change Mode

Automatic Setpoint Change (ASC) Mode allows up to 6 setpoint changes to be pre-programmed over defined periods of time using function code Cd53. Refer to **Table 4–4** for detail description of Cd53 menu selections and display values.

NOTE

Automatic Setpoint Change (ASC) and Automatic Cold Treatment (ACT) and can not be enabled simultaneously. Setting one will deactivate the other.

NOTE

Before starting this procedure, be aware that inaction to confirm a menu selection in a timely fashion will result in the procedure being stopped and the menu will return to the top level.

Turning On and Setting ASC Mode:

- 1. Press the CODE SELECT key.
- 2. Use the Arrow keys to bring up Cd53 and press the ENTER key.
- 3. The display will show | "ASC" | "OFF" |.
- 4. Use the Arrow keys to select "On", then press ENTER.
- 5. The display will show | "nSC" | "#" |, where # is the number of setpoint changes.
 - For example, if 3 setpoints are chosen, 2 setpoints will be established along with associated days that they are to be active. Then, the 3rd setpoint is chosen for the temperature desired after this procedure is complete.
- 6. Use the Arrow keys to select the desired number (1-6) and press ENTER to confirm.
- 7. The display will show | "SP 0" | "#.#°C" |, where # is the desired setpoint temperature. This is the first setpoint to be programmed.
- 8. Use the Arrow keys to select the desired setpoint and press ENTER to confirm.
- 9. The display will show | "dAY 0" | "#" |, where # is the amount of days to keep this setpoint active.
- 10. Use the Arrow keys to select the desired number of days (1-99) and press ENTER to confirm.
- 11. The display will return back to | "SP #" | "#.#"C" |.
- 12. If there was more than 1 programmed setpoint chosen (nSc value), then the process will repeat itself of selecting a setpoint along with days to run that setpoint. Repeat steps 7-10 for all setpoints.
 - If there are no more programmed setpoints, then this last setpoint will be for unit temperature after ASC has completed. Continue to the next step.
- 13. Use the Arrow keys to select the setpoint after completion and press ENTER to confirm.
- 14. The Cd53 menu is returned to the top level and the display will show | "Cd 53" | "0 0" |. Upon exiting Cd53 and then returning, the display will now show | "Cd 53" | "# #" |, where the right display is the countdown timer of days and hours remaining.
- 15. While ASC Mode is in progress, the user can choose to <u>view only the settings</u> chosen for ASC. Once at Cd53, "On" is flashing. Press ENTER and then continue to press ENTER to toggle through all of the current selections. No edits will be allowed.
- 16. While ASC Mode is in progress, the user can choose to <u>edit the settings</u> for the ASC Mode currently in progress. Once at Cd53, "On" is flashing. Use the arrow keys to display "OFF" and press ENTER. Then, use Arrow keys to select "On" and press ENTER. The procedure will start over to create settings for ASC mode. Repeat this procedure starting at step 5.

Turning Off ASC Mode:

ASC will be turned off automatically with a Trip Start, or if a Pre-Trip is initiated.

- 1. To manually turn ACT off, press the CODE SELECT key.
- 2. Use the Arrow keys to bring up Cd53 and press the ENTER key.
- 3. Use the Arrow keys to bring up "OFF" and press the ENTER key.
- 4. The Cd53 menu is returned to the top level and the display will show | "Cd 53" | "0 0" |.

5–13 T-362

5.10.6 Quest Mode

QUEST Mode, controlled with function code Cd50, is a power saving option that reduces energy requirements. QUEST Mode can apply to either QUEST or QUEST II option depending on which option was chosen for the particular unit. Refer to **Table 4–4** for detail description of Cd50 QUEST Mode menu selections and operation.

Turning On QUEST Mode:

- 1. Press the CODE SELECT key.
- 2. Use the Arrow keys to bring up Cd50 and press the ENTER key.
- 3. Use the Arrow keys to bring up "On" and press the ENTER key.

Turning Off QUEST Mode:

QUEST will be turned off automatically with a Trip Start, or if a Pre-Trip is initiated.

- 1. To manually turn QUEST Mode Off, press the CODE SELECT key.
- 2. Use the Arrow keys to bring up Cd50 and press the ENTER key.
- 3. Use the Arrow keys to bring up "OFF" and press the ENTER key.

5.10.7 FuelWise Mode

FuelWise Mode, controlled with function code Cd63, is an option that saves energy while operating in the perishable setpoint range. Refer to **Table 4–4** for detail description of Cd63 FuelWise Mode menu selections and operation.

Turning On FuelWise Mode:

- 1. Press the CODE SELECT key.
- 2. Use the Arrow keys to bring up Cd63 and press the ENTER key.
- 3. Use the Arrow keys to bring up "On" and press the ENTER key.

Turning Off FuelWise Mode:

FuelWise Mode is turned off automatically with a Trip Start, or if a Pre-Trip is initiated.

- 1. To manually turn FuelWise Off, press the CODE SELECT key.
- 2. Use the Arrow keys to bring up Cd63 and press the ENTER key.
- 3. Use the Arrow keys to bring up "OFF" and press the ENTER key.

5.10.8 Pharma Mode

Pharma Mode, controlled with function code Cd75, is an option that allows cargoes to be maintained at temperature setpoints of either 5°C (41°F) or 20°C (68°F), while maintaining lower humidity levels. Refer to **Table** 4–4 for detail description of Cd75 Pharma Mode menu selections and operation.

Turning On Pharma Mode:

- 1. Press the CODE SELECT key.
- 2. Use the Arrow keys to bring up Cd75 and press the ENTER key.
- 3. Use the Arrow keys to bring up "On" and press the ENTER key.
- 4. The display will show | "Sp" | "05" |, where 05 is blinking. Press ENTER to select 05. Or use the Arrow keys to select "20" and press ENTER.


Turning Off Pharma Mode:

- 1. To manually turn Pharma Mode Off, press the CODE SELECT key.
- 2. Use the Arrow keys to bring up Cd75 and press the ENTER key.
- 3. Use the Arrow keys to bring up "OFF" and press the ENTER key.

T-362 5–14

SECTION 6 TROUBLESHOOTING

Figure 6.1 Unit Troubleshooting Sequence



6-1 T-362

Condition	Possible Cause	Remedy / Reference
6.1 Unit will not Start or	r Starts then Stops	
No power to unit	External power source OFF	Turn on
	Start-Stop switch (ST) OFF or defective	Check
	Circuit breaker tripped or OFF	Check
	Autotransformer not connected	Section 5.2.2
	Circuit breaker OFF or defective	Check
Logo of control nower	Control transformer defective	Replace
Loss of control power	Fuse (F3A/F3B) blown	Check
	Start-Stop switch (ST) OFF or defective	Check
	Evaporator fan motor internal protector open	Section 7.17
	Condenser fan motor internal protector open	Section 7.12
Common ant(a) mat an austina	Compressor internal protector open	Section 7.9
Component(s) not operating	High pressure switch open	Section 6.7
	Heat termination thermostat open	Replace
	Malfunction of current sensor	Replace
	Low line voltage	Check
Compressor hums, but does	Single phasing	Check
not start	Shorted or grounded motor windings	Section 7.9
	Compressor seized	Section 7.9
6.2 Unit Operates Long	or Continuously in Cooling	
Containor	Hot load	Normal
Container	Defective box insulation or air leak	Repair
	Shortage of refrigerant	Section 7.3
	Evaporator coil covered with ice	Section 6.6
	Evaporator coil plugged with debris	Section 7.15
	Evaporator fan(s) rotating backwards	Section 7.17
	Air bypass around evaporator coil	Check
	Controller set too low	Reset
Refrigeration system	Compressor service valves or liquid line shutoff valve partially closed	Open valves completely
	Dirty condenser	Section 7.11.1
	Compressor worn	Section 7.9
	Current limit (function code Cd32) set to wrong value	Section 4.2.2
	Economizer solenoid valve malfunction	Section 7.21
	Digital unloader valve stuck open	Replace
	Electronic expansion valve	Replace

T-362 6–2

Condition	Possible Cause	Remedy / Reference
6.3 Unit Runs but has li	nsufficient Cooling	
	Abnormal pressures	Section 6.7
	Abnormal temperatures	Section 6.16
Refrigeration system	Abnormal currents	Section 6.17
	Controller malfunction	Section 6.9
	Evaporator fan or motor defective	Section 7.17
	Compressor service valves or liquid line shutoff valve partially closed	Open valves completely
	Frost on coil	Section 6.10
	Digital unloader valve stuck open	Replace
	Electronic expansion valve	Replace
6.4 Unit will not Heat or	has Insufficient Heating	
	Start-Stop switch (ST) OFF or defective	Check
No operation of any kind	Circuit breaker OFF or defective	Check
	External power source OFF	Turn ON
	Circuit breaker or fuse defective	Replace
	Control Transformer defective	Replace
No control power	Evaporator fan internal motor protector open	Section 7.17
	Heat relay defective	Check
	Heater termination thermostat open	Section 7.15
	Heater(s) defective	Section 7.16
	Heater contactor or coil defective	Replace
	Evaporator fan motor(s) defective or rotating backwards	Section 7.17
Unit will not heat or has	Evaporator fan motor contactor defective	Replace
insufficient heat	Controller malfunction	Section 6.9
	Defective wiring	Replace
	Loose terminal connections	Tighten
	Low line voltage	Section 3.3
6.5 Unit will not Termin	ate Heating	
	Controller improperly set	Reset
Unit fails to stop heating	Controller malfunction	Section 6.9
	Heater termination thermostat remains closed along with the heat relay	Section 7.15
6.6 Unit will not Defrost	t Properly	
	Defrost timer malfunction (Cd27)	Table 4–4
	Loose terminal connections	Tighten
Will not initiate defrost	Defective wiring	Replace
automatically	Defrost temperature sensor defective or heat termination thermostat open	Replace
	Heater contactor or coil defective	Replace

6–3 T-362

Condition	Possible Cause	Remedy / Reference
MACH COLOR OF THE COLOR	Manual defrost switch defective	Replace
Will not initiate defrost manually	Keypad is defective	Replace
manadily	Defrost temperature sensor open	Replace
Initiates but relay (DR) drops out	Low line voltage	Section 3.3
Initiates but does not defrost	Heater contactor or coil defective	Replace
initiates but does not denost	Heater(s) burned out	Section 7.16
Frequent defrost	Wet load	Normal
6.7 Abnormal Pressures	s	
	Condenser coil dirty	Section 7.11.1
	Condenser fan rotating backwards	Section 7.12
Lligh diagharma programa	Condenser fan inoperative	Section 7.12
High discharge pressure	Refrigerant overcharge or non-condensibles	Section 7.3
	Discharge service valve partially closed	Open
	Electronic expansion valve (EEV) control malfunction	Replace
	Incorrect software and/or controller configuration	Check
	Failed suction pressure transducer (SPT) or evaporator pressure transducer (EPT)	Replace
	Suction service valve partially closed\	Open
	Filter drier partially plugged	Section 7.14
Low suction pressure	Low refrigerant charge	Section 7.3
·	No evaporator air flow or restricted air flow	Section 7.15
	Excessive frost on evaporator coil	Section 6.6
	Evaporator fan(s) rotating backwards	Section 7.17.3
	EEV control malfunction	Replace
	Failed digital unloader valve (DUV)	Replace
Suction and discharge	Compressor operating in reverse	Section 6.15
pressures tend to equalize	Compressor cycling/stopped	Check
when unit is operating	Failed digital unloader valve (DUV)	Replace
6.8 Abnormal Noise or	Vibrations	
	Compressor start up after an extended shutdown	Normal
	Brief chattering when manually shut down	
0	Compressor operating in reverse	Section 6.15
Compressor	Loose mounting bolts or worn resilient mounts	Tighten/Replace
	Loose upper mounting	Section 7.9.1
	Loose slugging	Section 7.15
	Bent, loose or striking venturi	Check
Condenser or Evaporator Fan	Worn motor bearings	Section 7.12/Section 7.17
	Bent motor shaft	Section 7.12/Section 7.17

T-362 6–4

Condition	Possible Cause	Remedy / Reference		
6.9 Microprocessor Ma	6.9 Microprocessor Malfunction			
	Incorrect software and/or controller configuration	Check		
Will not control	Defective sensor	Section 7.29		
Will not control	Defective wiring	Check		
	Low refrigerant charge	Section 7.3		
6.10 No Evaporator Air F	Flow or Restricted Air Flow			
Even eveter seil bleeked	Frost on coil	Section 6.6		
Evaporator coil blocked	Dirty coil	Section 7.15		
	Evaporator fan motor internal protector open	Section 7.17		
No or partial evaporator air	Evaporator fan motor(s) defective	Section 7.17		
flow	Evaporator fan(s) loose or defective	Section 7.17		
	Evaporator fan contactor defective	Replace		
6.11 XtendFRESH not O	perating			
	Unit not Configured for XtendFRESH Operation	No action		
Vent not opening	Cd43 in Off mode	Enable Fresh Mode at Cd43. Table 4–4		
	Wiring disconnected	Check wiring		
Haabla ta salibaata 00	CO ₂ outside of acceptable levels	Check		
Unable to calibrate CO ₂ sensor	Check CO ₂ sensor	Enable Test Mode at Cd43. Table 4–4		
	Unit not Configured for XtendFRESH Operation	No action		
Code 44 displays " "	Check CO ₂ sensor	Enable Test Mode at Cd43. Table 4–4		
6.12 Electronic Expansion				
	Incorrect software and/or controller configuration	Check		
	Failed suction pressure transducer (SPT) or evaporator pressure transducer (EPT)	Replace		
	Suction service valve partially closed	Open		
	Filter drier partially plugged	Section 7.14		
	Low refrigerant charge	Section 7.3		
Low suction pressure	No evaporator air flow or restricted air flow	Section 7.15		
	Excessive frost on evaporator coil	Section 6.6		
	Evaporator fan(s) rotating backwards	Section 7.17.3		
	EEV control malfunction	Section 7.19		
	Failed digital unloader valve (DUV)	Replace		
	Loose or insufficiently clamped sensor	Replace		
	Foreign material in valve	Section 7.19		
High suction pressure with	Failed suction pressure transducer (SPT) or evaporator pressure transducer (EPT)	Replace		
low superheat	EEV control malfunction	Replace		
	Improperly seated powerhead	Ensure powerhead is locked and in place		

6–5 T-362

_iquid slugging in ecompressor	Failed suction pressure transducer (SPT) or evaporator pressure transducer (EPT)	Replace	
F	ailed FEV		
6.13 Autotransformer Malf	alled LL v	Replace	
	unction		
C	Circuit breaker (CB-1 or CB-2) tripped	Check	
Jnit will not start	Autotransformer defective	Section 7.26	
	Power source not turned ON	Check	
4	60 VAC power plug is not inserted into the receptacle	Section 5.2.2	
6.14 Water-Cooled Conder	nser or Water Pressure Switch		
ligh diagharma praceura	Dirty coil	Section 7.42	
High discharge pressure	Non-condensibles	Section 7.13	
Condenser fan starts and V	Vater pressure switch malfunction	Check	
stops	Vater supply interruption	Check	
6.15 Compressor Operatin	ng in Reverse		
	NOTE		
The compressor may st if required for phase de	tart in reverse for up to 10 seconds to determine co	orrect phase rotation	

Allowing the scroll compressor to operate in reverse for more than two minutes will result in internal compressor damage. Turn the start- stop switch OFF immediately.

_		
	Incorrect wiring of compressor	
Electrical	Incorrect wiring of compressor contactor(s)	Check
	Incorrect wiring of current sensor	
6.16 Abnormal Temperat	ures	
	Condenser coil dirty	Section 7.11.1
	Condenser fan rotating backwards	Section 7.12
	Condenser fan inoperative	Section 7.12.1
	Refrigerant overcharge or non-condensibles	Section 7.3
	Discharge service valve partially closed	Open
High discharge temperature	Electronic expansion valve (EEV) control malfunction	Replace
	Failed suction pressure transducer (SPT) or evaporator pressure transducer (EPT)	Replace
	Discharge temperature sensor drifting high	Replace
	Failed economizer expansion valve, economizer coil, or economizer solenoid valve	Replace
	Plugged economizer expansion valve, economizer coil, or economizer solenoid valve	Replace
	Loose or insufficiently clamped sensor	Replace
6.17 Abnormal Currents		
Unit reads abnormal currents	Current sensor wiring	Check

T-362 6–6

SECTION 7 SERVICE

NOTE

Use a refrigerant recovery system whenever removing refrigerant. When working with refrigerants you must comply with all local government environmental laws. In the U.S.A., refer to EPA section 608.



EXPLOSION HAZARD Failure to follow this WARNING can result in death, serious personal injury and / or property damage. Never use air or gas mixtures containing oxygen (O_2) for leak testing or operating the product. Charge only with refrigerants R-134a or R-513A as specified for the unit model number: Refrigerant must conform to AHRI Standard 700 specification.

NOTE

Annual maintenance procedures for PrimeLINE units 69NT40-561 can be found in the **62-10327 Annual Maintenance Manual**, located in the Literature section of the Container Refrigeration website. To find the manual from the Literature section, click on Container Units > All Container Units > Operation.

7.1 Section Layout

Service procedures are provided in this section beginning with refrigeration system service, then refrigeration system component service, electrical system service, temperature recorder service and general service. See the Table of Contents to locate specific topics.

7.2 Manifold Gauge Set

The manifold gauge set (see **Figure 7.1**) is used to determine system operating pressure, add refrigerant charge, and to equalize or evacuate the system.

2 7 6 5

Figure 7.1 Manifold Gauge Set

- Suction Pressure Valve (shown backseated)
- 2) Suction Pressure Gauge
- 3) Discharge Pressure Gauge
- 4) Discharge Pressure Valve (shown frontseated)

- 5) High Side Connection
- 6) Utility Connection to:
 - a. Refrigerant Cylinder
 - b. Vacuum Pump
 - c. Oil Container
- 7) Low Side Connection

When the Suction Pressure Valve is frontseated (turned all the way in), the suction (low) pressure can be checked at the Suction Pressure Gauge.

When the Discharge Pressure Valve is frontseated, the discharge (high) pressure can be checked at the Discharge Pressure Gauge.

When both valves are backseated (all the way out), high pressure vapor will flow into the low side.

7–1 T-362

When the Suction Pressure Valve is open and the Discharge Pressure Valve is shut, the system can be charged through the Utility Connection. Oil can also be added to the system.

A manifold gauge / hose set with self-sealing hoses (see **Figure 7.2**) is required for service of the models covered within this manual. The manifold gauge/hose set is available from Carrier Transicold. (P/N 07-00294-00, which includes items 1 through 6, **Figure 7.2**.)

NOTE

It is recommended that the manifold gauge set be dedicated to a specified refrigerant (R-134a or R-513A).

7.2.1 Evacuating the Manifold Gauge Set

If the manifold gauge / hose set is new or was exposed to the atmosphere, it will need to be evacuated to remove contaminants and air as follows:

- 1. Backseat (turn counterclockwise) both field service couplings (see Figure 7.2) and midseat both hand valves.
- 2. Connect the yellow hose to a vacuum pump and refrigerant cylinder.
- 3. Evacuate to 10 inches of vacuum and then charge with refrigerant to a slightly positive pressure of 0.1 kg / cm2 (1.0 psig).
- 4. Frontseat both manifold gauge set valves and disconnect from cylinder. The gauge set is now ready for use.




Figure 7.2 Manifold Gauge / Hose Set

- RED Refrigeration and / or Evacuation Hose (SAE J2196 / R-134a)
- 2) Hose Fitting (0.5-16 Acme)
- YELLOW Refrigeration and/or Evacuation Hose (SAE J2196 / R-134a)

- 4) Hose Fitting with O-ring (M14 x 1.5)
- 5) High Side Field Service Coupling (Red Knob)
- 6) BLUE Refrigeration and/or Evacuation Hose (SAE J2196/R-134a)
- Low Side Field Service Coupling (Blue Knob)

7.3 Service Connections


The compressor suction, compressor discharge, and the liquid line service valves (see Figure 7.3) are provided with a double seat and an access valve which enables servicing of the compressor and refrigerant lines.

Turning the valve stem clockwise (all the way forward) will frontseat the valve to close off the line connection and open a path to the access valve. Turning the stem counterclockwise (all the way out) will backseat the valve to open the line connection and close off the path to the access valve.

With the valve stem midway between frontseat and backseat, both of the service valve connections are open to the access valve path.

For example, the valve stem is first fully backseated when connecting a manifold gauge to measure pressure. Then, the valve is opened 1/4 to 1/2 turn to measure the pressure.

Figure 7.3 Service Valve



- 1) Access Valve
- 2) Step Cap
- 3) Valve Stem

- 4) Compressor or Filter Drier Inlet Connection
- 5) Line Connection

Connection of the manifold gauge / hose set (see Figure 7.4) is dependent on the component being serviced. If only the compressor is being serviced, the high side coupling is connected to the discharge service valve.

For service of the low side (after pump down), the high side coupling is connected to the liquid line service valve. The center hose connection is brought to the tool being used (vacuum, tank, etc.).

7.3.1 Connecting the Manifold Gauge Set

- 1. Remove the service valve stem cap and make sure the valve is backseated.
- 2. Remove the access valve cap (see Figure 7.3).
- 3. Connect the field service coupling (see Figure 7.2) to the access valve.
- 4. Turn the field service coupling knob clockwise to open the system to the gauge set.
- 5. Slightly midseat the service valve to read system pressures.
- 6. Repeat the procedure to connect the other side of the gauge set.



To prevent trapping liquid refrigerant in the manifold gauge set, make sure set is brought to suction pressure before disconnecting.

7.3.2 Removing the Manifold Gauge Set

- 1. While the compressor is still ON, backseat the high side service valve.
- 2. Midseat both hand valves on the manifold gauge set and allow the pressure in the manifold gauge set to be drawn down to low side pressure. This returns any liquid that may be in the high side hose to the system.
- 3. Backseat the low side service valve.
- 4. Backseat both field service couplings and frontseat both manifold hand valves.
- 5. Remove couplings from the access valves.
- 6. Install both service valve stem caps and service port caps (finger-tight only).

7.4 Pump Down the Unit

To service the filter drier, economizer, expansion valves, economizer solenoid valve, digital unloader valve or evaporator coil, pump the refrigerant into the high side of the unit:

7–3 T-362



The scroll compressor achieves low suction pressure very quickly. Do not use the compressor to evacuate the system below 0 psig. Never operate the compressor with the suction or discharge service valves closed (frontseated). Internal damage will result from operating the compressor in a deep vacuum.

7.4.1 Automatic Pump Down

1. To perform an Automatic Pump Down, use function code Cd59 Pump Down Logic. See Cd59 description in Table 4–4 Controller Function Codes.

7.4.2 Manual Pump Down:

- 1. Attach manifold gauge set to the compressor suction and discharge service valves. See Section 7.2.
- 2. Start the unit and run in the frozen mode, with controller set below -10°C (14°F), for 10 to 15 minutes.
- 3. Check function code Cd21 (See Section 4.2.2). The economizer solenoid valve should be open. If not, continue to run until the valve opens.
- 4. Frontseat the liquid line service valve. When the suction reaches a positive pressure of 0.1 bar (1.4 psig), place the Start-Stop switch (ST) to "0" to turn the unit Off.
- 5. Frontseat the suction service valve and discharge service valve. The refrigerant will be trapped between the discharge service valve and the liquid line valve.
- 6. Before opening up any part of the system, a slight positive pressure should be indicated on the pressure gauge. Remove power from the unit before opening any part of the system. If a vacuum is indicated, emit refrigerant by cracking the liquid line valve momentarily to build up a slight positive pressure.
- 7. When opening up the refrigerant system, certain parts may frost. Allow the part to warm to ambient temperature before dismantling. This avoids internal condensation which puts moisture in the system.
- 8. After repairs have been made, make sure to perform a refrigerant leak check (See Section 7.5), and evacuate and dehydrate the low side (see Section 7.6).
- 9. Check refrigerant charge. See Section 7.7.1.

7.5 Refrigerant Leak Checking

↑ WARNING

EXPLOSION HAZARD Failure to follow this WARNING can result in death, serious personal injury and / or property damage. Never use air or gas mixtures containing oxygen (O_2) for leak testing or operating the product. Charge only with refrigerants R-134a or R-513A as specified for the unit model number: Refrigerant must conform to AHRI Standard 700 specification.

- 1. The recommended procedure for finding leaks in a system is with an appropriate electronic leak detector. Testing joints with soapsuds is satisfactory only for locating large leaks.
- 2. If the system is without refrigerant, charge the system with refrigerant to build up pressure between 2.1 to 3.5 bar (30.5 to 50.8 psig). To ensure complete pressurization of the system, refrigerant should be charged at the compressor suction valve and the liquid line service valve. Remove refrigerant cylinder and leak-check all connections.

NOTE

Only refrigerant R-134a or R-513A, as specified for the unit model number, should be used to pressurize the system. Any other gas or vapor will contaminate the system, which will require additional purging and evacuation of the system.

- 3. If required, remove refrigerant using a refrigerant recovery system and repair any leaks. Check for leaks.
- 4. Evacuate and dehydrate the unit. See Section 7.6.
- 5. Charge unit. See Section 7.7.

7.6 Evacuation and Dehydration

7.6.1 General

Moisture is detrimental to refrigeration systems. The presence of moisture in a refrigeration system can have many undesirable effects. The most common are copper plating, acid sludge formation, "freezing-up" of metering devices by free water, and formation of acids, resulting in metal corrosion.

7.6.2 Preparation

- 1. Evacuate and dehydrate only after completing a pressure leak test. See Section 7.5.
- 2. Essential tools to properly evacuate and dehydrate any system include a vacuum pump (8m3/hr = 5 cfm volume displacement) and an electronic vacuum gauge. The pump is available from Carrier Transicold, P/N 07-00176-11. The micron gauge is P/N 07-00414-00.
- 3. If possible, keep the ambient temperature above 15.6°C (60°F) to speed evaporation of moisture. If the ambient temperature is lower than 15.6°C (60°F), ice might form before moisture removal is complete. Heat lamps or alternate sources of heat may be used to raise the system temperature.
- 4. Additional time may be saved during a complete system pump down by replacing the filter drier with a section of copper tubing and the appropriate fittings. Installation of a new drier may be performed during the charging procedure.




Figure 7.4 Refrigeration System Service Connections

- 1) Economizer Solenoid Valve
- 2) Receiver or Water Cooled Condenser
- 3) Compressor
- 4) Discharge Service Connection
- 5) Suction Service Connection
- 6) Vacuum Pump

- 7) Electronic Vacuum Gauge
- 8) Refrigerant Cylinder
- 9) Reclaimer
- 10) Manifold Gauge Set
- 11) Liquid Service Connection

7.6.3 Evacuate and Dehydrate - Complete System

NOTE

See Partial System procedure for information pertaining to partial system evacuation and dehydration.

1. Remove all refrigerant using a refrigerant recovery system.

7–5 T-362

 The recommended method to evacuate and dehydrate the system is to connect evacuation hoses at the compressor suction and liquid line service valve (see Figure 7.4). Make sure the service hoses are suited for evacuation purposes.

NOTE

To prevent the area between the Economizer Solenoid Valve (ESV) and the compressor from being isolated during evacuation, it is necessary to open the ESV using a magnet tool (Carrier Transicold P/N 07-00512-00).

3. Remove the ESV coil from the valve body. Place the magnet tool over the valve stem. An audible click will be heard when the ESV opens.

NOTE

Make sure to replace the valve coil before restating the unit. Starting the unit with the coil removed from the valve will burn out the coil.

- 4. Test the evacuation setup for leaks by backseating the unit service valves and drawing a deep vacuum with the vacuum pump and gauge valves open. Shut off the pump and check to see if the vacuum holds. Repair leaks if necessary.
- 5. Midseat the refrigerant system service valves.
- 6. Open the vacuum pump and electronic vacuum gauge valves, if they are not already open. Start the vacuum pump. Evacuate the unit until the electronic vacuum gauge indicates 2000 microns. Close the electronic vacuum gauge and vacuum pump valves. Shut off the vacuum pump. Wait a few minutes to be sure the vacuum holds.
- 7. Break the vacuum with either clean refrigerant (R-134a or R-513A as specified for the unit model number) or dry nitrogen. Raise system pressure to roughly 0.14 bar (2 psig), monitoring it with the compound gauge.
- 8. If refrigerant was used, remove using a refrigerant recovery system. If nitrogen was used, relieve the pressure.
- 9. Repeat steps 6 and 7 one time.
- 10. Remove the copper tubing and change the filter drier. Evacuate unit to 500 microns. Close the electronic vacuum gauge and vacuum pump valves. Shut off the vacuum pump. Wait five minutes to see if vacuum holds. This procedure checks for residual moisture and/or leaks.
- 11. With a vacuum still in the unit, the refrigerant charge may be drawn into the system from a refrigerant container on weight scales.

7.6.4 Evacuate and Dehydrate - Partial System

- If refrigerant charge has been removed from the low side only, evacuate the low side by connecting the
 evacuation set-up at the compressor suction valve and the liquid service valve but leave the service valves
 frontseated until evacuation is completed.
- Once evacuation has been completed and the pump has been isolated, fully backseat the service valves to isolate the service connections and then continue with checking and, if required, adding refrigerant in accordance with normal procedures.

7.7 Refrigerant Charge



EXPLOSION HAZARD Failure to follow this WARNING can result in death, serious personal injury and l or property damage. Never use air or gases containing oxygen (O₂) for leak testing or operating the product. Charge only with refrigerants R-134a or R-513A as specified for the unit model number: Refrigerant must conform to AHRI Standard 700 specification.

7.7.1 Checking the Refrigerant Charge

NOTE

Use a refrigerant recovery system whenever removing refrigerant. When working with refrigerants you must comply with all local government environmental laws. In the U.S.A., see EPA Section 608.

- 1. Connect the gauge manifold to the compressor discharge and suction service valves. For units operating on a water-cooled condenser, change over to air-cooled operation.
- 2. Bring the container temperature to approximately 0°C (32°F) or below. Then set the controller setpoint to 25°C (-13°F).
- 3. Partially block the condenser coil inlet air. If covering the lower portion of the coil is not sufficient, remove the left hand infill panel and cover the left side of the coil. Increase the area blocked until the compressor discharge pressure is raised to approximately 12.8 bar (185 psig).
- 4. On units equipped with a receiver, the level should be between the glasses. On units equipped with a watercooled condenser, the level should be at the center of the glass. If the refrigerant level is not correct, See Section 7.7.2 and Section 7.7.3 to add or remove refrigerant as required.

7.7.2 Adding Refrigerant to System - Full Charge

- 1. Evacuate unit and leave in deep vacuum. See Section 7.6.1.
- 2. Place refrigerant cylinder on scale and connect charging line from cylinder to liquid line valve. Purge charging line at liquid line valve and then note weight of cylinder and refrigerant.
- 3. Open liquid valve on cylinder. Open liquid line valve halfway and allow liquid refrigerant to flow into the unit until the correct weight of refrigerant has been added as indicated by scales. See **Section 3.2**
- 4. It may be necessary to finish charging unit through suction service valve in gas form, due to pressure rise in high side of the system.
- 5. Backseat the manual liquid line valve to close off the gauge port. Close liquid valve on cylinder.
- 6. Start the unit in cooling mode. Run for approximately 10 minutes and check the refrigerant charge.

7.7.3 Adding Refrigerant to System - Partial Charge

- 1. Examine the refrigerant system for any evidence of leaks, repair as necessary. See Section 7.5.
- 2. Maintain the conditions outlined in Section 7.7.1.
- 3. Fully backseat the suction service valve and remove the service port cap.
- 4. Connect the charging line between suction service valve port and refrigerant cylinder. Open the VAPOR valve.
- 5. Partially frontseat (turn clockwise) the suction service valve and slowly add charge until the refrigerant appears at the proper level. Be careful not to frontseat the suction valve fully. If the compressor is operated in a vacuum, internal damage may result.

7.8 Converting to R-513A Refrigerant

This procedure only applies to R-513A-ready units for 69NT40-561-500 models. This conversion is only by approval of the equipment owner.

- 1. The compressor will have a green dot on the DUV fitting to note that it can accept R-513A.
- 2. Recover all R-134a refrigerant from the unit, by following procedure in Section 7.6.
- 3. Change the filter drier.
- 4. Evacuate to 500 microns by placing the vacuum pump on the liquid line and suction service valve.
- 5. Charge the unit with a full charge of R-513A refrigerant, by following procedure in **Section 7.7.2**. Charge amounts are found in **Section 3.2** Refrigeration System Data.



When charging the unit with R-513A refrigerant, charge as a liquid only. R-513A is an azeotrope blend containing R-1234yf and R-134a. Charging or topping off as a vapor will result in an incorrect mixture of blend in the system.

6. Upon completion, change the refrigerant label (Carrier P/N 76-50235-00) on the front of the unit indicating the change in refrigerant.

7–7 T-362

7.9 Compressor

WARNING

Make sure power to the unit is OFF and power plug disconnected before replacing the compressor.

⚠ WARNING

Before disassembly of the compressor, be sure to relieve the internal pressure very carefully by slightly loosening the couplings to break the seal.

A CAUTION

The scroll compressor achieves low suction pressure very quickly. Do not use the compressor to evacuate the system below 0 psig. Never operate the compressor with the suction or discharge service valves closed (frontseated). Internal damage will result from operating the compressor in a deep vacuum.

! CAUTION

The PrimeLINE unit has a hermetically sealed compressor that should not be opened and/or repaired. Doing so can cause a loss in performance and premature system failure due to the precision machinery and assembly required within the compressor. To repair the unit, remove the faulty compressor and replace with an approved Carrier compressor. If the return of the compressor is not required, follow local waste collection & recycling regulations in discarding the compressor.

NOTICE

Replacement compressors are supplied without oil.

7.9.1 Removing and Replacing the Compressor

1. Turn the unit ON and run it in full cool mode for 10 minutes.

NOTE

If the compressor is not operational, frontseat the suction and discharge service valves and go to step 5.

- 2. Frontseat the manual liquid line valve and allow the unit to pull-down to 0.1 kg/cm2 (1 psig).
- 3. Place the Start-Stop switch (ST) to "0", turn the unit circuit breaker (CB-1) OFF, and disconnect power to the unit.
- 4. Frontseat the discharge and suction service valves.
- 5. Remove all remaining refrigerant from the compressor using a refrigerant recovery system.
- 6. Remove the compressor terminal cover, disconnect the ground wire and pull the cable plug from the compressor terminals. Install the terminal cover back after removing the power cable.


NOTE

Inspect the power cable (plug) terminals to ensure they are not deformed or have any signs of heat or arcing. If any damage is noted, replace the power cable.

- 7. Remove the Rotalock fittings from the suction and discharge service connections, and uncouple the unloader and economizer lines from the compressor.
- 8. Cut the dome temperature sensor (CPDS) wires. The replacement compressor comes with a CPDS already assembled.
- 9. Remove and save the compressor base mounting bolts. Discard the four top resilient mounts and washers.

- 10. Remove (slide out) the old compressor from the unit.
- 11. Inspect compressor base plate for wear. Replace, if necessary.
- 12. Wire tie the compressor base plate to the compressor, and slide the new compressor into the unit. See Figure 7.5.

Figure 7.5 Compressor Kit



- Compressor Discharge Temperature Sensor (CPDS)
- 2) O-Ring, Economizer Connection
- 3) Teflon Seal for Valve Connection (2)
- 4) Base Mounting Bolts
- 5) SST Washers
- 6) Resilient Mount

- 7) SST Washers
- 8) Mylar Washers
- 9) Wire Ties
- 10) Power Cable Gasket, Ground Connection Screw
- 11) Teflon Seal for Valve Connection (2)
- 12) O-Ring, Unloader Connection
- 13. Cut and discard the wire ties used to hold the base plate to the compressor.
- 14. Place the new SST washers on each side of the resilient mounts, and the new Mylar washer on the bottom of it as shown in Figure 7.5. Install the four base mounting bolts loosely.
- 15. Place the new Teflon seals at the compressor suction and discharge ports as well as the O-rings at the unloader and economizer line connection ports. Hand tighten all four connections.
- 16. Torque the four base-mounting screws to 6.2 mkg (45 ft-lbs).
- 17. Torque the compressor ports / connections.

Service Valve / Connection	Torque Value
Suction and Discharge Rotalocks	108.5 to 135.5 Nm (80 to 100 ft-lbs.)
Unloader connection	24.5 to 27 Nm (18 to 20 ft-lbs.)
Economized connection	32.5 to 35 Nm (24 to 26 ft-lbs.)

- 18. Connect (butt-splice and heat shrink) the new compressor dome temperature sensor with the old sensor wires removed in step 8. Wire-tie any loose wiring as appropriate.
- 19. Evacuate the compressor to 1000 microns if the unit was pumped down before the replaced compressor was removed. Otherwise, evacuate the complete unit and charge it with refrigerant (see Section 7.6.1 and Section 7.7.1).

7–9 T-362

- 20. Open the compressor terminal cover and connect the compressor power cable following the steps below:
 - a. Liberally coat the orange gasket surfaces with the Krytox lubricant.
 - b. Install the orange gasket part onto the compressor fusite with the grooved or threaded side out. Ensure that the gasket is seated onto the fusite base.
 - c. Coat the inside of the power plug (female) connector pins with the Krytox lubricant, and insert the plug onto the compressor terminal connections. Make sure, the orange gasket has bottomed out onto the fusite and it fits securely onto the terminal pins while fully inserted into the orange plug.
 - d. Connect the green ground wire to the grounding tab located inside the terminal box of the compressor using the self-tapping grounding screw. Close the compressor terminal box using the terminal cover removed in step 20.
- 21. Backseat all service valves, connect the power to the unit and run it for at least 20 minutes.
- 22. Perform a leak check of the system.

7.10 High Pressure Switch

7.10.1 Checking High Pressure Switch



Do not use a nitrogen cylinder without a pressure regulator.

NOTE

The high pressure switch is non-adjustable.

- 1. Remove switch as outlined in Section 7.10.2.
- 2. Connect ohmmeter or continuity light across switch terminals. Ohm meter will indicate no resistance or continuity light will be illuminated if the switch closed after relieving compressor pressure.
- 3. Connect hose to a cylinder of dry nitrogen (see Figure 7.6).

Figure 7.6 High Pressure Switch Testing

- 1) Cylinder Valve and Gauge
- 2) Pressure Gauge (0 to 36 kg/ cm2 = 0 to 400 psig)
- 3) Bleed-Off Valve

- 4) 1/4 inch Connection
- 5) Nitrogen Cylinder
- 6) Pressure Regulator

4. Set nitrogen pressure regulator at 26.4 kg/cm² (375 psig) with bleed-off valve closed.

- 5. Close valve on cylinder and open bleed-off valve.
- 6. Open cylinder valve. Slowly close bleed-off valve to increase pressure on switch. The switch should open at a static pressure up to 25 kg/cm² (350 psig). If a light is used, the light will go out. If an ohmmeter is used, the meter will indicate open circuit.
- 7. Slowly open bleed-off valve to decrease the pressure. The switch should close at 18 kg/cm² (250 psig).

7.10.2 Replacing High Pressure Switch

- 1. Remove the refrigerant charge.
- 2. Disconnect wiring from defective switch. The high pressure switch is located on the discharge connection or line and is removed by turning counterclockwise.
- 3. Install a new high pressure switch after verifying switch settings.
- 4. Evacuate, dehydrate and recharge the system.
- 5. Start the unit, verify refrigeration charge and oil level.

7.11 Condenser Coil

7.11.1 Condenser Coil Cleaning

To ensure optimal efficiency of the unit the condenser coil must be clean. The condenser coil should be cleaned at least once a year, but more frequent cleaning may be required depending on operating conditions. The coil is cleaned with fresh water sprayed in the reverse direction of the air flow to remove any debris from the coil. A high pressure washer is not required, mains water pressure is sufficient.



Do not remove the condenser fan grille before turning power OFF and disconnecting the power plug.

- 1. Make sure the unit is powered off and the plug is disconnected.
- 2. Remove the condenser fan grille.
- 3. Starting from the top of the coil, use a water hose with a nozzle to wash the coil from the inside out.
- 4. Systematically wash across the inside top face of the coil until the water runs clean.
- 5. Wash down the center section, and then through the bottom of the coil, continue washing until the water runs clear.
- 6. After the coil is clean, rinse the condenser fan to remove any dirt build up from the blades.
- 7. Replace the condenser fan grille ensuring that it is centered around the fan.

7.11.2 Condenser Coil Removal

1. Using a refrigerant reclaim system remove the refrigerant charge.



Do not remove the condenser fan grille before turning power OFF and disconnecting the power plug.

- 2. Remove the condenser fan grille, retain all bolts and washers for reuse.
- 3. Remove the condenser fan.
- 4. Remove the infill panels to the left and right of the condenser fan shroud.
- 5. Remove the condenser fan shroud.
- 6. Unplug the condenser fan motor.
- 7. Remove and retain sufficient putty from around the motor wire harness to allow the harness to be slid back through the side support bracket.
- 8. Cut the top and bottom drain lines midway between the side support bracket and the first cable tie, approx 150mm (6") from the side support bracket.
- 9. Remove and retain sufficient putty from around the drain lines to allow the tubes to be slid back through the side support bracket.
- 10. Remove filter drier.
- 11. Unbraze the inlet connection to coil.

7–11 T-362

- 12. Remove the cushion clamps securing the liquid line to the top and bottom receiver brackets, retain all clamps and securing hardware.
- 13. Place a support under the condenser coil before releasing the coil from the frame.
- 14. Remove the lower mounting bracket bolts from the inside of the coil.
- 15. Remove the top mounting bracket bolts and grille extension mount from inside the coil.
- 16. Remove the side support bracket mounting bolts.
- 17. Slide the condenser assembly with receiver out of the unit.

7.11.3 Condenser Coil Preparation

Before installing the new condenser coil, the receiver assembly and mounting hardware must be removed from the old coil assembly:

- 1. From the old coil, unbolt the receiver assembly from side support bracket.
- 2. Unbraze the receiver assembly from the coil outlet line and remove from the coil assembly.
- 3. Unbolt the side support bracket from the top and bottom coil supports and remove from old coil.
- 4. Refit the side support bracket to the new coil ensuring that the top and bottom are flush mounted with the coil support.


7.11.4 Condenser Coil Installation

Once the side support bracket has been secured to the new condenser coil, the entire assembly is ready to be installed into the unit:

- 1. Slide the new condenser coil into place ensuring the coil inlet connection is mated to the pipework and that the coil is fully supported.
- 2. Secure the condenser coil into the unit using the retained hardware; refit the mylar and fender washers:
 - a. Refit the side support bracket bolts.
 - b. Refit the top support bracket bolts as well as the top grille extension support.
 - c. Refit the bottom support bracket bolts.
- 3. Braze the condenser coil inlet connection.
- 4. Insert the receiver pipe work onto the coil outlet and loosely secure the receiver assembly to the side support bracket with the retained hardware.
- 5. Braze the outlet connection to the receiver assembly.
- 6. Install a new filter drier.
- 7. Replace the liquid line cushion clamps.
- 8. Secure the receiver assembly to the side support bracket.
- 9. Pressure / leak test the coil and filter drier connections. See Section 7.5.
- 10. Evacuate the entire unit. See Section 7.6.
- 11. Slide the top and bottom drain lines back into place through the side support bracket.
- 12. Using the two supplied straight connectors and contact adhesive reconnect the drain lines.
- 13. Slide the condenser fan motor wiring harness back through the side support bracket and refit to condenser motor.
- 14. Replace all wire ties that were removed to properly secure the drain line and wiring.
- 15. Reseal the wire harness and drain line penetrations with the putty.
- 16. Slide the condenser fan onto the motor shaft reversed but do not secure.
- 17. Refit the condenser fan shroud to the unit. Use the condenser fan as a guide to ensure the shroud is properly centered around the fan.

18. Remove the condenser fan, and place it on the shaft facing the correct direction. Adjust the fan to the correct position, 37mm (1.5") from the fan shroud, see Figure 7.7.

Figure 7.7 Condenser Fan Position



- 19. Use Loctite "H" on the fan set screws, and tighten.
- 20. Refit left and right infill panels.
- 21. Refit the condenser fan grille, ensuring the grille is properly centered around the condenser fan.
- 22. Evacuate the entire unit. See Section 7.6.
- 23. Recharge the unit with the charge shown on the unit serial plate. See **Section 7.7**. It is important for proper unit operation that the charge is weighed into the unit.

7.11.5 Micro Channel Heat Exchanger (MCHE) Repair Instructions



Before proceeding with the installation, make sure power to the unit is OFF and the power plug is disconnected.



Follow proper lockout / tagout procedures to ensure that the power cannot be inadvertently energized.



Dress with personal protective equipment (PPE) gear before attempting any field repairs. Aluminum fin is extremely sharp. Wear gloves and protective eye wear.

7–13 T-362

Tools Required:

- · Screw driver set
- Standard hand tools
- Needle nose pliers (long nose)
- · 35 degree bent long nose pliers
- Duckbill pliers
- Tube brush (soft bristle)
- · Emery cloth
- Disposable gloves
- · Utility knife
- · Protective goggles
- Vacuum pump
- · Gauge manifold
- Alcohol
- Water

Parts Required:

Item	Part Number	Description	Quantity
	76-00893-00	MCHE Repair Kit	1
1	02-00312-00	3M SCOTCH-WELD DP100 Epoxy B/A Gray	1
2	58-05127-00	Dispensing Gun For 1.69 oz Cartridges	1
3	58-05127-01	Plunger, 1:1 Mix Ratio	1
4	58-05127-02	Mixer Nozzles, 1.69 oz Cartridges	3
5	68-18212-00	Plate, Aluminum	3
6	58-05127-03	Emery Cloth Block-Shaped 180 Grit, 1" x 7"	2
7	58-05127-04	Zip-Press Polyethylene Bag 2 Mil Thick, 2" x 2"	1
8	58-05127-05	Documents Holder, Press to Close, 10" x 8-1/2"	1
9	58-05127-06	Nonmarring Picks, Wood, Flat Tip/Point Tip, 7" Length	1
10	98-02667-00	Instruction Sheet	1

Procedure:

NOTE

This repair is only a limp home repair. The coil should be replaced at the earliest convenience.

1. Locate the suspect leak using an electronic leak detector or liquid soap (looking for bubbles). If required, pressurize the unit with Nitrogen confirming the leak location.

NOTE


When refrigerant escapes, oil that also escapes will typically result in a wet looking area and or heavy concentrations of dirt sticking to oil. These are usually good indicators of where to begin a check.

2. Remove the refrigerant and or any nitrogen used for leak checking from the system.

3. Using a utility knife, carefully section off the area around the leak (approximately 0.5 inches)




4. Using needle nose pliers, carefully remove the fins from the damaged area above and below the tube needing repair. The fins to be removed should be approximately 1/2" of fin material from each side of the repair location.



5. Remove dirt from the surface around the leak point with a soft bristle brush and water. Then wash off any residual oil with alcohol. Allow the surfaces to fully air dry.



6. Open up the leak point to at least 1 mm width by using the tip of a knife carefully. Remove all aluminum fragments. Shape the cut to make it easy for epoxy resin to enter the microchannel.



- 7. Clean the area around the leak point with alcohol.
- 8. Connect the gauge manifold to the HI and LO service valves and evacuate the unit using a vacuum pump.
- 9. Remove the coil coating from the repair area by brushing the upper and lower portion of the tube with the round tube brush.
- 10. Prepare the precut aluminum wrapper by folding it in half along the short (0.75") length.
- 11. Using the emery cloth, remove any rough edges on the upper and lower portion of the tube and also scuff the inside of the aluminum wrapper.

7–15 T-362


12. Prepare the required amount of epoxy resin per instructions on the package and place on the cardboard and replace the cap onto the epoxy container after use.



NOTE

When the temperature is below 10°C (50°F), warm up the affected area prior to the repair using a heat gun. Do not use an open flame.

13. Place mixed epoxy onto the leak point using wooden picks (while the unit is under vacuum).



14. The vacuum pump should be able to pull the epoxy through the cut area to form a shape that works as a plug.



- 15. Apply additional mixed epoxy with the application tool to the leak area and along the cleared fin section. Make sure that resin is sucked into the opening.
- 16. Place mixed epoxy on the aluminum wrapper and place the aluminum wrapper over the leak area.



17. Lightly "crimp" the aluminum wrapper with needle nose pliers.



18. Allow an additional one to two hours for epoxy to cure before leak checking the system.

NOTE

Keep the unit under vacuum until the epoxy is fully cured.

- 19. Repeat the original leak check of the system in step 4 to verify that the leak has been plugged.
- 20. Evacuate and recharge the unit with refrigerant following procedures identified in the unit model Operations & Service Manual.

7.12 Condenser Fan and Fan Motor

The condenser fan rotates counter-clockwise (viewed from front of unit). The fan pulls air through the condenser coil, and discharges the air horizontally through the front of the unit.

7.12.1 Condenser Fan Motor Remove/Replace



Before removing the condenser fan grille, make sure power to the unit is OFF and the power plug is disconnected

- 1. Remove the condenser fan grille, retain all bolts and washers for reuse.
- 2. Remove the condenser fan by loosening the two set screws.
- 3. Disconnect the condenser fan motor wiring.



Take necessary steps (place plywood over coil or use sling on motor) to prevent motor from falling into condenser coil.

- 4. Note the number of shims on each side of the motor as the same configuration will be required to refit the new motor.
- 5. Remove the fan motor mounting hardware and remove motor.
- 6. Loosely mount the new motor using new lock nuts.
- 7. Connect the fan motor wiring to the new fan motor.
- 8. Replace the shims in the same configuration as they were removed.
- 9. Tighten the fan motor mounting bolts to properly secure the motor.
- 10. To make sure that the motor is aligned properly, slide the condenser fan onto the motor shaft reversed but do not secure.
- 11. Rotate the fan to make sure the fan blades do not contact the shroud:
 - a. If the fan motor is misaligned vertically, add or remove shims to align.
 - b. If the fan motor is not properly centered, loosen the mounting bolts, and adjust the motor position on the bracket, and then secure the motor.

7–17 T-362

- 12. Remove the condenser fan, and connect the fan motor wiring to the fan motor.
- 13. Place the condenser fan on the shaft facing the correct direction. Adjust the fan to the correct position, 37mm (1.5") from the fan shroud, see **Figure 7.7**.
- 14. Use Loctite "H" on the fan set screws, and tighten.
- 15. Refit the left and right infill panels.
- 16. Refit the condenser fan grille, ensuring the grille is properly centered around condenser fan.

7.13 Water-Cooled Condenser Cleaning

The water-cooled condenser is of the shell and coil type with water circulating through the cupro-nickel coil. The refrigerant vapor is admitted to the shell side and is condensed on the outer surface of the coil. Rust, scale and slime on the water-cooling surfaces inside of the coil interfere with the transfer of heat, reduce system capacity, cause higher head pressures and increase the load on the system.

By checking the leaving water temperature and the actual condensing temperature, it can be determined if the condenser coil is becoming dirty. A larger than normal difference between leaving condensing water temperature and actual condensing temperature, coupled with a small difference in temperature of entering and leaving condensing water, is an indication of a dirty condensing coil.

If the water-cooled condenser is dirty, it may be cleaned and de-scaled.

7.13.1 Cleaning Supplies Needed

- Oakite Aluminum Cleaner® 164, available as a powder in 20 kg (44 lb) pails and 205 kg (450 lb) drums.
- Oakite Composition No. 32, available as a liquid in cases, each containing 3.785 liters (4 U.S. gallon) bottles and also in carboys of 52.6 kg (116 lbs) net.
- · Fresh clean water.
- Acid proof pump and containers or bottles with rubber hose.

NOTE

When Oakite Compound No. 32 is used for the first time, the local Oakite technical service representative should be called in for suggestions in planning the procedure. The representative will advise the reader on how to do the work with a minimum dismantling of equipment: how to estimate the time and amount of compound required; how to prepare the solution; how to control and conclude the de-scaling operation by rinsing and neutralizing equipment before putting it back into service. The representative's knowledge of metals, types of scale, water conditions and de-scaling techniques will be highly useful.

7.13.2 Cleaning Procedure Summary

- 1. Turn the unit off and disconnect main power.
- 2. Disconnect the water pressure switch tubing by loosening the two flare nuts. Install a 1/4 inch flare cap on the water-cooled condenser inlet tube (replaces tubing flare nut). De-scale tubing if necessary.
- 3. Drain water from the condenser tubing circuit.
- 4. Clean the water tubes with Oakite Aluminum Cleaner® 164 to remove mud and slime.
- 5. Flush.
- 6. De-scale the water tubes with Oakite No. 32 to remove scale.
- 7. Flush.
- 8. Neutralize.
- 9. Flush.
- 10. Put the unit back in service under normal load and check head (discharge) pressure.

7.13.3 Cleaning Procedure Detailed

1. Drain and flush the water circuit of the condenser coil. If scale on the tube inner surfaces is accompanied by slime, a thorough cleaning is necessary before de-scaling process can be accomplished.

- 2. To remove slime or mud, use Aluminum Cleaner® 164. Mix 170 grams (6 ounces) per 3.785 liters (1 U.S. gallon) of water. Mix cleaner in one half the volume of water, while stirring, and then add remaining water. Warm this solution and circulate through the tubes until all slime and mud has been removed.
- 3. After cleaning, flush the tubes thoroughly with fresh clean water.
- 4. Prepare a 15% by volume solution for de-scaling, by diluting Oakite Compound No. 32 with water. This is accomplished by slowly adding 0.47 liter (1 U.S. pint) of the acid (Oakite No. 32) to 2.8 liters (3 U.S. quarts) of water.



Oakite No. 32 is an acid. Be sure that the acid is slowly added to the water. DO NOT PUT WATER INTO THE ACID - this will cause spattering and excessive heat.

⚠ WARNING

Wear rubber gloves and wash the solution from the skin immediately if accidental contact occurs. Do not allow the solution to splash onto concrete.

5. Fill the tubes with this solution by filling from the bottom. See Figure 7.8.

1 12 3 3 5 6 11 10 8

Figure 7.8 Water-Cooled Condenser Cleaning - Forced Circulation

- 1) Pump
- 2) Priming Connection (Centrifugal pump 50 gpm at 35' head)
- 3) Globe valves
- 4) Vent
- 5) Close vent pipe valve when pump is running

- 6) Condenser
- 7) Remove water regulating valve
- 8) Return
- 9) Fine mesh screen
- 10) Pump support
- 11) Tank
- 12) Suction

NOTE

It is important to provide a vent at the top for escaping gas.

6. Allow the Oakite No. 32 solution to soak in the tube coils for several hours, periodically pump-circulating it with an acid-proof pump.

An alternate method may be used whereby a pail (see **Figure 7.9**) filled with the solution and attached to the coils by a hose can serve the same purpose by filling and draining. The solution must contact the scale at every point for thorough de-scaling. Air pockets in the solution should be avoided by regularly opening the vent to release gas. Keep flames away from the vent gases.

7–19 T-362

7. The time required for de-scaling will vary, depending upon the extent of the deposits. One way to determine when de-scaling has been completed is to titrate the solution periodically, using titrating equipment provided free by the Oakite technical service representative. As scale is being dissolved, titrate readings will indicate that the Oakite No. 32 solution is losing strength. When the reading remains constant for a reasonable time, this is an indication that scale has been dissolved.

Fill condenser with cleaning solution. Do not add solution more rapidly than vent can exhaust gases caused by chemical reaction.

1" pipe

Approximately 5'

Condenser

Figure 7.9 Water-Cooled Condenser Cleaning - Gravity Circulation

8. When de-scaling is complete, drain the solution and flush thoroughly with water.

NOTE

If condenser cooling water is not being used as drinking water or is not re-circulated in a closed or tower system, neutralizing is not necessary.

- 9. Following the water flush, circulate a 56.7 gram (2 ounce) per 3.785 liter (1 U.S. gallon) solution of Oakite Aluminum Cleaner® 164 through the tubes to neutralize. Drain this solution.
- 10. Flush the tubes thoroughly with fresh water.
- 11. Put the unit back in service and operate under normal load. Check the head pressure. If normal, a thorough de-scaling has been achieved.

What You Can Do For Further Help:

Contact the Engineering and Service Department of OAKITE PRODUCTS CO., 675 Central Avenue, New Providence, NJ 07974 U.S.A. (or visit www.oakite.com)

7.14 Filter Drier

On units equipped with a water-cooled condenser, if the sight glass appears to be flashing or bubbles are constantly moving through the sight glass, the unit may have a low refrigerant charge or the filter drier could be partially plugged.

7.14.1 Checking the Filter Drier:

- 1. Test for a restricted or plugged filter drier by feeling the liquid line inlet and outlet connections. If the outlet side feels cooler than the inlet side, then the filter drier should be changed.
- 2. Check the moisture-liquid indicator. If it shows a high level of moisture, the filter drier should be replaced.

7.14.2 Replacing the Filter Drier:

1. Pump down the unit (see **Section 7.4**). If the unit is not equipped with service values, evacuate the unit. Then replace filter drier.

- 2. Evacuate the low side in accordance with Section 7.6.
- 3. After unit is in operation, inspect for moisture in the system and check charge.

7.15 Evaporator Coil

The evaporator section, including the evaporator coil, should be cleaned regularly. The preferred cleaning fluid is fresh water or steam. Another recommended cleaner is Oakite 202 or similar, following manufacturer's instructions.

The two drain pan hoses are routed behind the condenser fan motor and compressor. The drain pan line(s) must be open to ensure adequate drainage.

7.15.1 Evaporator Coil Replacement

1. Pump unit down. See Section 7.4.




Always turn OFF the unit circuit breakers (CB-1 & CB-2) and disconnect main power supply before working on moving parts.

- 2. With power OFF and power plug removed, remove the screws securing the panel covering the evaporator section (upper panel).
- 3. Disconnect the defrost heater wiring.
- 4. Remove the mounting hardware from the coil.
- 5. Unsolder the two coil connections, one at the distributor and the other at the coil header.
- 6. Disconnect the defrost temperature sensor (see Section 7.29) from the coil.
- 7. Remove middle coil support.
- 8. After defective coil is removed from unit, remove defrost heaters and install on replacement coil.
- 9. Install coil assembly by reversing above steps.
- 10. Leak check connections. Evacuate and add refrigerant charge.

7.16 Evaporator Heaters

Figure 7.10 Heater Arrangement



1) Heater Element

3) Retainer

2) Bracket

The heaters are wired directly back to the contactor and if a heater failure occurs during a trip, the heater set containing that heater may be disconnected at the contactor.

The next pre-trip (P1) will detect that a heater set has been disconnected and indicate that the failed heater should be replaced.

7–21 T-362

⚠ WARNING

Always turn OFF the unit circuit breakers, disconnect the main power supply, and perform Lock Out / Tag Out before working on moving parts.

All of the checks performed during this procedure should be carried out using a 500v Meg-ohm tester.

- 1. Connect the ground wire from the insulation tester to a fixed ground point, preferably the ground plate in the control box.
- 2. At the load side of the heater contactor, check the insulation resistance to ground.

If readings are > 2 Mohm, then the heaters are operating properly and no action is needed.

<u>If readings are < 1 Mohm</u>, then the faulty heater needs to be identified. Proceed to step 3 for units *with* a heater access panel or step 4 for units *without* a heater access panel.

If readings are between 1 and 2 Mohm, then the heaters need to be re-tested with the following steps:

- a. Reconnect the unit to power and power the unit on.
- b. Set the unit set point to a minimum of 10°C higher than the current temperature of the container. Allow the unit to go into heat mode, reach the temperature set point and maintain for 10-15 minutes.
- c. Power the unit off. Allow the unit to cool to ambient temperature.
- d. Connect the ground wire from the insulation tester to a fixed ground point, preferably the ground plate in the control box.
- e. At the load side of the heater contactor, check the insulation resistance to ground.

<u>If readings are > 1 Mohm</u>, then the heaters are operating properly and no action is needed.

<u>If readings are < 1 Mohm</u>, then the faulty heater needs to be identified. Proceed to step 3 for units with a heater access panel or step 4 for units without a heater access panel.

- 3. Identify the faulty heater(s) for units with a heater access panel:
 - a. Open the access panel and cut out all wire splices to isolate all heaters inside of the unit.
 - b. Repeat the Megger test on each individual heater. Connect the ground clip to the outer metal sheath of the heater and the test clip to one of the wires from the same heater.
 - c. Replace any heater where the readings are < 1 Mohm.
- 4. Identify the faulty heater(s) for units without a heater access panel:
 - a. Remove all six connections from the Heater (HR) contactor load side, which splits the six heaters into three separate pairs.
 - b. Identify the following three wires: DHTL, DHML, DHBL. There is one from each load connection.
 - c. Repeat the Megger test on each pair of heaters to identify the faulty heater pair. Connect the ground clip from the insulation tester to a fixed ground point on the unit, preferably the ground plate in the control box. Connect the test clip to one of the wires stated above.
 - d. Test all three wires and replace any heater pair that has readings < 1 Mohm.
- 5. If the unit is loaded, and the heater can not be immediately replaced, perform the following steps:
 - a. Identify the wire at the opposite end of the faulty heater pair: DHTL DHTR, DHML DHMR, DHBL DHBR.
 - b. Isolate the two wires.
 - c. Reconnect the remaining good wiring pairs to their original connections.
 - d. The unit will fail the PTI test P1-0 at the next pre-trip inspection. Repair action can be taken at that time.
- 6. If the unit is empty, replace the faulty heater:



Always turn OFF the unit circuit breakers, disconnect the main power supply, and perform Lock Out / Tag Out before working on moving parts.

- a. With the heater pair identified, remove the upper back panel inside the container.
- b. Identify the center point connection for the heater pair (black wiring from heaters) either against the unit back wall or in the wiring loom.
- c. Cut the splice to separate the two heaters.
- d. Carry out a Megger check on the two heaters in the same way as for units with heater panel. Replace any heater where the Megger readings are < 1 Mohms.

NOTE

If all heaters are above the acceptable limit with the wiring disconnected, then this indicates that the fault was in one or more of the wire splices that were removed.

- e. Remove the hold-down clamp securing the heater(s) to the coil.
- f. Verify that the heaters are not hot before handling them.
- g. Lift the bent end of the heater (with the opposite end down and away from the coil). Move the heater to the side enough to clear the heater end support and remove.
- h. To install heater, reverse steps.
- i. Reconnect all wiring using new splices and heat shrink where needed. The heat shrink MUST have a 'melt-able' liner to ensure that the connections are properly sealed when shrunk. This can be seen as a 'Ring' of melt liner pushed from under the heat shrink at each end of the shrink tube.

NOTE

Failure to use melt liner heat shrink allows moisture to 'wick' up under the heat shrink and cause a leakage path.

7.17 Evaporator Fan and Motor Assembly

The evaporator fans circulate air throughout the container by pulling air in the top of the unit. The air is forced through the evaporator coil where it is either heated or cooled and then discharged out the bottom of the refrigeration unit into the container. The fan motor bearings are factory lubricated and do not require additional grease.

7.17.1 Replacing the Evaporator Fan Assembly



Always turn OFF the unit circuit breakers (CB-1 & CB-2) and disconnect main power supply before working on moving parts.

- 1. Remove the access panel by removing the mounting bolts and TIR locking device. Reach inside of the unit and remove the Ty-Rap securing the wire harness loop. Disconnect the connector by twisting to unlock and pulling to separate.
- 2. Loosen four 1/4-20 clamp bolts that are located on the underside of the fan deck at the sides of the fan assembly. Slide the loosened clamps back from the fan assembly.
- 3. Slide the fan assembly out from the unit and place on a sturdy work surface.

7.17.2 Disassemble the Evaporator Fan Assembly

- 1. Attach a spanner wrench to the two 1/4-20 holes located in the fan hub. Loosen the 5/8-18 shaft nut by holding the spanner wrench stationary and turning the 5/8-18 nut counter-clockwise (see Figure 7.11).
- 2. Remove the spanner wrench. Use a universal wheel puller and remove the fan from the shaft. Remove the washers and key.

7–23 T-362

3. Remove the four 1/4-20 x 3/4 long bolts that are located under the fan that support the motor and stator housing. Remove the motor and plastic spacer.

7.17.3 Assemble the Evaporator Fan Assembly

1. Assemble the motor and plastic spacer onto the stator.

NOTE

When removing the black nylon evaporator fan blade, care must be taken to assure that the blade is not damaged. In the past, it was a common practice to insert a screwdriver between the fan blades to keep it from turning. This practice can no longer be used, as the blade is made up of a material that will be damaged. It is recommended that an impact wrench be used when removing the blade. Do not use the impact wrench when reinstalling, as galling of the stainless steel shaft can occur.

- 2. Apply Loctite to the 1/4-20 x 3/4 long bolts and torque to 0.81 mkg (70 inch-pounds).
- 3. Place one 5/8 flat washer on the shoulder of the fan motor shaft. Insert the key in the keyway and lubricate the fan motor shaft and threads with a graphite-oil solution (such as Never-seez).
- 4. Install the fan onto the motor shaft. Place one 5/8 flat washer with a 5/8-18 locknut onto the motor shaft and torque to 40 foot-pounds.




Figure 7.11 Evaporator Fan Assembly

- 2) Washer
- 3) Nut
- 4) Screws / Washers


- 6) Motor
- Stator

5. Install the evaporator fan assembly in reverse order of removal. Torque the four 1/4-20 clamp bolts to 0.81 mkg (70 inch-pounds). Connect the wiring connector.

6. Replace the access panel making sure that the panel does not leak. Make sure that the TIR locking device is lockwired. Torque the access panel hardware to 69 kg-cm (60 in/lbs.) using a crossing pattern as shown in Figure 7.12. Repeat the pattern twice for a proper seal.

T-362 7-24

Figure 7.12 Access Panel Torque Pattern



7.18 Evaporator Section Cleaning

Containers and Container units that are exposed to certain fumigants may develop visible surface corrosion. This corrosion will show up as a white powder found on the inside of the container and on the reefer unit evaporator stator and fan deck.

Analysis by Carrier Transicold environmental specialists have identified the white powder as consisting predominantly of aluminum oxide. Aluminum oxide is a coarse crystalline deposit most likely the result of surface corrosion on the aluminum parts within the container. If left untreated over time, it may build up in thickness and eventually flake as a light-weight white powder.

The surface corrosion of aluminum is brought about by exposure to chemicals such as sulfur dioxide and possibly other fumigants that are commonly used for fumigation and protection of some perishable cargo such as grapes, for example. Fumigation is the process by which a chemical is released into an enclosed area to eliminate infestations of insects, termites, rodents, weeds and soil-born disease.

Typically any aluminum oxide that becomes detached from evaporator fan stators will be blown into the wet evaporator coil where it will be caught and then flushed out of the unit during routine defrost cycles.

However, it is still highly recommended that after carrying cargo subject to fumigation procedures, that the inside of the unit be thoroughly cleansed prior to reuse.

Carrier Transicold has identified a fully biodegradable and environmentally safe alkaline cleaning agent (Tri-Pow'r® HD) for the unit. This will assist in helping to remove the corrosive fumigation chemicals and dislodging of the corrosive elements.

This cleaner is available from the Carrier Transicold Performance Parts Group (PPG) and can be ordered through any of the PPG locations; Part Number NU4371-88.

As a general safety precaution, before using this product, see and retain the Material Safety Data (MSDS) sheet.

7.18.1 Cleaning Preparation

- Always wear goggles, gloves and work boots.
- · Avoid contact with skin and clothing, and avoid breathing mists.
- When mixing, add water to the sprayer first, then the cleaner.
- ALWAYS provide for proper ventilation when cleaning indoor evaporator coils (rear doors must be open).
- Be aware of surroundings food, plants, etc., and the potential for human exposure.
- Always read directions and follow recommended dilution ratios. More is not always better. Using non-diluted cleaner is not recommended.

7–25 T-362

7.18.2 Cleaning Procedure

- 1. Remove the upper evaporator access panel inside of the unit.
- 2. Spray the surface with water before applying the cleaning solution. This helps the cleaner work better.
- 3. Liberally apply the prepared cleaner solution (5 parts water and 1 part cleaner).
- 4. Allow the cleaner to soak in for five to seven minutes.
- 5. Assess area for rinsing. Follow all local regulations regarding disposal of waste water.
- 6. Thoroughly rinse the cleaner and surrounding area, floor, etc. When rinsing where heavy foaming solution is present, it is very important to take the time to thoroughly rinse the equipment and surroundings.
- 7. Always rinse the empty coil cleaner bottle, cap tightly and dispose of properly.

7.19 Electronic Expansion Valve (EEV)

The electronic expansion valve (EEV) is an automatic device which maintains required superheat of the refrigerant gas leaving the evaporator. The valve functions are: (a) automatic response of refrigerant flow to match the evaporator load and (b) prevention of liquid refrigerant entering the compressor. Unless the valve is defective, it seldom requires any maintenance.




Figure 7.13 Electronic Expansion Valve (EEV)

7.19.1 Removing an EEV



Always turn OFF the unit circuit breakers (CB-1 & CB-2) and disconnect main power supply before working on moving parts.

- 1. Pump down the compressor (see Section 7.4) and frontseat both suction and discharge valves.
- 2. Turn unit power off and remove power from the unit.
- 3. Remove the coil.
- 4. Remove the valve. The preferred method of removing the valve is to cut the connection between the brazed section and the valve, using a small tube cutter. Remove the valve. Alternatively, use a wet rag to keep the valve cool. Heat inlet and outlet connections to valve body and remove valve.
- 5. Clean the valve stem with mild cleaner, if necessary.

7.19.2 Installing an EEV

- 1. Install the valve and a new strainer with the cone of the strainer / screen pointing into the liquid line at the inlet to the valve.
- 2. During installation, make sure the EEV coil is snapped down fully, and the coil retention tab is properly seated in one of the valve body dimples. Also, ensure that coil boot is properly fitted over valve body. See Figure 7.13.
- 3. Replace the filter drier.
- 4. Evacuate to 500 microns by placing the vacuum pump on the liquid line and suction service valve.
- 5. Open the liquid line service valve and check refrigerant level.
- 6. Check superheat. See Section 3.2.
- 7. Check unit operation by running a pre-trip. See Section 4.6.

7.20 Humidity Sensor (HS)

The humidity sensor is an optional component that allows setting of a humidity set point in the controller. In dehumidification mode, the controller will operate to reduce internal container moisture level. When the sensor is disabled, it will be added as an event in the DataLINE report.

7.20.1 Disabling the Humidity Sensor

If a humidity sensor fails and is not going to be replaced, the sensor operation can be disabled at the unit display. Once disabled, any related alarms will be masked and PTI tests will be skipped.

- 1. Press the CODE SELECT key.
- 2. Use the Arrow keys until Cd33 is displayed and then press the ENTER key.
- 3. Use the Arrow keys to select "diSbl" and press ENTER. This sets the configuration variable CnF04 to OFF.
- 4. It is recommended to unplug the humidity sensor from the unit (capping off the sensor plug). This is essential as the humidity sensor shares the power source with other components.

7.20.2 Checking the Operation of the Humidity Sensor (HS)

This procedure is to be performed in an effort to ease the troubleshooting of the humidity sensor. When performing this procedure and while working on the unit, always follow the proper lockout/tagout procedures.

Items Required:

- One 7/16" socket wrench or nut driver.
- One 1/4" socket wrench or nut driver.
- One clean, clear water bottle with a minimum 6 cm (2.5 in) opening and capacity to hold 500 ml (16.9 oz).
- 100 ml (3.4 oz) of fresh water distilled if available.
- 50 gm of Salt (NaCl).

Procedure:

- 1. Remove the left Upper Fresh Air Makeup Vent panel.
- 2. Remove the humidity sensor from the mounting hardware and bring to the front of the access panel.
- 3. Disconnect the humidity sensor from the harness.
- 4. Drill a 3 cm (1.25 in) hole in the cap of a bottle.
- 5. Pour approximately 100 ml (3.4 oz) of water into the empty clean bottle.
- 6. Add salt to the water until it is present at the bottom of the bottle.
- 7. Cap the bottle and tape over the drilled hole.
- 8. Shake the bottle until the salt dissolves and water is saturated.

NOTE


To ensure saturation, add additional salt until it settles at the bottom without dissolving while shaking.

7–27 T-362

9. Remove the cap and insert the humidity sensor into the bottle through the bottle opening and pull the connector back through the drilled hole in the cap. Then, secure the cap and seal the wire going through the cap.

NOTE


Make sure that the sensor is not at all in contact with the salt water.



- 10. Allow the saturated salt mixture to settle for approximately ten minutes.
- 11. Reconnect the humidity sensor to the harness and power the reefer unit on.
- 12. Press the CODE SELECT key on the keypad.
- 13. Use the Arrow keys until "Cd17" is displayed then press the ENTER key.




- 14. This displays the humidity sensor reading. Verify the reading is between 60% and 85% relative humidity.
- 15. If the humidity sensor display is outside of this range, reconfirm the salt mixture and retest. If not in range, replace the sensor at the next opportunity.
- 16. Wipe clean and reinstall the humidity sensor and access panel. Torque the access panel hardware to 69 kg-cm (60 in.-lbs.) using a crossing pattern similar to the numbering below.



- 17. If the panel gasket is damaged and needs to be replaced, use the following part numbers:
 - · 42-00296-01: Standard Panel Gasket
 - 42-00823-00: XtendFRESH Panel Gasket

7.21 Economizer Solenoid Valve (ESV)

Figure 7.14 Coil View of Economizer Solenoid Valve (ESV)



- 1) Slotted Screw
- 2) Top Coil (small) O-ring
- Solenoid Coil, Enclosing Tube and Body

- 4) Bottom Coil (large) O-ring
- 5) Brass Spacer

7.21.1 Removing a Solenoid Valve Coil



Always turn OFF the unit circuit breakers (CB-1 & CB-2) and disconnect main power supply before working on moving parts.

- 1. Turn unit power off and remove power from the unit. Disconnect leads.
- 2. Remove the top screw and o-ring. Remove the coil and save mounting hardware, seals and spacer for reuse (see Figure 7.14). See Valve Coil Installation Procedure.

7.21.2 Removing the Solenoid Valve

- 1. Pump down the compressor (see Section 7.4) and frontseat both suction and discharge valves.
- Remove the valve. The preferred method of removing the solenoid valve is to cut the connection between the brazed section and the valve, using a small tube cutter. Remove valve.
 Alternatively, heat inlet and outlet connections to valve body and remove valve.
- 3. Clean the valve stem with mild cleaner, if necessary.

7.21.3 Installing the Solenoid Valve

1. Fit the new solenoid valve into position and braze. Use a wet rag to keep valve cool whenever brazing.

7.21.4 Installing the Solenoid Valve Coil

- 1. Install the brass spacer on the valve stem.
- 2. Lubricate both o-rings with silicone provided in the kit.
- 3. Install bottom coil o-ring on the valve stem.
- 4. Install the solenoid coil on the valve stem.
- 5. Place the top coil o-ring on the coil mounting screw and secure the coil to the valve using a torque wrench. Torque the screw to 25 in-lbs.
- 6. Connect coil wires using butt-splices and heat shrink tubing.

7–29 T-362

7.22 Economizer Expansion Valve (EXV)

The economizer expansion valve (See **Figure 7.15**) is an automatic device that maintains constant superheat of the refrigerant gas leaving at the point of bulb attachment, regardless of suction pressure.

Unless the valve is defective, it seldom requires maintenance other than periodic inspection to ensure that the thermal bulb is tightly secured to the suction line and wrapped with insulating compound.

NOTE

The economizer expansion valve is a hermetic valve, it does not have adjustable superheat.




Figure 7.15 Economizer Expansion Valve

7.22.1 Removing the Economizer Expansion Valve

- 1. Pump down the compressor (see Section 7.4) and frontseat both suction and discharge valves. If unit is not equipped with service valves, evacuate unit. See Section 7.6.1.
- 2. Turn unit power off and remove power from the unit.
- 3. Remove cushion clamps located on the inlet and outlet lines.
- 4. Remove insulation (Presstite) from the expansion valve bulb.
- 5. Unstrap the bulb, located on the economizer line.
- 6. Remove the valve. The preferred method of removing the valve is to cut the connection between the brazed section and the valve, using a small tube cutter. Remove valve. Alternatively, use a wet rag to keep valve cool. Heat inlet and outlet connections to valve body and remove valve.
- 7. Clean the valve stem with a mild cleaner, if necessary.

7.22.2 Installing the Economizer Expansion Valve

- 1. The economizer expansion valve should be wrapped in a soaked cloth for brazing.
- 2. Braze the inlet connection to the inlet line.
- 3. Braze the outlet connection to the outlet line.
- 4. Reinstall the cushion clamps on the inlet and outlet lines.
- 5. Replace the filter drier. See Section 7.14.
- 6. Evacuate to 500 microns by placing vacuum pump on liquid line and suction service valve.
- 7. Check economizer expansion valve superheat. See Section 3.2.

7.23 Troubleshooting P6-7 (DUV)


A failed digital unloader valve (DUV), which is normally closed, or an internal seal failure of the compressor can result in the unit running continually in the fully loaded mode causing it to undershoot its setpoint temperature.

Both of these conditions can be evaluated by running pre-trip test P6-7. When running P6-7, the controller is looking for the differences in pressure and current draw between loaded mode and unloaded mode to make a judgment. If there are no differences, then it will show fail.

To confirm what caused the test to fail, perform the following additional test.

- 1. Connect the manifold gauge set to discharge service valve (DSV) and suction service valve (SSV).
- 2. Front seat the SSV and pump down the compressor.
- 3. Front seat the DSV valve to isolate the compressor.
- 4. Disconnect the DUV from the top of compressor and install a 1/2 to 1/4 flared adapter / O-ring (P/N 40-50076-00sv).

Figure 7.16 Adapter and O-Ring



- 5. Using refrigerant (R-134a or R-513A as specified for the unit model number) or Nitrogen, pressurize the line to 50 psi (3.5 bar) at the adapter connection and close supply at the tank. Pressure should hold as the valve is normally closed. If pressure drops, check for leaks at the installed fitting (part number 40-50076-00sv); repair and retest. If pressure increases at the suction service valve and decreases at the pressure supply; the valve is leaking and should be replaced. If no leak proceed to step 6.
- 6. Energize the DUV by removing the coil and placing a magnet on the valve stem opening the valve. If the pressure does not increase at the SSV and decrease at the supply, replace the valve as it did not open.

If a magnet is not available, a jumper procedure can be used as follows:

- 1. Remove all four controller fuses (F1, F2, F3a, F3b).
- 2. Remove the KA6 wire from the KA controller connector on the front of the controller.
- 3. Disconnect the X1 wire from the 24VAC side of the transformer (black wire) and locate it away from the transformer.
- 4. Jumper between the black transformer wires to the KA6 wire removed from the connector.
- 5. Connect power to the unit and turn the circuit breaker on. The DUV coil is now energized.
- 6. Pressure should drop.
- 7. Power the circuit breaker off, reconnect wires and reinstall fuses.
- 8. If the valve opens and closes properly, the failure mode is with the compressor and it should be changed at the earliest opportunity.

7.24 Digital Unloader Valve (DUV)

7.24.1 Removing the DUV

1. Pump down the compressor (see Section 7.4) and frontseat both suction and discharge valves. In the event the DUV is stuck open and compressor cannot pump down, remove charge.



The scroll compressor achieves low suction pressure very quickly. Do not use the compressor to evacuate the system below 0 psig. Never operate the compressor with the suction or discharge service valves closed (frontseated). Internal damage will result from operating the compressor in a deep vacuum.

2. Turn unit power off and remove power from the unit.

7–31 T-362

3. Loosen the bolt on top of the DUV and remove the coil assembly.


NOTE

There is a small spacer tube between the top of the valve and the 12 VDC coil that needs to be reinstalled into the solenoid valve coil. When removing the coil, it may fall out when lifted from the valve body. Take care that the spacer is not lost; the valve will not function correctly without it.

- 4. Remove the clamps holding the DUV to the discharge line.
- 5. Loosen the nuts attaching the DUV to the top of the compressor.
- 6. Remove the valve. The preferred method of removing the solenoid valve is to cut the connection between the brazed section and the valve, using a small tube cutter. Remove valve. (See Figure 7.17).

 Alternatively, use a wet rag to keep valve cool. Heat outlet connection to valve body and remove valve.

Figure 7.17 View of Digital Unloader Valve (DUV) Assembly



- 1) Screen Valve Strainer
- 2) Tube
- 3) Solenoid Valve Body

- 4) Hex Nut, 1/2 OD
- 5) Sleeve
- 6) O-ring (hidden)
- 7. Examine the compressor and service valves. Ensure that the o-ring is not stuck in the gland of the valve.
- 8. Discard the o-ring on the o-ring face seal connection.

7.24.2 Installing the DUV

- 1. Lubricate the gland shoulder area and o-ring with refrigerant oil.
- 2. Fit the new valve in position and hand-tighten the o-ring nut.
- 3. Use a wet rag to keep the valve cool while brazing. Braze the DUV to service valve connection.
- 4. Reinstall and tighten the brackets that secure the valve body to the discharge line.
- 5. Torque the o-ring face seal connections to 18 to 20 ft-lbs.
- 6. Install the coil onto the valve body and tighten the attachment bolt.

NOTE

Confirm that the small spacer tube is inserted into the coil prior to attaching it to the valve body. The valve will not function correctly without it.

- 7. Leak check and evacuate the low side of unit as applicable. See Section 7.6.1.
- 8. Open the service valves.

7.25 Valve Override Controls

Controller function code Cd41 is a configurable code that allows timed operation of the automatic valves for troubleshooting. Test sequences are provided in **Table 7–1**. Capacity mode (CAP) allows alignment of the economizer solenoid valve in the standard and economized operating configurations. DUV Capacity Modulation% Setting (PCnt) and Electronic Expansion Valve (EEV) allows opening of the digital unloader valve and electronic expansion valve, respectively, to various percentages. If the unit is equipped with an LIV, the Liquid Valve Setting allows the LIV to be automatically controlled, or manually opened and closed.

The Override Timer (tIM) selection is also provided to enter a time period of up to five minutes, during which the override(s) are active. If the timer is active, valve override selections will take place immediately. If the timer is not active, changes will not take place for a few seconds after the timer is started. When the timer times out, the override function is automatically terminated and the valves return to normal machinery control. To operate the override:

- 1. Press the CODE SELECT key then press an Arrow key until Cd41 is displayed in the left window. The right window will display a controller communications code.
- 2. Press the ENTER key. The left display will show a test name alternating with the test setting or time remaining. Use an Arrow key to scroll to the desired test. Press the ENTER key, SELCt will appear in the left display.
- 3. Use an Arrow key to scroll to the desired setting, and then press the ENTER key. Selections available for each of the tests are provided in Table 7–1.
- 4. If the timer is not operating, follow the above procedure to display the timer. Use an Arrow key to scroll to the desired time interval and press ENTER to start the timer.
- 5. The above described sequence may be repeated during the timer cycle to change to another override.

Table 7-1 Valve Override Control Displays

Left Display	Controller Communication Codes (Right Display)	Setting Codes (Right Display)
	tIM (Override Timer)	0 00 (0 minutes/0 Seconds) In 30 second increments to 5 00 (5 minutes/ 0 seconds)
	PCnt (% Setting - DUV Capacity Modulation)	AUtO (Normal Machinery Control) 0 3 6 10 25 50 100
Cd 41/SELCt	EEV (% Setting - Electronic Expansion Valve)	AUtO (Normal Machinery Control) CLOSE (Closed) 0 3 6 10 25 50 100
	CAP (Capacity Mode)	AUtO (Normal Control) Std UnLd (Economizer = Closed) ECOn (Economizer = Open)


7.26 Autotransformer

If the unit does not start, check the following:

- 1. Verify the 460 VAC (yellow) power cable is plugged into the receptacle (see Figure 7.18) and locked in place.
- 2. Verify that circuit breakers CB-1 and CB-2 are in the "ON" position. If the circuit breakers do not hold in, check voltage supply.
- 3. Using a voltmeter, and with the primary supply circuit ON, check the primary (input) voltage (460 VAC). Next, check the secondary (output) voltage (230 VAC). The transformer is defective if output voltage is not available.

7–33 T-362

Figure 7.18 Autotransformer



- 1) Circuit Breaker (CB-2) 230-Volt
- 2) 460 VAC Power Receptacle

3) Dual Voltage Modular Autotransformer

7.27 Controller Service



Do not remove wire harnesses from circuit boards unless you are grounded to the unit frame with a static safe wrist strap or equivalent static drain device.



Remove the controller module and unplug all connectors before performing any arc welding on any part of the container.



Do not attempt to use an ML2i PC card in an ML3 equipped unit. The PC cards are physically different and will result in damage to the controller.

NOTE

Do not attempt to service the controller modules. Breaking the seal will void the warranty.

7.27.1 Controller Module Handling

The guidelines and cautions provided herein should be followed when handling the modules. These precautions and procedures should be implemented when replacing a module, when doing any arc welding on the unit, or when service to the refrigeration unit requires handling and removal of a module.

- 1. Obtain a grounding wrist strap (Carrier Transicold P/N 07-00304-00) and a static dissipation mat (Carrier Transicold P/N 07-00277-00). The wrist strap, when properly grounded, will dissipate any potential static buildup on the body. The dissipation mat will provide a static-free work surface on which to place and/or service the modules.
- 2. Disconnect and secure power to the unit.
- 3. Place strap on wrist and attach the ground end to any exposed unpainted metal area on the refrigeration unit frame (bolts, screws, etc.).
- 4. Carefully remove the module. Do not touch any of the electrical connections if possible. Place the module on the static mat.

NOTE

The strap should be worn during any service work on a module, even when it is placed on the mat.

7.27.2 Controller Troubleshooting

A group of test points (TP, see Figure 7.19) are provided on the controller for troubleshooting electrical circuits (see schematic diagram sections). A description of the test points is provided in Table 7–2.

Table 7-2 Test Point Descriptions

Test Point	Description
TP1	Not used in this application.
TP2	Check if the high pressure switch (HPS) is open or closed.
TP3	Check if the water pressure switch (WP) contact is open or closed.
TP4	Check if the internal protector for the condenser fan motor (IP-CM) is open or closed.
TP5	Check if the internal protectors for the evaporator fan motors (IP-EM1 or IP-EM2) are open or closed.
TP6	(if equipped) - Check if the controller liquid injection valve relay (TQ) is open or closed.
TP7	Check if the controller economizer solenoid valve relay (TS) is open or closed.
TP8	Not used in this application.
TP9	Chassis (unit frame) ground connection.
TP10	Check if the heat termination thermostat (HTT) contact is open or closed.

NOTE

Use a digital voltmeter to measure AC voltage between TP's and ground (TP9), except for TP8.




Figure 7.19 Controller

- Micro-Link 3 Controller / DataCORDER Module
- 2) Mounting Screw
- 3) Connectors
- 4) Test Points

- 5) Fuses
- 6) Control Circuit Power Connection
- 7) Software Programming Port
- 8) Battery Pack (Standard Location)

7–35 T-362

7.27.3 Removing and Installing a Controller

Removal:

- 1. Disconnect all front wire harness connectors and move wiring out of the way.
- 2. The lower controller mounting is slotted. Loosen the top mounting screw (see Figure 7.19) and lift up and out.
- 3. Disconnect the back connectors and remove the module.
- 4. When removing the replacement module from its packaging, note how it is packaged. When returning the old module for service, place it in the packaging in the same manner as the replacement. The packaging has been designed to protect the module from both physical and electrostatic discharge damage during storage and transit.

Installation:

- 1. Install the module by reversing the removal steps.
- 2. Torque values for mounting screws (item 2, see Figure 7.19) are 0.23 mkg (20 inch-pounds). Torque value for the connectors is 0.12 mkg (10 inch-pounds).

7.27.4 Battery Replacement

Standard Battery Location (Standard Cells):

- 1. Turn unit power Off and disconnect the power supply.
- 2. Slide the bracket out and remove the old batteries. (See Figure 7.19, Item 8.)
- 3. Install new batteries and slide the bracket into the control box slot.



Use care when cutting wire ties to avoid nicking or cutting wires.

Standard Battery Location (Rechargeable Cells):

- 1. Turn unit power Off and disconnect the power supply.
- 2. Disconnect the battery wire connector from the control box.
- 3. Slide out and remove the old battery and bracket. (See Figure 7.19, Item 8.)
- 4. Slide the new battery pack and bracket into the control box slot.
- 5. Reconnect the battery wire connector to the control box and replace wire ties that were removed.

Secure Battery Option (Rechargeable Cells Only):

- 1. Turn unit power Off and disconnect the power supply.
- 2. Open the control box door and remove both the high voltage shield and clear plastic rain shield (if installed).
- 3. Disconnect the battery wires from the "KA" plug positions 14, 13, 11.
- 4. Using Driver Bit, Carrier Transicold part number 07-00418-00, remove the four screws securing the display module to the control box. Disconnect the ribbon cable and set the display module aside.

NOTE

The battery wires must face toward the right.

- 5. Remove the old battery from the bracket and clean bracket surface. Remove the protective backing from the new battery and assemble to the bracket. Secure battery by inserting the wire tie from the back of the bracket around the battery, and back through the bracket.
- 6. Reconnect the ribbon cable to display and re-install the display.
- 7. Route the battery wires from the battery along the display harness and connect the red battery wire and one end of the red jumper to "KA14," the other end of the red jumper wire to "KA11," and the black wire to "KA13."
- 8. Replace wire ties that were removed.

7.28 Controller Programming Procedures

This section contains programming procedures for data downloads, software loading, and configuration changes. These are performed by using the unit display and the controller's programming port (See Figure 7.19).

Videos are available that explain different programming procedures and methods for using the programming port. The videos can be viewed from:

- Carrier Transicold's Container Refrigeration YouTube channel.
- Carrier Transicold's ContainerLINK™ app that is available for Apple or Android devices. In ContainerLINK, from the main menu navigate to Resources > Videos.

The following hardware solutions can be utilized with the programming port:

- MUA Adapter with USB drive (Part # 07-00571-00). Click for instructions
- MST Service Tool with USB drive (Part # 07-00-00572-00). Click for instructions
- USB Adapter and USB drive**. Click for instructions
- PCMCIA sRAM Card**

^{**} Device still supported but no longer available for purchase.



The unit must be OFF whenever a programming device is inserted or removed from the controller programming port.

7.28.1 Downloading Unit Data

- 1. Turn unit power off ("0") at the Start-Stop switch (ST).
- 2. Inspect the pins on the controller's programming slot for damage.
- 3. Insert the programming device (with proper software loaded) into the slot. See Figure 7.19
- 4. Turn unit power on ("I") at the Start-Stop switch (ST).
- 5. The display will show "Usb LOAd". Use the Arrow keys to select "dnLd dAtA" and press the ENTER key.

NOTE

For PCMCIA sRAM cards, the display will open directly to the "dnLd dAtA" menu.

- 6. Use the Arrow keys to scroll through the download options (triP, 30 day, 60 day, 90 day, All). The amount of available space on the USB is also displayed in this menu. Press ENTER to confirm the download choice.
- 7. The display will flash "dnLd" while downloading and then "dnLd donE" when complete.
- 8. Press the CODE SELECT key to see free space remaining.
- 9. Turn unit power off ("0") at the Start-Stop switch (ST).
- 10. Remove the programming device from the controller. The download files can now be transferred to PC for data evaluation with DataLINE.
- 11. Turn unit power on ("I") at the Start-Stop switch (ST).

7.28.2 Loading Operational Software

PrimeLINE units must be loaded with software version 53XX. See the label in the control box door for factory installed software version.

- 1. Turn unit power off ("0") at the Start-Stop switch (ST).
- 2. Inspect the pins on the controller's programming slot for damage.
- 3. Insert the programming device (with proper software loaded) into the slot. See Figure 7.19.
- 4. Turn unit power on ("I") at the Start-Stop switch (ST).
- 5. The display will show "Usb LOAd". Use the arrow keys to select "LOAd SoFt" and press the ENTER key. The display will show "SEt UP".

7–37 T-362

NOTE

For PCMCIA sRAM cards, the display will show "SEt UP" when unit turns on.

- 6. Use the Arrow keys until the display shows "LOAd 53XX" and press the ENTER key.
- 7. The display will alternate between the messages "PrESS EntR" and "rEV 53XX". Press ENTER.
- 8. The display will flash "Pro SoFt" as the software is uploading. It may take up to one minute for this to complete. When complete, the display will show "Pro donE".

NOTE

If a problem occurs while loading software, the display will blink the message "Pro FAIL" or "bad 12V." Turn unit power off "0" at the Start-Stop switch and remove the card.

- 9. Turn unit power off ("0") at the Start-Stop switch (ST).
- 10. Remove the programming device from the controller.
- 11. Turn unit power on ("I") at the Start-Stop switch (ST).
- 12. On power up, the controller LED flashes quickly and the display will remain blank as the controller loads the new software. This takes about 15 seconds. When complete, the controller will reset and power up normally.
- 13. Bring up function code Cd18 to confirm that the correct software revision is loaded.

7.28.3 Changing Controller Configuration

- 1. Turn unit power off ("0") at the Start-Stop switch (ST).
- 2. Inspect the pins on the controller's programming slot for damage.
- 3. Insert the programming device (with proper software loaded) into the slot. See Figure 7.19.
- 4. Turn unit power on ("I") at the Start-Stop switch (ST).
- 5. The display will show "Usb LOAd". Use the Arrow keys to select "LOAd SoFt" and press the ENTER key. The display will show "SEt UP".

NOTE

For PCMCIA sRAM cards, the display will show "SEt UP" when unit turns on.

- 6. Press the ENTER key on the keypad.
- 7. The display will show the message "ruN ConFG". Press the ENTER key.

NOTE

If the display has blinking message "bAd CArd", then the card is defective. Turn unit power off "0" at the Start-Stop switch (ST) and remove the card.

- 8. The display module will go blank briefly and then display "5XX XXX", based on the operational software installed.
- 9. Use the Arrow keys to display the desired model number and then press ENTER.
- 10. When software loading has successfully completed, the display will show the message "COnFG donE."

NOTE

If the display has blinking message "Pro FAIL" or "bad 12V", then a problem has occurred while loading the software. Turn unit power off "0" at the Start-Stop switch and remove the card.

- 11. Turn unit power off ("0") at the Start-Stop switch (ST).
- 12. Remove the programming device from the controller.
- 13. Turn unit power on ("I") at the Start-Stop switch (ST).
- 14. To confirm the correct model configuration was loaded, use the keypad to bring up function code Cd20. The model displayed should match the last five digits of the model number listed on the unit nameplate.

7.28.4 Setting the Date and Time

- 1. Turn unit power off ("0") at the Start-Stop switch (ST).
- 2. Inspect the pins on the controller's programming slot for damage.
- 3. Insert the programming device (with proper software loaded) into the slot. See Figure 7.19.
- 4. Turn unit power on ("I") at the Start-Stop switch (ST).
- 5. The display will show "Usb LOAd". Use the Arrow keys to select "LOAd SoFt" and press the ENTER key. The display will show "SEt UP".

NOTE

For PCMCIA sRAM cards, the display will show "SEt UP" when unit turns on.

- 6. Press the ENTER key on the keypad.
- 7. The display will show the message "ruN ConFG".
- 8. Use the Arrow keys to display "SEt tIM" and then press ENTER.
- 9. The display will show the date in YYYY MM-DD format. The day value will be blinking.
- 10. The date values are modified from right to left. Use the Arrow keys to increase or decrease the values. Press the ENTER key to confirm the value for the current field and move to the next value. Press the CODE SELECT key to modify the previous value.
- 11. After pressing ENTER to confirm the year value, the time will be displayed in HH MM format with the hours being in a 24 hour format. The minutes will be blinking.
- 12. The time values are modified from right to left. Use the Arrow keys to change the values. Press the ENTER key to confirm the value for the current field and move to the next value. Press the CODE SELECT key to modify the previous value.
- 13. After pressing ENTER to confirm the hour value, the display will return to "SEt tIM".
- 14. Turn unit power off ("0") at the Start-Stop switch (ST).
- 15. Remove the programming device from the controller.
- 16. Turn unit power on ("I") at the Start-Stop switch (ST).

7.28.5 Setting the Container ID

NOTE

The characters will be preset to the container ID already on the controller. If none exist, the default will be AAAA0000000.

- 1. Turn unit power off ("0") at the Start-Stop switch (ST).
- 2. Inspect the pins on the controller's programming slot for damage.
- 3. Insert the programming device (with proper software loaded) into the slot. See Figure 7.19.
- 4. Turn unit power on ("I") at the Start-Stop switch (ST).
- 5. The display will show "Usb LOAd". Use the Arrow keys to select "LOAd SoFt" and press the ENTER key. The display will show "SEt UP".

NOTE

For PCMCIA sRAM cards, the display will show "SEt UP".

- 6. Press the ENTER key on the keypad.
- 7. The display will show the message "ruN ConFG"
- 8. Use the Arrow keys to display "SEt Id" and then press ENTER.
- 9. The display will show the first letter of the container ID.
- 10. Use the Arrow keys to change the values. Press ENTER to confirm a value for the current field and move to the next value. Press the CODE SELECT key to modify a previous value.

7–39 T-362

- 11. When the last value is entered, press ENTER to enter the information to the controller. The display will return to "SEt Id".
- 12. Turn unit power off ("0") at the Start-Stop switch (ST).
- 13. Remove the programming device from the controller.
- 14. Turn unit power on ("I") at the Start-Stop switch
- 15. To confirm that the correct container ID was loaded, use the keypad to bring up function code Cd40.

7.29 Temperature Sensor Service

Service procedures for the return recorder (RRS), return temperature (RTS), supply recorder (SRS), supply temperature (STS), ambient temperature (AMBS), defrost temperature (DTS), evaporator temperature (ETS), and compressor discharge temperature (CPDS) sensors are provided here.

7.29.1 Ice Bath Preparation

The ice-water bath is a method for testing the accuracy of sensors by submerging the sensors in an insulated container with ice cubes or chipped ice, then filling voids between ice with water and agitating until mixture reaches 0°C (32°F) measured on a laboratory thermometer.

Notes:

- Wherever possible, use a thermometer that is regularly calibrated by an accredited test lab. Contact your instrument representative if the reference thermometer is not showing correct readings.
- Always use a temperature measurement reference instrument which is of higher accuracy than the device checked – for e.g., a thermometer with a rated accuracy of +/- 0.2 °C should be used to check a device with a rated accuracy +/- 0.3 °C.
- A thermally insulated container, tub open to atmosphere and large enough to contain crushed ice and water should be used. The tub should be large enough to contain the unit's sensor and the reference thermometer.
- Enough distilled water should be available to make ice cubes and to set up a proper and stable ice-water triple-point mixture. Prepare ice using distilled water.
- Pre-cool distilled water for testing.

Procedure:

- 1. Prepare a mixture of clean ice using distilled water in a clean insulated container. If possible, the person handling should be wearing latex gloves.
 - a. Crush or chip the ice to completely fill the container. The finer the ice particles, the more accurate the mixture.
 - b. Add enough pre-cooled distilled water to fill the container.
 - c. Stir the mixture for a minimum of 2 minutes to ensure water is completely cooled and good mixing has occurred.
 - d. The mixture should generally contain about 85% ice with the distilled water occupying the rest of the space.
 - e. Add more ice as the ice melts.
- 2. Stir the ice water slurry mixture to maintain a temperature 0°C (32°F).
- 3. Constantly monitor the temperature of the ice water slurry with your reference thermometer. Ensure that the temperature of the bath has stabilized. The criterion for stability generally is to take two readings at 1 minute intervals, and the two readings should give you 0°C (32°F).

7.29.2 Sensor Checkout Procedure

This procedure is performed to verify the accuracy of a temperature sensor.

- 1. Remove the sensor and place in a 0°C (32°F) ice-water bath. Refer to Ice Bath Preparation Procedure.
- 2. Start the unit and check sensor reading on the control panel. The reading should be 0°C (32°F). If the reading is correct, reinstall sensor; if it is not, continue with the next step.

- 3. Place the Start-Stop switch (ST) to "0" to turn the unit Off. Disconnect the power supply.
- 4. See Section 7.27 to remove the controller to gain access to the sensor plugs.
- 5. Using the plug connector marked "EC" that is connected to the back of the controller, locate the sensor wires (RRS, RTS, SRS, STS, AMBS, DTS, or CPDS as required). Follow those wires to the connector and using the pins of the plug, measure the resistance. Values are provided in **Table 7–3** and **Table 7–4**.

Due to the variations and inaccuracies in ohmmeters, thermometers or other test equipment, a reading within 2% of the chart value would indicate a good sensor. If a sensor is defective, the resistance reading will usually be much higher or lower than the resistance values given.

7–41 T-362

Table 7–3 Sensor Resistance - AMBS, DTS, ETS, RRS, RTS, SRS, STS

°C	°F	OUMC		°C	°F	OLIMO
		OHMS				OHMS
-40	-40	336,500	<u> </u>	6	42.8	24,173
-39	-38.2	314,773		7	44.6	23,017
-38	-36.4	294,600		8	46.4	21,922
-37	-34.6	275,836		9	48.2	20,886
-36	-32.8	258,336		10	50	19,900
-35	-31	242,850		11	51.8	18,975
-34	-29.2	228,382		12	53.6	18,093
-33	-27.4	214,164		13	55.4	17,258
-32	-25.6	200,909		14	57.2	16,466
-31	-23.8	188,545		15	59	15,715
-30	-22.0	177,000		16	60.8	15,002
-29	-20.2	166,360		17	62.6	14,325
-28	-18.4	156,426		18	64.4	13,683
-27	-16.6	147,148		19	66.2	13,073
-26	-14.8	138,478		20	68	12,494
-25	-13	130,374		21	69.8	11,944
-24	-11.2	122,794		22	71.6	11,420
-23	-9.4	115,702		23	73.4	10,923
-22	-7.6	109,063		24	75.2	10,450
-21	-5.8	102,846		25	77	10,000
-20	-4	97,022		26	78.8	9,572
-19	-2.2	91,563		27	80.6	9,164
-18	-0.4	86,445	1	28	82.4	8,777
-17	1.4	81,644	1	29	84.2	8,407
-16	3.2	77,139		30	86	8,055
-15	5.2	72,910		31	87.8	7,720
-14	6.8	68,938		32	89.6	7,401
-13	8.6	65,206		33	91.4	7,096
-12	10.4	61,699	-	34	93.2	6,806
-11	12.2	58,401		35	95.2	6,529
-10	14	55,330			96.8	
		· ·	-	36		6,265
-9	15.8	52,381	-	37	98.6	6,013
-8	17.6	49,634	1	38	100.4	5,772
-7	19.4	47,047	-	39	102.2	5,543
-6	21.2	44,610	-	40	104.0	5,323
-5	23	42,314	-	41	105.8	5,114
-4	24.8	40,149		42	107.6	4,914
-3	26.6	38,108		43	109.4	4,723
-2	28.4	36,182		44	111.2	4,540
-1	30.2	34,365	1	45	113	4,365
0	32	32,650		46	114.8	4,198
1	33.8	31,030		47	116.6	4,038
2	35.6	29,500		48	118.4	3,885
3	37.4	28,054		49	120.2	3,739
4	39.2	26,688		50	122	3,599
5	41	25,396				

Table 7-4 Sensor Resistance - PrimeLINE CPDS

°C	°F	OHMS	°C	°F	OHMS
-40	-40	2,889,600	18	64.4	117,656
-38	-36.4	2,532,872	20	68.0	107,439
-36	-32.8	2,225,078	22	71.6	98,194
-34	-29.2	1,957,446	24	75.2	89,916
-32	-25.6	1,724,386	25	77	86,113
-30	-22.0	1,522,200	26	78.8	82,310
-28	-18.4	1,345,074	28	82.4	75,473
-26	-14.8	1,190,945	30	83.0	69,281
-24	-11.2	1,056,140	32	89.6	63,648
-22	-7.6	938,045	34	93.2	58,531
-20	-4.0	834,716	36	96.8	53,887
-18	-0.4	743,581	38	100.4	49,656
-16	3.2	663,593	40	104.0	45,812
-14	6.8	593,030	42	107.6	42,294
-12	10.4	530,714	44	111.2	39,078
-10	14.0	475,743	46	114.8	36,145
-8	17.6	426,904	48	118.4	33,445
-6	21.2	383,706	50	122.0	30,985
-4	24.8	345,315	52	125.6	28,724
-2	28.4	311,165	54	129.2	26,651
0	32.0	280,824	56	132.8	27,750
2	35.6	253,682	58	136.4	23,005
4	39.2	229,499	60	140.0	21,396
6	42.8	207,870	62	143.6	19,909
8	46.4	188,494	64	147.2	18,550
10	50.0	171,165	66	150.8	17,294
12	53.6	155,574	68	154.4	16,133
14	57.2	141,590	70	158.0	15,067
16	60.8	129,000	72	161.6	14,078

7.29.3 GDP Supply and Return Sensor Calibration

European Commission GDP (Good Distribution Practices) guidelines, which are used worldwide, call for the equipment used to control or monitor environments where medicinal products are stored or transported be calibrated in accordance with pharmaceutical shipper specifications, typically every six months or annually.

This procedure explains how to perform a GDP calibration of the supply (STS/SRS) and return (RTS/RRS) sensors using DataLINE software version 3.1 or higher. The calibration procedure should be conducted in pairs (STS/SRS, or RTS/RRS) and it is recommended to calibrate before the full pre-trip inspection.



Before removing the Supply or Return air sensors from the unit, turn the ON/OFF switch and circuit breaker to the OFF position. Disconnect the power plug from the unit. Follow proper lockout/tagout procedures to ensure the power cannot inadvertently be energized. It is important that all dismantling work is done and tools and personnel are away from the unit before powering on the unit for calibration.

7–43 T-362



When performing the Return Air Sensor calibration, disconnect both evaporator motors.

Before proceeding with the calibration procedure, ensure that controller software version is 5368 or higher and DataLINE version 3.1 or higher is installed onto the download device. Only the latest DataLINE and controller software will allow users to carry out Good Distribution Practice (GDP) calibration. Do not downgrade the software after installing the latest software.

Before proceeding with the calibration procedure, it is recommended to check the sensors by running pre-trip P5-0. This test checks the sensor values. If the test fails, identify and correct the faulty sensor and rerun the test.

Tools Required:

- · Socket screwdrivers set
- Phillips screwdriver
- · Standard hand tools
- · Interrogator cable
- Laptop with DataLINE 3.1 or above installed
- Clean insulated container for distilled water and ice
- A regularly calibrated reference thermometer, recommended to be of accuracy up to 2 decimal places.

GDP Calibration, Removing Supply Sensors (STS/SRS) from Unit:

- 1. Locate the supply sensors cover assembly on the suction side of the compressor. Remove the two fasteners securing the cover of the sensors (see Figure 7.20).
- 2. Remove the cover and rotate the supply air sensors, STS/SRS, in a clockwise direction and remove the sensors from the sensor housing (see Figure 7.20).




Figure 7.20 Supply Sensors - Cover Assembly and Sensors



GDP Calibration, Removing Return Sensors (RTS/RRS) from Unit:

1. Remove both front access panels from the unit by removing 8 fasteners from each panel (see **Figure 7.21**). Save all hardware for re-installation.

Figure 7.21 Removing Front Access Panels




2. On the right side, disconnect the fan motor wiring, loosen the fastener and remove (slide) the evaporator motor from the unit (see Figure 7.22).

Figure 7.22 Removing Evaporator Motor



3. Loosen the fastener on the sensor bracket (see Figure 7.23).

Figure 7.23 Return Sensors - Bracket



7–45 T-362

4. Cut all the wire ties (see Figure 7.24) that are securing the sensors to the harness and remove sensor.

Figure 7.24 Return Sensors - Cutting Wire Ties





GDP Calibration, Perform Calibration:

1. Connect the interrogator cable to the interrogator port. Then, power on the unit.



Before powering on the unit, it is important to ensure that all dismantling work is done and tools are away and service personnel are not working on the unit at the time of power on.

2. Open DataLINE version 3.1 or above. From the DataLINE launch pad, click on the Probe Calibration button (see Figure 7.25) to go to the Probe Calibration screen. A pop-up window will appear reminding the user to ensure proper ice bath temperature. Click OK to acknowledge.

Figure 7.25 DataLINE - Probe Calibration



3. On the Probe Calibration screen, click on the Calibrate Supply sensors or Calibrate Return sensors button (see Figure 7.26).


Probe Calibration Recorder Information Controller Information Container ID: TRIU8425410 Serial Number: 04685436 Serial Number: 04685436 Date and Time: 12/02/2020 16:05 Current Probe Offset Temperatures UnCal-Offset Calibrated Results Probe USDA1 -50.0 C 0.0 C -50.0 C USDA2 -50.0 C 0.0 C -50.0 C USDA3 -50.0 C 0.0 C -50.0 C Cargo -50.0 C 0.0 C -50.0 C Auto Auto **Bath Temperature** 0.0 🔷 C O External USDA Probe 1 USDA Probe 3 Calibrate Supply sensors USDA Probe 2 Cargo Probe Calibrate Return sensors

Figure 7.26 DataLINE - Calibrate Sensors Button

4. A Location of Service pop-up window will appear (see Figure 7.27). In the appropriate fields, enter the Service Center Name and Service Center Location where the calibration is being performed. Then, click the Save button. A pop-up window will appear reminding the user to ensure proper ice bath temperature. Click OK to acknowledge and remember to maintain the Ice bath at 0°C (32°F).

Start Cal

Figure 7.27 DataLINE - Enter Service Center Information



5. Prepare the ice bath. Refer to the Ice Bath Preparation procedure.

Ensure that the set-up (i.e. ice bath, sensors, reference thermometer) has reached a stable state before beginning the calibration process. Ensure that the set-up is clean and the reference thermometer is regularly maintained and calibrated.

7–47 T-362

Close

6. Place the ice bath in a location near sensors (see **Figure 7.28**). For Return Sensors, place the ice bath on an elevated platform (ladder) of appropriate height.

Figure 7.28 Ice Bath





- 7. Once temperature stability is ensured, submerge the sensors in the ice water slurry. Make certain that the sensors do not contact the container sides or bottom, or each other. Continuously stir the slurry mixture during calibration.
- 8. Ensure that the Ice bath is at 0°C (32°F) using the calibrated reference thermometer. Confirm that the sensor readings have stabilized and the sensors are within +/- 0.3°C (0.5°F). The readings can be taken from the Uncal column in the Current Probe Offset Temperatures table.
- 9. Then, after confirming the sensor readings have stabilized, click on the Start Cal button (see Figure 7.29). After clicking Start Cal, the process begins automatically and will complete in less than 5 minutes. Continue to stir the ice bath during testing. Calibration will fail if the stability cannot be achieved or the sensor offset is greater than 0.3°C (0.5°F).

Probe Calibration Recorder Information Controller Information Container ID: TRIU8425410 Serial Number: 04685436 Serial Number: 04685436 Date and Time: 12/02/2020 16:08 Current Probe Offset Temperatures Probe UnCal-Offset Calibrated Results STS 0.1 C 0.0 C 0.1 C SRS 0.1 C 0.0 C 0.1 C Auto Bath Temperature Start Cal Cancel Close F1=Help | Successfully connected to refrigeration unit... 5378 🔐

Figure 7.29 DataLINE - Start Cal Button

10. Once the calibration has completed, a pop-up will appear with the message Calibrate Complete. Click OK to acknowledge and the results will then be displayed on the screen in the Results column (see Figure 7.30).

Calibration will fail if the stability cannot be achieved or the sensor offset is greater than 0.3°C (0.5°F). The validity of a sensor can be checked by hand warming the sensors to see if there are changes in the readings on the DataLINE screen. If calibration will not complete, replace and recalibrate the sensors. Refer to the **Sensor Replacement** procedure.

Probe Calibration X Recorder Information Controller Information Container ID: TRIU8425410 Serial Number: 04685436 Serial Number: 04685436 Date and Time: 12/02/2020 16:08 Current Probe Offset Temperatures UnCal-Offset Calibrated Probe Results 0.0 C 0.0 C STS 0.1 C Passed 0.0 C 0.0 C SRS 0.1 C Passed Auto Bath Temperature Start Cal Cancel Close F1=Help Successfully connected to refrigeration unit... 5378

Figure 7.30 DataLINE - Calibration Results

11. After completing the calibration event, download a DCX file and check that all of the following information is captured: service center name, location, the results of the calibration and the offset applied. Ensure that all the information is captured and the event is considered a success when all the intended sensors in calibration have passed.

NOTE

If there is "uncal" in the download, it means that the calibration process was not completed.

12. After the completion of the calibration, restore the unit to its original state.

7.29.4 Sensor Replacement



Always turn OFF the unit circuit breaker (CB-1) and disconnect main power supply before removing electrical parts.

1. Place the Start-Stop switch (ST) to "0" to turn the unit Off. Disconnect the power supply.


NOTE

Include white date code label when cutting out and removing defective sensors. The label could be required for warranty returns.

- 2. Cut the cable. Slide the cap and grommet off the bulb type sensor and save for reuse. **Do not cut the grommet**.
- 3. Cut one wire of existing cable 40 mm (1-1/2 inches) shorter than the other wire.
- 4. Cut the replacement sensor wires (opposite colors) back 40 mm (1-1/2 inches). See Figure 7.31.


7–49 T-362

Figure 7.31 Sensor Types



- 5. Strip back insulation on all wiring 6.3 mm (1/4 inch).
- 6. Slide a large piece of heat shrink tubing over the cable, and place the two small pieces of heat shrink tubing, one over each wire, before adding crimp fittings as shown in **Figure 7.32**.

Figure 7.32 Sensor and Cable Splice



- 1) Sensor (typical)
- 2) Heat Shrink Tubing (2 or 3 as required)

- 3) Cable
- 4) Large Heat Shrink Tubing (1)
- 7. If required, slide the cap and grommet assembly onto the replacement sensor.
- 8. Slip crimp fittings over dressed wires (keeping wire colors together). Make sure wires are pushed into crimp fittings as far as possible and crimp with crimping tool.
- 9. Solder spliced wires with a 60% tin and 40% lead Rosincore solder.
- 10. Slide heat shrink tubing over each splice so that ends of tubing cover both ends of crimp as shown in Figure 7.32.
- 11. Heat tubing to shrink over splice. Make sure all seams are sealed tightly against the wiring to prevent moisture seepage.



Do not allow moisture to enter wire splice area as this may affect sensor resistance.

- 12. Slide large heat shrink tubing over both splices and shrink.
- 13. Position sensor in unit as shown in Figure 7.32 and re-check sensor resistance. See following sections:
 - See Figure 7.33 for Supply Sensor Positioning
 - See Figure 7.34 for Return Sensor Positioning
 - See Figure 7.35 for ETS Sensor Positioning

- 14. Reinstall sensor. See following sections:
 - See Section 7.29.5 for STS and SRS Reinstallation
 - See Section 7.29.6 for RRS and RTS Reinstallation
 - See Section 7.29.7 for DTS Reinstallation
 - See Section 7.29.8 for ETS1 and ETS2 Reinstallation

The P5 Pre-Trip test must be run to deactivate probe alarms (see Section 5.8).

7.29.5 Supply Sensor (STS/SRS) Reinstallation

To properly reinstall a unit Supply Temperature Sensor (STS) or Supply Recorder Sensor (SRS), the sensor must be fully inserted into the probe holder. This positioning will give the sensor the optimum amount of exposure to the supply air stream, and will allow the controller to operate correctly. Insufficient probe insertion into the probe holder will result in poor temperature control due to the lack of air flow over the sensor.

It is also necessary to ensure that the probe tip does not contact the back panel. The design minimum clearance of 6 mm (1/4 inch) should be maintained (see Figure 7.33).




Figure 7.33 STS/SRS Positioning

- 2) Cap & Grommet Assembly
- 3) Probe Holder

5) Supply Sensor

7.29.6 Return Sensor (RRS/RTS) Reinstallation

To properly reinstall a Return Temperature Sensor (RTS) or Return Recorder Sensor (RRS), be sure to position the enlarged positioning section of the sensor against the side of the mounting clamp (see Figure 7.34).




Figure 7.34 RRS/RTS Positioning

1) Mounting Clamp

2) Return Sensor

7-51 T-362

7.29.7 Defrost Temperature Sensor (DTS) Reinstallation

To properly reinstall a Defrost Temperature Sensor (DTS), insulating material must be placed completely over the sensor to ensure the coil metal temperature is sensed.

7.29.8 Evaporator Temperature Sensor (ETS1/ETS2) Reinstallation

The Evaporator Temperature Sensors (ETS1/ETS2) are located in a tube holder under insulation (see **Figure 7.35**). To properly reinstall this combo sensor, it must be placed in a tube holder by applying thermal grease. Insulating material must completely cover the sensor to ensure the correct temperature is sensed.

1) Insulation
2) Wire Tie

3) ETS Tube Holder
4) ETS1 and ETS2

Figure 7.35 ETS1/ETS2 Positioning

7.29.9 Compressor Discharge Temperature Sensor (CPDS) Reinstallation

- 1. Ensure the unit is disconnected from the power source.
- 2. Verify that the Start-Stop switch (ST) is in the "0" position.
- 3. Remove the existing sensor.

Silicon Bead

4. Clean all silicone sealer and dielectric compound from the sensor well. Make sure that the well is clean and dry. The top of the compressor, where the sensor seals, must also be clean and dry (see Figure 7.36).




Figure 7.36 Compressor Discharge Temperature Sensor

5. Using the syringe supplied with the replacement sensor, squeeze all of the dielectric compound into the sensor well.

- 6. Place a bead of the silicone sealer supplied with the replacement sensor around the sensor sealing ring. Insert sensor into the well with the leads parallel to the suction fitting.
- 7. Reconnect the sensor (see Figure 7.32) and run pre-trip P5.

7.30 Vent Position Sensor (VPS)

The vent position sensor (VPS) determines fresh air vent position in near real-time via function code Cd45.

The fresh air vent position sensor alarm (AL50) will occur if the sensor reading is not stable for four minutes or if the sensor is outside of its valid range (shorted or open). This can occur if the vent is loose or the panel is defective. To confirm a defective panel, assure that the wing nut is secure and then power cycle the unit. If the alarm immediately reappears as active, the panel should be replaced.

The alarm should immediately go inactive. Check the four minute stability requirement. If the alarm reoccurs after the four minutes and the panel was known to have been stable, then the sensor should be replaced.

Upper VPS:

In order to replace the Upper VPS, the panel must be removed and replaced with another upper fresh air panel equipped with VPS. Upon installation, a new VPS assembly requires calibration.

- 1. Rotate the vent to the 0 CMH / CFM position.Cd45 will automatically display.
- 2. Press and hold the ENTER key for five seconds.
- 3. After the ENTER key has been pressed the display will read "CAL" (for calibration).
- 4. Press and hold the ALT MODE key for five seconds.
- 5. After the calibration has been completed, Cd45 will display 0 CMH / CFM.

7.31 XtendFRESH Service

Procedures and technical information related to the XtendFRESH™ controlled atmosphere system can be found in the T-366 XtendFRESH Manual, located in the Literature section of the Container Refrigeration website. To find the manual from the Literature section, click on Options > XtendFRESH.


7.32 Maintenance of Painted Surfaces

The refrigeration unit is protected by a special paint system against the corrosive atmosphere in which it normally operates. However, should the paint system be damaged, the base metal can corrode. In order to protect the refrigeration unit from the highly corrosive sea atmosphere, or if the protective paint system is scratched or damaged, clean the area to bare metal using a wire brush, emery paper or equivalent cleaning method. Immediately following cleaning, apply paint to the area, and allow to dry. See the Parts List for proper paint selection.

7–53 T-362

7.33 Communications Interface Module Installation

Figure 7.37 Communications Interface Installation



1) Circuit Breaker 460V (CB1)

 Communications Interface Module

Units that have been factory provisioned for installation of a Communication Interface Module (CIM) have the required wiring installed. If the unit is not factory provisioned, a provision wiring kit (Carrier Transicold part number 76-00685-00) must be installed. Installation instructions are packaged with the kit.

7.33.1 Installing the Module



Installation requires wiring to the main unit circuit breaker, CB1. Make sure the power to the unit is off and power plug disconnected before beginning installation.

- 1. CB1 is connected to the power system, see wiring schematic.
- 2. Open control box, (see Figure 7.37) and remove low voltage shield.
- 3. Open high voltage shield.
- 4. If using factory provisioned wiring, remove the circuit breaker panel, with circuit breaker, from the control box. Locate, wires CB21/CIA3, CB22/CIA5 and CB23/CIA7 that have been tied back in the wire harness. Remove the protective heat shrink from the ends of the wires.
- 5. Refit the circuit breaker panel.
- 6. Fit the new CIM into the unit.
- 7. Attach three wires CB21/CIA3, CB22/CIA5 and CB23/CIA7 to the CIM at connection CIA.
- 8. Locate connectors CIA and CIB, remove plugs if required, and attach to the module.
- 9. Replace the low voltage shield.

Table 7–5 R-134a Refrigerant Pressure Temperature Chart

°F	°C	PSIG	°C	°F	BAR
-40	-40.0	<u>14.8</u>	-40	-40.0	-0.49
-38	-38.9	<u>13.9</u>	-39	-38.2	-0.46
-36	-37.8	13.0	-38	-36.4	-0.43
-34	-36.7	12.0	-37	-34.6	-0.40
-32	-35.6	<u>10.9</u>	-36	-32.8	-0.37
-30	-34.4	9.8	-35	-31.0	-0.34
-28	-33.3	8.7	-34	-29.2	-0.30
-26	-32.2	7.5	-33	-27.4	-0.27
-24	-31.1	<u>6.3</u>	-32	-25.6	-0.23
-22	-30.0	<u>5.0</u>	-31	-23.8	-0.20
-20	-28.9	<u>3.7</u>	-30	-22.0	-0.16
-18	-27.8	<u>2.3</u>	-29	-20.2	-0.12
-16	-26.7	<u>0.8</u>	-28	-18.4	-0.07
-14	-25.6	0.3	-27	-16.6	-0.03
-12	-24.4	1.1	-26	-14.8	0.02
-10	-23.3	1.9	-25	-13.0	0.06
-8	-22.2	2.8	-24	-11.2	0.11
-6	-21.1	3.6	-23	-9.4	0.16
-4	-20.0	4.6	-22	-7.6	0.22
-2	-18.9	5.5	-21	-5.8	0.27
0	-17.8	6.5	-20	-4.0	0.33
2	-16.7	7.5	-19	-2.2	0.39
4	-15.6	8.5	-18	-0.4	0.45
6	-14.4	9.6	-17	1.4	0.51
8	-13.3	10.8	-16	3.2	0.57
10	-12.2	11.9	-15	5.0	0.64
12	-11.1	13.1	-14	6.8	0.71
14	-10.0	14.4	-13	8.6	0.78
16	-8.9	15.7	-12	10.4	0.85
18	-7.8	17.0	-11	12.2	0.93
20	-6.7	18.4	-10	14.0	1.01
22	-5.6	19.9	-9	15.8	1.09
24	-4.4	21.3	-8	17.6	1.17
26	-3.3	22.9	-7	19.4	1.25
28	-2.2	24.5	-6	21.2	1.34
30	-1.1	26.1	-5	23.0	1.43
32	0.0	27.8	-4	24.8	1.53
34	1.1	29.5	-3	26.6	1.62
36	2.2	31.3	-2	28.4	1.72
38	3.3	33.1	-1	30.2	1.82
40	4.4	35.0	0	32.0	1.93

7–55 T-362

Table 7–5 R-134a Refrigerant Pressure Temperature Chart

°F	°C	PSIG	°C	°F	BAR
42	5.6	37.0	1	33.8	2.04
44	6.7	39.0	2	35.6	2.15
46	7.8	41.1	3	37.4	2.26
48	8.9	43.2	4	39.2	2.38
50	10.0	45.4	5	41.0	2.50
52	11.1	47.7	6	42.8	2.62
54	12.2	50.0	7	44.6	2.75
56	13.3	52.4	8	46.4	2.88
58	14.4	54.9	9	48.2	3.01
60	15.6	57.4	10	50.0	3.15
62	16.7	60.0	11	51.8	3.29
64	17.8	62.7	12	53.6	3.43
66	18.9	65.4	13	55.4	3.58
68	20.0	68.2	14	57.2	3.73
70	21.1	71.1	15	59.0	3.88
72	22.2	74.1	16	60.8	4.04
74	23.3	77.1	17	62.6	4.21
76	24.4	80.2	18	64.4	4.37
78	25.6	83.4	19	66.2	4.54
80	26.7	86.7	20	68.0	4.72
82	27.8	90.0	21	69.8	4.90
84	28.9	93.5	22	71.6	5.08
86	30.0	97.0	23	73.4	5.27
88	31.1	100.6	24	75.2	5.46
90	32.2	104.3	25	77.0	5.65
92	33.3	108.1	26	78.8	5.85
94	34.4	112.0	27	80.6	6.06
96	35.6	115.9	28	82.4	6.27
98	36.7	120.0	29	84.2	6.48
100	37.8	124.2	30	86.0	6.70
102	38.9	128.4	31	87.8	6.93
104	40.0	132.7	32	89.6	7.15
106	41.1	137.2	33	91.4	7.39
108	42.2	141.7	34	93.2	7.63
110	43.3	146.4	35	95.0	7.87
112	44.4	151.1	36	96.8	8.12
114	45.6	156.0	37	98.6	8.37
116	46.7	160.9	38	100.4	8.63
118	47.8	166.0	39	102.2	8.90
120	48.9	171.2	40	104.0	9.17
122	50.0	176.5	41	105.8	9.44
124	51.1	181.8	42	107.6	9.72

Table 7–5 R-134a Refrigerant Pressure Temperature Chart

°F	°C	PSIG	°C	°F	BAR
126	52.2	187.4	43	109.4	10.01
128	53.3	193.0	44	111.2	10.30
130	54.4	198.7	45	113.0	10.60
132	55.6	204.6	46	114.8	10.90
134	56.7	210.6	47	116.6	11.21
136	57.8	216.7	48	118.4	11.53
138	58.9	222.9	49	120.2	11.85
140	60.0	229.2	50	122.0	12.18
142	61.1	235.7	51	123.8	12.51
144	62.2	242.3	52	125.6	12.85
146	63.3	249.0	53	127.4	13.20
148	64.4	255.9	54	129.2	13.56
150	65.6	262.9	55	131.0	13.92
			56	132.8	14.28
			57	134.6	14.66
			58	136.4	15.04
			59	138.2	15.42
			60	140.0	15.82
			61	141.8	16.22
			62	143.6	16.63
			63	145.4	17.04
			64	147.2	17.47
			65	149.0	17.90

7–57 T-362

Table 7–6 R-513A Refrigerant Pressure Temperature Chart

°F	°C	PSIG	°C	°F	BAR
-40	-40.0	<u>9.8</u>	-40	-40.0	-0.32
-38	-38.9	8.6	-39	-38.2	-0.28
-36	-37.8	<u>7.4</u>	-38	-36.4	-0.25
-34	-36.7	<u>6.2</u>	-37	-34.6	-0.21
-32	-35.6	<u>4.9</u>	-36	-32.8	-0.17
-30	-34.4	<u>3.6</u>	-35	-31.0	-0.13
-28	-33.3	<u>2.2</u>	-34	-29.2	-0.09
-26	-32.2	0.7	-33	-27.4	-0.05
-24	-31.1	0.4	-32	-25.6	0.00
-22	-30.0	1.1	-31	-23.8	0.04
-20	-28.9	1.9	-30	-22.0	0.09
-18	-27.8	2.8	-29	-20.2	0.14
-16	-26.7	3.7	-28	-18.4	0.19
-14	-25.6	4.6	-27	-16.6	0.25
-12	-24.4	5.5	-26	-14.8	0.30
-10	-23.3	6.5	-25	-13.0	0.36
-8	-22.2	7.5	-24	-11.2	0.42
-6	-21.1	8.5	-23	-9.4	0.48
-4	-20.0	9.6	-22	-7.6	0.54
-2	-18.9	10.7	-21	-5.8	0.61
0	-17.8	11.9	-20	-4.0	0.67
2	-16.7	13.1	-19	-2.2	0.74
4	-15.6	14.3	-18	-0.4	0.81
6	-14.4	15.6	-17	1.4	0.89
8	-13.3	16.9	-16	3.2	0.96
10	-12.2	18.3	-15	5.0	1.04
12	-11.1	19.7	-14	6.8	1.12
14	-10.0	21.1	-13	8.6	1.21
16	-8.9	22.6	-12	10.4	1.29
18	-7.8	24.2	-11	12.2	1.38
20	-6.7	25.8	-10	14.0	1.47
22	-5.6	27.5	-9	15.8	1.56
24	-4.4	29.2	-8	17.6	1.66
26	-3.3	30.9	-7	19.4	1.76
28	-2.2	32.7	-6	21.2	1.86
30	-1.1	34.6	-5	23.0	1.97
32	0.0	36.5	-4	24.8	2.07
34	1.1	38.5	-3	26.6	2.18
36	2.2	40.5	-2	28.4	2.30
38	3.3	42.6	<u>-</u> 1	30.2	2.41
40	4.4	44.8	0	32.0	2.53
	7.7	77.0	0	02.0	2.00

Table 7–6 R-513A Refrigerant Pressure Temperature Chart

°F	°C	PSIG	°C	°F	BAR
42	5.6	47.0	1	33.8	2.65
44	6.7	49.3	2	35.6	2.78
46	7.8	51.6	3	37.4	2.91
48	8.9	54.0	4	39.2	3.04
50	10.0	56.5	5	41.0	3.18
52	11.1	59.0	6	42.8	3.32
54	12.2	61.6	7	44.6	3.46
56	13.3	64.3	8	46.4	3.60
58	14.4	67.0	9	48.2	3.75
60	15.6	69.8	10	50.0	3.91
62	16.7	72.7	11	51.8	4.06
64	17.8	75.7	12	53.6	4.22
66	18.9	78.7	13	55.4	4.39
68	20.0	81.8	14	57.2	4.56
70	21.1	85.0	15	59.0	4.73
72	22.2	88.2	16	60.8	4.91
74	23.3	91.6	17	62.6	5.09
76	24.4	95.0	18	64.4	5.27
78	25.6	98.5	19	66.2	5.46
80	26.7	102.1	20	68.0	5.65
82	27.8	105.7	21	69.8	5.85
84	28.9	109.5	22	71.6	6.05
86	30.0	113.3	23	73.4	6.26
88	31.1	117.3	24	75.2	6.47
90	32.2	121.3	25	77.0	6.68
92	33.3	125.4	26	78.8	6.90
94	34.4	129.6	27	80.6	7.13
96	35.6	133.9	28	82.4	7.36
98	36.7	138.3	29	84.2	7.59
100	37.8	142.8	30	86.0	7.83
102	38.9	147.4	31	87.8	8.07
104	40.0	152.0	32	89.6	8.32
106	41.1	156.8	33	91.4	8.57
108	42.2	161.7	34	93.2	8.83
110	43.3	166.7	35	95.0	9.10
112	44.4	171.8	36	96.8	9.37
114	45.6	177.0	37	98.6	9.64
116	46.7	182.3	38	100.4	9.92
118	47.8	187.7	39	102.2	10.21
120	48.9	193.3	40	104.0	10.50
122	50.0	198.9	41	105.8	10.79
124	51.1	204.7	42	107.6	11.10

7–59 T-362

Table 7–6 R-513A Refrigerant Pressure Temperature Chart

0=	00	DOLO	00	٥=	545
°F	°C	PSIG	°C	°F	BAR
126	52.2	210.5	43	109.4	11.40
128	53.3	216.5	44	111.2	11.72
130	54.4	222.7	45	113.0	12.04
132	55.6	228.9	46	114.8	12.36
134	56.7	235.2	47	116.6	12.70
136	57.8	241.7	48	118.4	13.03
138	58.9	248.3	49	120.2	13.38
140	60.0	255.1	50	122.0	13.73
142	61.1	261.9	51	123.8	14.09
144	62.2	268.9	52	125.6	14.45
146	63.3	276.1	53	127.4	14.82
148	64.4	283.3	54	129.2	15.20
150	65.6	290.8	55	131.0	15.58
			56	132.8	15.97
			57	134.6	16.37
			58	136.4	16.77
			59	138.2	17.18
			60	140.0	17.60
			61	141.8	18.03
			62	143.6	18.46
			63	145.4	18.90
			64	147.2	19.35
			65	149.0	19.80

Table 7–7 Recommended Bolt Torque Values (Dry, Non-Lubricated for 18-8 Stainless Steel)

,						
Bolt Diameter	Threads	In-Lb	Ft-Lb	Nm		
	Free Spinning					
#4	40	5.2	0.4	0.6		
#6	32	9.6	0.8	1.1		
#8	32	20	1.7	2.3		
#10	24	23	1.9	2.6		
1/4	20	75	6.3	8.5		
5/16	18	132	11	14.9		
3/8	16	240	20	27.1		
7/16	14	372	31	42		
1/2	13	516	43	58.3		
9/16	12	684	57	77.3		
5/8	11	1104	92	124.7		
3/4	10	1488	124	168.1		
Non Free Spinning (Locknuts etc.)						
1/4	20	82.5	6.9	9.3		
5/16	18	145.2	12.1	16.4		
3/8	16	264	22.0	29.8		
7/16	14	409.2	34.1	46.2		
1/2	13	567.6	47.3	64.1		
9/16	12	752.4	62.7	85		
5/8	11	1214.4	101.2	137.2		
3/4	10	1636.8	136.4	184.9		

7–61 T-362

SECTION 8


ELECTRICAL WIRING SCHEMATIC AND DIAGRAMS

Figure 8.1 LEGEND - Standard Unit Configuration

ZONE	SYMBO	L	DESCRIPTION
C23	AMBS	_	AMBIENT SENSOR
L21 J1	C CB1	_	CONTROLLERS CIRCUIT BREAKER 460V
D1	CB2	_	OPTIONAL CIRCUIT BREAKER 230V (DVM OPTION)
			TERMINAL BLOCK WHEN CB2 NOT PRESENT
N8,L11	CF	_	CONDENSER FAN CONTACTOR
L10,P1 A4	CH CI	_	COMPRESSOR CONTACTOR COMMUNICATIONS INTERFACE MODULE (OPTION)
L12	C-L	_	COOL LIGHT (OPTION)
E11,G11,R9	9 CM	_	CONDENSER FAN MOTOR
T4	CP	-	COMPRESSOR MOTOR
A23 M2	CPDS CS	_	DISCHARGE TEMPERATURE SENSOR CURRENT SENSOR
R8	DHBL	_	DEFROST HEATER - BOTTOM LEFT
T7	DHBR	_	DEFROST HEATER - BOTTOM RIGHT
R7	DHML	_	DEFROST HEATER - MIDDLE LEFT
T7 R7	DHMR DHTL	_	DEFROST HEATER — MIDDLE RIGHT DEFROST HEATER — TOP LEFT
T8	DHTR	_	DEFROST HEATER - TOP RIGHT
L7	DL	_	DEFROST LIGHT (OPTION)
K23	DPT	_	DISCHARGE PRESSURE TRANSDUCER
C23 F24	DTS DUV	_	DEFROST TEMPERATURE SENSOR DIGITAL UNLOADER VALVE
D1	DVM	_	DUAL VOLT MODULE (OPTIONAL)
F3	DVR	_	DUAL VOLTAGE RECEPTACLE (OPTIONAL)
R16	EEV	_	EVAPORATOR EXPANSION VALVE
N11,K13	EF	_	EVAPORATOR FAN CONTACTOR (HIGH SPEED)
T11,T13 E14,F14,G1	EM 14	_	EVAPORATOR FAN MOTOR
H23	EPT	_	EVAP. PRESSURE TRANSDUCER
P10,L13 D23	ES ETS	_	EVAPORATOR FAN CONTACTOR (LOW SPEED) EVAPORATOR TEMPERATURE SENSOR (SUCTION)
J11	ESV	_	ECONOMIZER SOLENOID VALVE
C7,D7,F21,		_	FUSE
G21	FLA		FULL LOAD AMPS
G9	HPS	_	FULL LOAD AMPS HIGH PRESSURE SWITCH
N7,L15	HR	_	HEATER CONTACTOR
F23	HS	_	HUMIDITY SENSOR (OPTIONAL)
E15	HTT	_	HEAT TERMINATION THERMOSTAT
T23 T24	ICF ICR	_	INTERROGATOR CONNECTOR FRONT INTERROGATOR CONNECTOR REAR
E14,F11,	IP	_	INTERNAL PROTECTOR
G14 K15	I.D.I		IN BANCE LIGHT (OPTION)
K9,L8,N1	IRL PA	_	IN-RANGE LIGHT (OPTION) UNIT PHASE CONTACTOR
K8,L9,N3	PB	_	UNIT PHASE CONTACTOR
M24,N24,	PR	_	PROBE RECEPTACLE (USDA OPTION)
P24 N17	PTC1	_	PTC FOR VENT POSITION SENSOR (UPPER)
K7,L7,K12	, RM	_	REMOTE MONITORING RECEPTACLE (OPTION)
L12,K15, L15			
C23	RRS	_	RETURN RECORDER SENSOR
B23	RTS	_	RETURN TEMPERATURE SENSOR
H23	SPT	_	SUCTION PRESSURE TRANSDUCER SUPPLY RECORDER SENSOR
L23	SRS		
K5 A23	ST STS	_	START-STOP SWITCH SUPPLY TEMPERATURE SENSOR
J9	TC	_	CONTROLLER RELAY (COOLING)
J8,J9	TCP		CONTROLLER RELAY (PHASE SEQUENCING)
J14	TE	_	
J15	TH	_	CONTROLLER RELAY (HEATING)
E7	TF	_	CONTROLLER RELAY (DEFROST)
J15	TI	_	CONTROLLER RELAY (IN RANGE)
J12 J11	TL TN	_	CONTROLLER RELAY (COOL LIGHT) CONTROLLER RELAY (CONDENSER FAN)
H9,F10,	TP	_	TEST POINT
H11,G12, H13,G15,L	17		
M3	TR	_	TRANSFORMER
D3	TRANS	_	TRANSFORMER AUTO 230/460 (OPTION)
E10	TS	_	
J13	TV	_	CONTROLLER RELAY (LOW SPEED EVAPORATOR FANS)
N17	VPS WCR	_	VENT POSITIONING SENSOR (UPPER) (OPTION) WETTING CURRENT SENSOR (OPTION)
J12 E12	WP	_	WETTING CURRENT SENSOR (OPTION) WATER PRESSURE SWITCH (OPTION)


8–1 T-362

Figure 8.2 Schematic Diagram



T-362 8–2

Figure 8.3 Unit Wiring Diagram (Sheet 1 of 2)



8–3 T-362

мк DISPLAY MODULE MB(6)15(4)3(2)1)(0)9(8)7(6)5(4)3(2)1 -MB13 -мв9 -MB8 -MB6 -M84 -MB12 MB1 -MB10 -MB3 KEYPAD 0 71 B 8 2 93 11 (5) -CIC1 12 6 9 1 MB9-MB1-MB10-MB2-MB11-11 3 MB3-MB3-MB3-91 CONTROLLER COMMUNICATIONS (RED) 11 3 M83-(2) 4 M84-M813-M813-M813-M814-M815-M85-M85-M86-M86-M87-M87-M87-M87-M88-M88-M88-M88-M88-M88-M88-M88-M81-M84-M85-M8 MAINS POWER
FUSE
2 AT
(IF EQUIPPED) (B3) (B2) (B1 K) (B AMBS — ETS1 — (RED) — (RED) — HPSB — 5 1 6 2 TAN-BLK 7 3 ORN-8 4 5 MA4 Ē 6 MA10-6 5 F2 $\overline{\mathcal{I}}$ | CRE CIC 3 2 ETS2 (RED/WHT) ETSG (BLACK) F3A RM $C \leftarrow$ `(A) 2 3 4 5 F3B (KA11) RED RED 14 LOCATING TAB ON BOTTOM (2) (3) -TRX2-PHASE 1 FUSE 1 AT (IF EQUIPPED CIB)@@ -ST4 KE 5 EEVD-4 EEVB 7 6 5 4 FUSE 1 AT (IF EQUIPPED) KEYWAY SIDE -EFA1-10 9 8 7 6 5 4 3 2 1 -EF21-2 EEVA FUSE 1 AT 3 (IF EQUIPPED KD 4 VPS3~ 3 KA2 ~ 2 PA2 h 10 9 8 7 KA2 -квз TRX4 - RMC KB 6 6 5 $D \leftarrow$ (5) - ECN1-\C B\(\)
- ECN3-\C a\(\)
- ECM2-\C 0\(\)
- ECM3-\C a\(\)
- ECM3-\C a\(\)) 4 3 2 1 BATTERY -ECF2 4 PACK 2 5 8 3 ♦ ♦ ♦ ♦ -0C1-DUV EPT SPT HPS

Figure 8.4 Unit Wiring Diagram (Sheet 2 of 2)

T-362 8–4

Figure 8.5 Legend - Unit With Auto Transformer

ZONE S	SYMBOL	_	DESCRIPTION
C23	AMBS	_	AMBIENT SENSOR
L21	С	_	CONTROLLERS
J1	CB1	_	CIRCUIT BREAKER 460V
D1	CB2	_	
Di	CBZ		OPTIONAL CIRCUIT BREAKER 230V (DVM OPTION) TERMINAL BLOCK WHEN CB2 NOT PRESENT
N8,L11	CF	_	CONDENSER FAN CONTACTOR
L10,P1	CH	_	COMPRESSOR CONTACTOR
A4	CI	_	COMMUNICATIONS INTERFACE MODULE (OPTION)
L12	C-L	_	COOL LIGHT (OPTION)
E11,G11,R9	CM	_	CONDENSER FAN MOTOR
T4	CP		COMPRESSOR MOTOR
A23	CPDS		DISCHARGE TEMPERATURE SENSOR
		_	CURRENT SENSOR
M2	CS	_	
R8	DHBL	_	DEFROST HEATER - BOTTOM LEFT
T7	DHBR	_	DEFROST HEATER - BOTTOM RIGHT
R7	DHML	_	DEFROST HEATER - MIDDLE LEFT
T7	DHMR	_	DEFROST HEATER - MIDDLE RIGHT
R7	DHTL	_	DEFROST HEATER - TOP LEFT
T8	DHTR	_	DEFROST HEATER - TOP RIGHT
L7	DL	_	DEFROST LIGHT (OPTION)
K23	DPT	_	DISCHARGE PRESSURE TRANSDUCER
C23 F24	DTS DUV	_	DEFROST TEMPERATURE SENSOR DIGITAL UNLOADER VALVE
		_	
D1	DVM	_	DUAL VOLT MODULE (OPTIONAL)
F3	DVR	-	DUAL VOLTAGE RECEPTACLE (OPTIONAL)
R16	EEV	_	EVAPORATOR EXPANSION VALVE
N11,K13	EF	_	EVAPORATOR FAN CONTACTOR (HIGH SPEED)
T11,T13	EM	_	EVAPORATOR FAN MOTOR
E14,F14,G1			
H23	EPT	_	EVAP. PRESSURE TRANSDUCER
P10,L13	ES	_	EVAPORATOR FAN CONTACTOR (LOW SPEED)
D23	ETS	_	EVAPORATOR TEMPERATURE SENSOR (SUCTION)
J11	ESV	_	ECONOMIZER SOLENOID VALVE
C7,D7,F21,	F	_	FUSE
G21	1		1032
	FLA	_	FULL LOAD AMPS
G9	HPS	_	HIGH PRESSURE SWITCH
N7,L15	HR	_	HEATER CONTACTOR
F23	HS	_	HUMIDITY SENSOR (OPTIONAL)
E15	HTT	_	HEAT TERMINATION THERMOSTAT
T23	ICF	_	INTERROGATOR CONNECTOR FRONT
T24	ICR	_	INTERROGATOR CONNECTOR REAR
E14,F11, G14	IP	_	INTERNAL PROTECTOR
K15	IRL	_	IN-RANGE LIGHT (OPTION)
			•
K9,L8,N1	PA	_	UNIT PHASE CONTACTOR
K8,L9,N3	PB	_	UNIT PHASE CONTACTOR
M24,N24,	PR	_	PROBE RECEPTACLE (USDA OPTION)
P24	DTC1		DIG FOR VENT DOCITION CENCOR (HDDER)
N17	PTC1		PTC FOR VENT POSITION SENSOR (UPPER)
K7,L7,K12,	RM	_	REMOTE MONITORING RECEPTACLE (OPTION)
L12,K15, L15			
C23	RRS	_	RETURN RECORDER SENSOR
B23	RTS	_	RETURN TEMPERATURE SENSOR
H23	SPT	_	SUCTION PRESSURE TRANSDUCER
		_	SUPPLY RECORDER SENSOR
L23	SRS	_	
K5	ST	_	START-STOP SWITCH
A23	STS	-	SUPPLY TEMPERATURE SENSOR
D1,D2	TBU	_	TRANSFORMER BRIDGING UNIT
J9	TC	_	CONTROLLER RELAY (COOLING)
D6	TCC	_	TRANSFRESH COMMUNICATIONS CONNECTOR (OPTION)
J8,J9	TCP	_	CONTROLLER RELAY (PHASE SEQUENCING)
J14	TE	_	CONTROLLER RELAY (HIGH SPEED EVAPORATOR FANS)
J15	TH	_	CONTROLLER RELAY (HEATING)
		_	
E7	TF	_	CONTROLLER RELAY (DEFROST)
J15	ΤI	_	CONTROLLER RELAY (IN RANGE)
J12	TL	_	CONTROLLER RELAY (COOL LIGHT)
J11	TN	_	CONTROLLER RELAY (CONDENSER FAN)
H9,F10,	TP	_	TEST POINT
H11,G12,			
H13,G15,L1			TRANSFORMER
М3	TR	_	TRANSFORMER
D3	TRANS	_	TRANSFORMER AUTO 230/460 (OPTION)
E7	TRC	_	TRANSFRESH REAR CONNECTOR (OPTION)
E10	TS	_	CONTROLLER RELAY (ECONOMIZER SOLENOID VALVE)
J13	TV	_	CONTROLLER RELAY (LOW SPEED EVAPORATOR FANS)
N17	VPS	_	VENT POSITIONING SENSOR (UPPER) (OPTION)
J12	WCR		WETTING CURRENT SENSOR (OPTION)
E12	WP	_	
L 1 Z	** [_	WATER PRESSURE SWITCH (OPTION)

8–5 T-362


230-3-60 OR 190-3-50 POWER PLUG s2 ← C CS PB T1 12-4 SOV CABLE COMMUNICATIONS MODULE C D B 1 3 70 (тсс) KD1 21 CF | T1 (1 T1 PA PB

KD2 21 22 A1 A2 L2 | T2 | C2 | T2 | T3 | T3 | C5 | GRD ES T1 L2 T2 ECF2 ESV L3 | T3 K1 (T12 EM IP-CM CM4 IP S IP ECG1 ECG2 ECH1 ≺9८і 1 (+ T12 EM2 + Z2 (+ T11) 3 T13/ GRD/ IP-EM1 IP-EM2 P 5 P ECJ1 EM14 P 5 P EM16 EM26 EM24 ECJ2 ECD3 ₩ KB3 KEYPAD **⊕**− TP9 MK RECHARGEABLE BATTERY PACK = 7.2VDC + DISPLAY MODULE мв 1 4 10 8 6 1 MC 5 6 8 TP 6 5 4 3 2 1 14|13|12|11|10|9|8||1||10||1||6||5||4||3||2||1||4||3||2||1 KA | KB KC KD MB 28 F1 F2 F3A F3B CONTROLLER \oslash PROGRAMMING SLOT LAWBS

Figure 8.6 Schematic Diagram - Unit With Auto Transformer


T-362 8-6

Figure 8.7 Unit Wiring Diagram - Unit With Auto Transformer (Sheet 1 of 2)



8–7 T-362

Figure 8.8 Unit Wiring Diagram - Unit With Auto Transformer (Sheet 2 of 2)



T-362 8–8

SECTION 9 EU DECLARATION OF CONFORMITY



	Serial Number:
_	
	Manufacturing Date:

We, manufacturer:

Carrier Transicold Pte Ltd 251 Jalan Ahmad Ibrahim Singapore 629146

Declare, under our sole responsibility, that the PrimeLINE Container Unit:

|--|

is in conformity with the provisions of the following European Directives:

- Machinery Directive 2006/42/EC following Annex VIII
- Electromagnetic Compatibility Directive 2014/30/EU following Annex II
- Radio Equipment Directive 2014/53/EU Annex II (with select options)

The assembly was assessed for applicability under the Pressure Equipment Directive, 2014/68/EU, but determined to be outside of the scope based on the exclusion indicated in PED Article 1, Paragraph 2.f. The assembly was determined to be no higher than PED Category I and is covered by the Machinery Directive 2006/42/EC.

The following Harmonized Standards were applied for this equipment:

Machinery Directive	EMC Directive	RED Directive (with select option - TripLINK 12LB (CT4000))
=11100 10100 0010		, , , , , , , , , , , , , , , , , , , ,
EN ISO 12100:2010	EN 61000-6-2:2005	EN 61000-4-5:2006, EN 60950-1:2006,
EN 60204-1:2006	EN 61000-6-4:2007+A1:2011	EN 62368-1:2014, EN 62311:2008,
EN 13857:2008	EN55011:2009+A1:2010/CISPR11:2009+A1:2010	EN301 489-1 v2.1.1, EN 301 489-3 v2.1.1,
	EN61000-4-2:2009	EN 301 489-7 v1.3.1, EN 301 489-17 v3.2.1,
	EN 61000-4-3:2006,+A1:2008, +A2:2010	EN 301 489-19 v2.1.1, EN 301 489-20 v2.1.1,
	EN 61000-4-4:2012	EN 301 489-52 v1.1.0, EN 301 511 v12.5.1,
	EN 61000-4-5:2006	EN 301 908-1 v11.1.1, EN 301 908-2 v11.1.2,
	EN 61000-4-6:2009	EN 301 908-13 v11.1.2, EN 303 413 v1.1.1,
	EN 61000-4-8:2010	EN 300 328 v2.2.1, EN 300 220-2 v3.2.1
	EN 61000-4-11:2004	

The following Technical Standards were applied for this equipment:

· ISO 1496-2:2008

Person established in Europe authorized to compile a copy of the Technical File:

Shaun Bretherton Regional Service Manager EMEA Waalhaven Oostzijde 85 3087 BM Rotterdam The Netherlands

Nader Awwad, Engineering Director Carrier Transicold P.O. Box 4805 Date

9–1

Syracuse, New York 13221 USA (Authorized person to sign declaration on behalf of the manufacturer)



China RoHS per SJ/T 11364-2014

产品中有害物质的名称及含量

	有害物质					
	铅	汞	镉	六价铬	多溴联苯	多溴二苯醚
部件名称	(Pb)	(Hg)	(Cd)	(Cr (VI))	(PBB)	(PBDE)
金属板部件	0	0	0	0	0	0
塑料部件	0	0	0	0	0	0
盘管组件	Х	0	0	0	0	0
加热部件	0	0	0	0	0	0
马达, 压缩机与风扇组件	0	0	0	0	0	0
温度控制微处理器系统	Х	0	0	0	0	0
断路器与接触器	0	0	0	0	0	0
变压器	0	0	0	0	0	0
传感器	Х	0	0	0	0	0
通讯组件	0	0	0	0	0	0
阀组件	Х	0	0	0	0	0
电缆线/电源	0	0	0	0	0	0
电池	0	0	Х	0	0	0
标签与绝缘材料	0	0	0	0	0	0
玻璃部件	Х	0	0	0	0	0
十 = 4/5 / H O 1/T 44004 45 H 中心中心						

本表格依据 SJ/T 11364 的规定编制。

O: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。

X:表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。

62-66122-00, Rev A

INDEX

Numerics	Ambient Temperature Sensor (AMBS) Location 3–1
230 Volt Cable 2–3	Automatic Cold Treatment (ACT) Mode 4–14
460 Volt Cable 2–3	Automatic Cold Treatment (ACT) Mode Operation 5–12
A	Automatic Setpoint Change (ASC) Mode 4–15
Access Panels Location 3–1	Automatic Setpoint Change (ASC) Mode Operation 5–13
Adjust Fresh Air Makeup Vent 5–2	Autotransformer 2–2
Air-Cooled Condenser Section 3–2	Autotransformer Location 3–1
ALO3 4–30	Autotransformer Service 7–33
AL05 4–30 AL05 4–30	В
AL06 4–30	Back Panels 2–3
AL07 4–30	Battery 2–2, 7–36
AL08 4–30	Battery Replacement 7–36
AL09 4–31	Bulb Mode 4–8
AL10 4–31	Build Middle 4 0
AL14 4–31	C
AL16 4–32	Cable Restraint 2–3
AL17 4–32 AL17 4–32	Cd01 4-5
AL18 4–33	Cd03 4-5
AL19 4–33	Cd04 4-5
AL20 4–34	Cd05 4-5
AL21 4–34 AL21 4–34	Cd06 4-5
AL21 4–34 AL22 4–34	Cd07 4-5
AL23 4–34 AL23 4–35	Cd08 4-5
	Cd09 4-5
AL24 4–35	Cd10 4-5
AL25 4–35	Cd11 4-5
AL26 4–35	Cd12 4-5
AL27 4–35	Cd14 4-5
AL28 4–35	Cd15 4-5
AL29 4–36	Cd16 4-6
AL50 4–37 AL51 4–37	Cd17 4-6
	Cd18 4-6
AL52 4–37	Cd19 4-6
AL53 4–37	Cd20 4-6
AL54 4–37	Cd21 4-6
AL57.4.38	Cd22 4-6
AL57 4–38	Cd23 4-6
AL58 4–38	Cd25 4-6
AL59 4–38	Cd26 4-6
AL60 4–38	Cd27 4-7
AL61 4–38	Cd28 4-7
AL62 4–39	Cd29 4-7
AL64 4 30	Cd30 4-7
AL64 4–39	Cd34 4-8
AL65 4-40	Cd35 4-8
AL66 4-40	Cd36 4-9
AL67 4-40	Cd37 4-9
AL 70 4 40	Cd38 4-9
AL70 4-40	Cd39 4-9
AL71 4-40	Cd40 4-9
AL72 4–41	Cd41 4-9
AL96 4-41	Cd43 4-10

Index–1 T-362

Cd44 4-10	Container Unit Operation 5–1
Cd45 4-11	Container Unit Service 7–1
Cd46 4-11	Control Box 2–1
Cd47 4-11	Control Box Component Location 3–10
Cd48 4-12	Control Box Section 3–10
Cd49 4-12	Control Panel Location 3–1
Cd50 4-13	Controller 2–3, 7–34
Cd51 4-14	Controller Alarms Description 4–29
Cd53 4-15	Controller Description 4–1
Cd54 4-15	Controller Function Codes Check 5–5
Cd55 4-15	Controller Module Handling 7–34
Cd58 4-16	Controller Operational Software 4–4
Cd59 4-16	Controller Pre-Trip Test Codes 4–42
Cd60 4-16	Controller Software Description 4–3
Cd62 4-16	Controller Troubleshooting 7–35
Cd63 4-17	•
Cd65 4–17	D
Cd66 4–17	DataCORDER Communications 4–56
Cd67 4–17	DataCORDER Description 4–48
Cd70 4–18	DataCORDER Operational Software 4–51
Cd75 4–18	DataCORDER Power Up Procedure 4–53
Communications Interface Module 2–2, 3–10	Defrost Description 4–25
Communications Interface Module Installation 7–54	Defrost Operation 4–26
	Defrost Related Settings 4–27
Complete Inspection 5–5	Defrost Temperature Sensor (DTS) Location 3–7
Compressor Discharge Temperature Sensor (CDDS) Le	Defrost Temperature Sensor (DTS) Operation 4–26
Compressor Discharge Temperature Sensor (CPDS) Location 3–2	Defrost Temperature Sensor (DTS) Service 7–52
Compressor Discharge Temperature Sensor (CPDS)	Defrost Timer 4–27 Dehumidification 2–2
Service 7–52	
Compressor Location 3–1, 3–2	Digital Unloader Valve (DUV) Location 3–2
Compressor Section 3–2	Digital Unloader Valve (DUV) Service 7–31
Compressor Terminal Box Location 3–2	Discharge Connection Location 3–2
Condenser Coil 2–2	Discharge Pressure Transducer (DPT) Location 3–2
Condenser Coil Cleaning 7–11	Discharge Service Valve Location 3–2
Condenser Coil Cover Location 3–2	Display Module 4–2
Condenser Coil Installation 7–12	E
Condenser Coil Location 3–2	Economized Operation Description 3–14
Condenser Coil Service 7–11	Economizer Connection Location 3–2
Condenser Fan and Fan Motor Service 7–17	Economizer Expansion Valve (EXV) Location 3–2
Condenser Fan Location 3–1, 3–2	Economizer Expansion Valve (EXV) Service 7–30
Condenser Fan Motor Location 3–2	Economizer Heat Exchanger Location 3–1
Condenser Fan Motor Remove/Replace 7–17	Economizer Location 3–2
Condenser Grille 2–4	Economizer Solenoid Valve (ESV) Location 3–2
Condenser Grille and Venturi Assembly Location 3–2	Economizer Solenoid Valve (ESV) Service 7–29
Configuration Identification 2–1	Economy Mode 4–8
Configuration Software 4–3	Electrical Data 3–12
Configuration Variables 4–3	Electronic Expansion Valve (EEV) Description 3–14
Connect Power 5–1	Electronic Expansion Valve (EEV) Location 3–14 Electronic Expansion Valve (EEV) Location 3–7
Connect Remote Monitoring Receptacle 5–5	Electronic Expansion Valve (EEV) Service 7–26
Connect Water-Cooled Condenser 5–4	
Connection To 190/230 VAC Power 5–1	Emergency Bypass Operation (aption) 5, 8
Connection To 380/460 VAC Power 5–1	Emergency Bypass Operation (option) 5–8 Evacuation and Dehydration 7–5
Container Unit Description 3–1	-varianon ann 1400001400 /-9
Container Unit Description, Front Section 3–1	Evaporator 2–2 Evaporator Coil Heaters Location 3–7

T-362 Index–2

Francisco Ocil Lagation 0. 7	17
Evaporator Coil Location 3–7	K
Evaporator Coil Replacement 7–21	Keypad 4–1
Evaporator Coil Service 7–21	Keypad Location 3–1
Evaporator Fan #1 Location 3–7	L
Evaporator Fan #2 Location 3–7	-
Evaporator Fan and Motor Assembly Service 7–23	Labels 2–3
Evaporator Fan Operation 2–2	Logging Interval (dCF03) 4–51
Evaporator Heaters Megger Testing 7–22	Lower Air 2–3
Evaporator Pressure Transducer (EPT) Location 3–2	Lower Fresh Air Make Up 2–3
Evaporator Section 3–7	М
Evaporator Section Cleaning 7–25	Manifold Gauge Set 7–1
Evaporator Temperature Sensors (ETS1 / ETS2) Loca-	•
tion 3–7	Manual Pump Down 7–4
Evaporator Temperature Sensors (ETS1 / ETS2) Ser-	MCHE Coil Location 3–4
vice 7–52	MCHE Coil Repar Instructions 7–13
_	Micro-Link 3 Microprocessor 4–1
F	Microprocessor 4–1
Feature Descriptions 2–1	ML3 Controller 4–1
Filter Drier Location 3–2	Modes of Operation 4–19
Filter Drier Service 7–20	0
First Aid 1–1	-
Fork Lift Pockets Location 3–1	Oil Drain Location 3–2
Fresh Air Makeup Vent 3–7	Operating Precautions 1–1
Frozen "Heat" Mode 4-24	Options Descriptions 2–2
Frozen Economy Mode 4–24	Options Label Location 3–1
Frozen Idle Mode 4–24	Р
Frozen Mode Cooling, Sequence of Operation 4–24	P0-0 4–42
Frozen Mode, Temperature Control 4–23	P1-0 4–42
Frozen Steady State 4–23	P10-0 4–48
FuelWise Mode 4–17	P10-0 4-48
FuelWise Mode Operation 5–14	P10-1 4-48
FuelWise Option 2–4	
Function Codes Description 4–4	P1-1 4-43
Fusible Plug Location 3–2	P2-0 4-43
Table Flag Ecoalisti & Z	P2-1 4-43
G	P3-0 4-43
Gutters 2–3	P3-1 4-43
	P4-0 4-43
H	P4-1 4-43
Handles 2–3	P5-0 4-44
Heat Termination Thermostat (HTT) Location 3–7	P5-1 4–44
High Pressure Switch (HPS) Location 3–2	P5-10 4-45
High Pressure Switch (HPS) Replace 7–11	P5-11 4–45
High Pressure Switch (HPS) Service 7–10	P5-12 4–45
Humidity Sensor (HS) Location 3–7	P5-2 4-44
Humidity Sensor (HS) Service 7–27	P5-3 4-44
Humidity Sensor (HS) Troubleshooting 7–27	P5-7 4–44
	P5-8 4-44
<u> </u>	P5-9 4-44
Indicator Lights 4–2	P6-0 4-45
Inspection 5–1	P6-1 4-45
Interrogator 2–2	P6-10 4-46
Interrogator Connector Receptacle (ICR) Location 3–7	P6-2 4–45
Introduction 2–1, 9–1	P6-3 4-45
ISO Trip Header 4–59	P6-4 4–45
	· · · · · · · · · · · · · · · · · · ·

Index–3 T-362

P6-5 4-45	Refrigeration System Data 3–11
P6-6 4-46	Remote Monitoring 2–2
P6-7 4–46	Remote Monitoring Receptacle Location 3–1
P6-9 4–46	Replacing the Evaporator Fan Assembly 7–23
P7-0 4–46	Return Recorder Sensor (RRS) Location 3–7
P7-1 4–46	Return Recorder Sensor (RRS) Service 7–51
P8-0 4-47	Return Temperature Sensor (RTS) Location 3–7
P8-1 4–47	Return Temperature Sensor (RTS) Service 7–51
P8-2 4–47	resum remperature conser (itte) conser or
P9-0 4–47	S
Painted Surfaces 7–53	Safety and Protective Devices 3–13
Perishable Dehumidification 4–20	Safety Notices 1–1
Perishable Dehumidification, Bulb Mode 4–21	Safety Summary 1–1
Perishable Economy 4–21	Sampling Type (dCF05 & dCF06) 4-51
Perishable Heating 4–20	Sensor 7–51
3	Sensor Checkout 7–40
Perishable Idle, Air Circulation 4–19 Regionable Made Cooling, Seguence of Operation 4, 22	Sensor Configuration (dCF02) 4–49
Perishable Mode Cooling, Sequence of Operation 4–22	Service Access Valve Location 3–2
Perishable Mode Heating, Sequence of Operation 4–23	Service Connections 7–2
Perishable Mode Temperature Control 4–19	Specific Hazard Statements 1–1
Perishable Mode, Trim Heat 4–23	Standard Battery 7–36
Perishable Pulldown 4–19	Standard Operation Description 3–14
Perishable Steady State 4–19	Start Temperature Recorder 5–5
Pharma Mode 4–18	Start Up - Compressor Bump Start 4–19
Pharma Mode Operation 5–14	Start Up - Compressor Phase Sequence 4–19
Physical Inspection 5–5	Starting and Stopping Instructions 5–5
Plate Set 2–2	Starting the Unit 5–5
Power Cables and Plug Location 3–1	Start-Stop Switch (ST) Location 3–1
Pressure Readout 2–1	Start-Up Inspection 5–5
Pre-Trip Data Recording Description 4–55	Stopping the Unit 5–5
Pre-Trip Diagnosis 5–6	Suction Connection Location 3–2
Pre-Trip Diagnostics 4–42	Suction Pressure Transducer (SPT) Location 3–2
Pre-Trip Test Codes 4–42	Suction Service Valve Location 3–2
PrimeLINE 2–1	Supply Recorder Sensor (SRS) Location 3–2
PrimeLINE models 2–1	Supply Temperature Sensor (STS) Location 3–2
Probe Diagnostics 5–7	сарр. , тет.регалаге сет.сет (ст.с.) десалет с д
Protection Modes of Operation 4–28	T
Pump Down 7–3	Temperature Control Microprocessor System 4–1
Push Button Switches 4–2	Temperature Readout 2–1
Q	Temperature Sensor Service 7–40
QUEST Mode 4–13	Thermometer Port 2–3
QUEST Mode Operation 5–14	TripWise Mode 4–17
QUEST operation 4–28	TripWise Operation 5–9
QUEST Option 2–4	TripWise Option 2–4, 5–9
QOLOT OPHOTIZ	Troubleshooting Flow Chart 6–1
R	Troubleshooting P6- 7 (DUV) 7–30
Receiver Liquid Level / Moisture Indicator Location 3–2	Troubleshooting, Abnormal Currents 6–6
Receiver Location 3–2	Troubleshooting, Abnormal Pressures 6–4
Receiver Sight Glass Location 3–2	Troubleshooting, Abnormal Temperatures 6–6
Refrigerant - Adding Full Charge to System 7–7	Troubleshooting, Autotransformer Malfunction 6–6
Refrigerant - Adding Partial Charge to System 7–7	Troubleshooting, Compressor Operating in Reverse 6–6
Refrigerant - Checking Charge 7–6	Troubleshooting, Noise or Vibrations 6–4
Refrigerant Description 2–1	Troubleshooting, Starts Then Stops 6–2
Refrigerant Leak Checking 7–4	Troubleshooting, Unit Has Insufficient Heating 6–3
Refrigeration Circuit Description 3–14	Troubleshooting, Unit Operates Continuously in Cooling

T-362 Index-4

6-2

Troubleshooting, Unit Operates Long 6-2

Troubleshooting, Unit Runs but Insufficient Cooling 6–3

Troubleshooting, Unit Will Not Defrost Properly 6-3

Troubleshooting, Unit Will Not Heat 6-3

Troubleshooting, Unit Will Not Start 6-2

Troubleshooting, Unit Will Not Stop Heating 6–3

Troubleshooting, Water Cooled Condenser 6-6

U

Unit Display Location 3-1

Unit Identification Information 2-1

Unit Nameplate Location 3-1

Upper Fresh Air Make Up 2-3

Upper Fresh Air Makeup Vent 5-2

USDA 2-2

USDA / Message Trip Comment 4-57

USDA Cold Treatment Description 4-57

USDA Cold Treatment Procedure 4-57

USDA Probes Location 3-7

USDA Recording 4-57

V

Valve Override Controls 7-32

Vent Position Sensor (VPS) Operation 5-4

Vent Position Sensor (VPS) Service 7-53

W

Water Cooling 2-3

Water-Cooled Condenser (WCC) Cleaning 7-18

Water-Cooled Condenser (WCC) Description 3-6

Water-Cooled Condenser (WCC) Operation 5-4

X

XtendFRESH Mode 4-10

XtendFRESH Mode Operation 5-11

XtendFRESH Option 2-4

Index–5 T-362

