

\*EXTRA CARE MUST BE TAKEN WHEN USING MURIATION

\*EXTREMELY IMPORTANT TO VENTILATE THE WALK-IN

ACID OR OTHER HARSH CLEANING MATERIALS.

PROPERLY WHILE CONCRETE IS CURING.

INSTALLED IN A DEPRESSION, CONTACT THE

CARROLL COOLERS, INC. SALES DEPT. IMMEDIATELY

CARROLL COOLERS MUST KNOW IF YOU ARE USING

QUARRY TILE IN THE WALK-IN OR BUTTING UP TO

THE WALK-IN. ROUGH OPENINGS FOR PASS THRU

DOORS AND CCI DOORS WILL NEED MODIFICATION TO

ALLOW THE DOORS TO OPEN AND CLOSE PROPERLY.

CORE MATERIAL

20

400

R15578

FLAME SPREAD

SMOKE DEVELOPED

STEEL

20

OVER 500

<u>ALUMINUM</u>

30

OVER 500

EER. 0  $\bigcirc$ P.0. 30 ), A 51401 764-6834 -6748 HIGHWAY 19705 HIG CARROLL, 1 PHONE (8C FAX (712)

ᇢ ጀΩ ਹ 9

ON THIS DRAWING. FINAL DRAWING WILL BE

PRODUCED USING A SIGNED APPROVAL DWG.

WALK-IN COMPLIES WITH ALL PROVISIONS OF SECTION 312 OF THE ENERGY INDEPENDENCE AND SECURITY ACT OF 2007